

LH WARDROBE - REMOVAL/INSTALLATION

EFFECTIVITY: AIRCRAFT WITH LH WARDROBE

1. General

- A. This section gives the procedures to remove/install the LH wardrobe.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
25-26-04-000-803-A	LH WARDROBE OPTION 1 - REMOVAL	AIRCRAFT WITH LH WARDROBE OPTION 1
25-26-04-400-803-A	LH WARDROBE OPTION 1 - INSTALLATION	AIRCRAFT WITH LH WARDROBE OPTION 1
25-26-04-000-804-A	LH WARDROBE OPTION 2 - REMOVAL	AIRCRAFT WITH LH WARDROBE OPTION 2
25-26-04-400-804-A	LH WARDROBE OPTION 2 - INSTALLATION	AIRCRAFT WITH LH WARDROBE OPTION 2

TASK 25-26-04-000-803-A

EFFECTIVITY: AIRCRAFT WITH LH WARDROBE OPTION 1

2. LH WARDROBE OPTION 1 - REMOVAL

A. General

(1) This task gives the procedure to remove the LH wardrobe option 1.

B. References

REFERENCE	DESIGNATION
AMM TASK 25-27-05-000-801-A/400	-

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin
1	Helps the other technician	Passenger cabin

I. Preparation

SUBTASK 841-008-A

- (1) Make sure that the aircraft is safe for maintenance.
- (2) Make sure that the LH wardrobe is empty.
- (3) On the air conditioning/pneumatic control panel, installed on the overhead panel, make sure that the PASS CABIN rotary switch is not set to the ATTD position and attach a DO-NOT-SET-TO-ATTD-POSITION tag to it.
- (4) On the overhead panel, set the EMERG LT switch to OFF position and attach a DO-NOT-MOVE-FROM-OFF tag to it.
- (5) On the circuit breaker panel, open the EMERG circuit breaker and attach a DO-NOT-CLOSE tag to it (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
- (6) Remove the main door curtain assembly (AMM TASK 25-27-05-000-801-A/400).

- (7) Remove the sealant from the forward portion of the LH wardrobe.

J. LH Wardrobe - Removal (Figure 401)

SUBTASK 020-012-A

EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR

- (1) Remove the emergency equipment from the LH wardrobe (14).
- (2) Remove the sidewall fitting covers (10) with the screws (11).
- (3) Remove the bolts (12) and washers (13) that attach the LH wardrobe (14) to the sidewall track (9).
- (4) Remove the bolts (2) and washers (3) that attach the LH wardrobe (14) to the track engage fitting assemblies (5) on the floor track (4).

CAUTION: THE STEP BELOW MUST BE DONE WITH CARE TO PREVENT DAMAGE TO THE CONDITIONED AIR HOSE (7) AND THE ELECTRICAL CONNECTOR (1).

- (5) Lightly move the LH wardrobe (14) to the aisle to get access to the conditioned air hose (7) and the electrical connector (1).
- (6) Loosen the clamp (6) and remove the conditioned air hose (7) from the skirting lining panel flange (8).
- (7) Disconnect the electrical connector (1).
- (8) Remove the LH wardrobe (14).

K. LH Wardrobe with Shroud - Removal (Figure 402)

SUBTASK 020-013-A

EFFECTIVITY: AIRCRAFT WITH AIRSTAIRS DOOR

- (1) Remove the emergency equipment from the LH wardrobe (17).
- (2) Remove the shroud (4) with the screws (2) and washers (3).
- (3) Remove the sidewall fitting covers (13) with the screws (14).
- (4) Remove the bolts (15) and washers (16) that attach the LH wardrobe (17) to the sidewall track (12).
- (5) Remove the bolts (5) and washers (6) that attach the LH wardrobe (17) to the track engage fitting assemblies (8) on the floor track (7).

CAUTION: THE STEP BELOW MUST BE DONE WITH CARE TO PREVENT DAMAGE TO THE CONDITIONED AIR HOSE (9) AND THE ELECTRICAL CONNECTOR (1).


- (6) Lightly move the LH wardrobe (17) to the aisle to get access to the conditioned air hose (9) and the electrical connector (1).
- (7) Loosen the clamp (10) and remove the conditioned air hose (9) from the skirting lining panel flange (11).
- (8) Disconnect the electrical connector (1).

- (9) Remove the LH wardrobe (17).

EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR


LH Wardrobe Option 1 - Removal/Installation

Figure 401



145AMM250315.MCE

EFFECTIVITY: AIRCRAFT WITH AIRSTAIRS DOOR
LH Wardrobe Option 1 with Shroud - Removal/Installation
Figure 402



1 SEALANT APPLICATION REGION

145AMM250314.MCE

TASK 25-26-04-400-803-A

EFFECTIVITY: AIRCRAFT WITH LH WARDROBE OPTION 1

3. LH WARDROBE OPTION 1 - INSTALLATION

A. General

(1) This task gives the procedure to install the LH wardrobe option 1.

B. References

REFERENCE	DESIGNATION
AMM TASK 21-60-00-700-801-A/500	TEMPERATURE CONTROL SYSTEM - OPERATION-AL CHECK
AMM TASK 25-27-05-400-801-A/400	-
AMM TASK 33-21-00-700-801-A/500	PASSENGER CABIN LIGHTS - OPERATIONAL TEST
AMM TASK 33-25-00-700-801-A/500	READING AND ATTENDANT CALL LIGHTS (1) - OP-ERATIONAL TEST
AMM TASK 33-50-00-700-801-A/500	EMERGENCY LIGHTS - OPERATIONAL CHECK
AMM TASK 52-73-00-700-801-A/500	AIRSTAIRS MAIN DOOR WARNING MESSAGE - OP-ERATIONALLY CHECK
SRM 51-20-01	-

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

SPECIFICATION (BRAND)	DESCRIPTION	QTY
RTV 780 (black)	Sealant	AR

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin
1	Helps the other technician	Passenger cabin

I. LH Wardrobe - Installation (Figure 401)

SUBTASK 420-012-A

EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR

- (1) Remove the sealant residues (SRM 51-20-01) from the related area.
- (2) Put the LH wardrobe (14) in position.
- (3) Connect the electrical connector (1).
- (4) Attach the conditioned air hose (7) to the skirting lining panel flange (8) with the clamp (6).
- (5) Put the LH wardrobe (14) in its installation position.
- (6) Attach the LH wardrobe (14) to the sidewall track (9) with the bolts (12) and washers (13).
- (7) Attach the LH wardrobe (14) to the track engage fitting assemblies (5) on the floor track (4) with the bolts (2) and washers (3).
- (8) Install the sidewall fitting covers (10) with the screws (11).
- (9) Install the emergency equipment into the LH wardrobe (14).
- (10) Apply the sealant in the forward portion of the LH wardrobe (SRM 51-20-01).

J. LH Wardrobe with Shroud - Installation (Figure 402)

SUBTASK 420-013-A

EFFECTIVITY: AIRCRAFT WITH AIRSTAIRS DOOR

- (1) Remove the sealant residues (SRM 51-20-01) from the related area.
- (2) Put the LH wardrobe (17) in position.
- (3) Connect the electrical connector (1).
- (4) Attach the conditioned air hose (9) to the skirting lining panel flange (11) with the clamp (10).
- (5) Put the LH wardrobe (17) in its installation position.
- (6) Attach the LH wardrobe (17) to the sidewall track (12) with the bolts (15) and washers (16).
- (7) Attach the LH wardrobe (17) to the track engage fitting assemblies (8) on the floor track (7) with the bolts (5) and washers (6).
- (8) Install the sidewall fitting covers (13) with the screws (14).
- (9) Install the shroud (4) with the screws (2) and washers (3).
- (10) Install the emergency equipment into the LH wardrobe (17).
- (11) Apply the sealant in the forward portion of the LH wardrobe (SRM 51-20-01).

K. Follow-on

SUBTASK 842-008-A

- (1) Remove the DO-NOT-SET-TO-ATTD-POSITION tag from the air conditioning/pneumatic control panel, installed on the overhead panel.
- (2) Close the EMERG circuit breaker and remove the DO-NOT-CLOSE tag from it (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
- (3) On the overhead panel, set the EMERG LT switch to ARM position and remove the DO-NOT-MOVE-FROM-OFF tag from it.
- (4) Do an operational test of the emergency lights ([AMM TASK 33-50-00-700-801-A/500](#)).
- (5) Do an operational test of the attendant call and the Passenger Service Units (PSUs) ([AMM TASK 33-25-00-700-801-A/500](#)).
- (6) Do an operational test of the cabin lights ([AMM TASK 33-21-00-700-801-A/500](#)).
- (7) Do an operational test of the cabin temperature control ([AMM TASK 21-60-00-700-801-A/500](#)).
- (8) Do an operational test of the main door internal control panel ([AMM TASK 52-73-00-700-801-A/500](#)) (except for aircraft with side-hinged main door installed).
- (9) Install the main door curtain (AMM TASK 25-27-05-400-801-A/400).

TASK 25-26-04-000-804-A

EFFECTIVITY: AIRCRAFT WITH LH WARDROBE OPTION 2

4. LH WARDROBE OPTION 2 - REMOVAL

A. General

(1) This task gives the procedure to remove the LH wardrobe option 2.

B. References

REFERENCE	DESIGNATION
AMM TASK 25-27-05-000-801-A/400	-

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin
1	Helps the other technician	Passenger cabin

I. Preparation

SUBTASK 841-009-A

- (1) Make sure that the aircraft is safe for maintenance.
- (2) Make sure that the LH wardrobe is empty.
- (3) On the air conditioning/pneumatic control panel, installed on the overhead panel, make sure that the PASS CABIN rotary switch is not set to the ATTD position and attach a DO-NOT-SET-TO-ATTD-POSITION tag to it.
- (4) On the overhead panel, set the EMERG LT switch to OFF position and attach a DO-NOT-MOVE-FROM-OFF tag to it.
- (5) On the circuit breaker panel, open the EMERG circuit breaker and attach a DO-NOT-CLOSE tag to it (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
- (6) Remove the main door curtain assembly (AMM TASK 25-27-05-000-801-A/400).

- (7) Remove the sealant from the forward portion of the LH wardrobe.

J. LH Wardrobe - Removal (Figure 403)

SUBTASK 020-014-A

EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR

- (1) Remove the emergency equipment from the LH wardrobe (2).
- (2) Remove the sidewall fitting covers (11) with the screws (12).
- (3) Remove the bolts (13) and washers (14) that attach the LH wardrobe (2) to the sidewall track (10).
- (4) Remove the bolts (3) and washers (4) that attach the LH wardrobe (2) to the track engage fitting assemblies (6) on the floor track (5).

CAUTION: THE STEP BELOW MUST BE DONE WITH CARE TO PREVENT DAMAGE TO THE CONDITIONED AIR HOSE (8) AND THE ELECTRICAL CONNECTOR (1).

- (5) Lightly move the LH wardrobe (2) to the aisle to get access to the conditioned air hose (8) and the electrical connector (1).
- (6) Loosen the clamp (7) and remove the conditioned air hose (8) from the skirting lining panel flange (9).
- (7) Disconnect the electrical connector (1).
- (8) Remove the LH wardrobe (2).

K. LH Wardrobe with Shroud - Removal (Figure 404)

SUBTASK 020-015-A

EFFECTIVITY: AIRCRAFT WITH AIRSTAIRS DOOR

- (1) Remove the emergency equipment from the LH wardrobe (2).
- (2) Remove the shroud (5) with the screws (3) and washers (4).
- (3) Remove the sidewall fitting covers (14) with the screws (15).
- (4) Remove the bolts (16) and washers (17) that attach the LH wardrobe (2) to the sidewall track (13).
- (5) Remove the bolts (6) and washers (7) that attach the LH wardrobe (2) to the track engage fitting assemblies (9) on the floor track (8).

CAUTION: THE STEP BELOW MUST BE DONE WITH CARE TO PREVENT DAMAGE TO THE CONDITIONED AIR HOSE (11) AND THE ELECTRICAL CONNECTOR (1).


- (6) Lightly move the LH wardrobe (2) to the aisle to get access to the conditioned air hose (11) and the electrical connector (1).
- (7) Loosen the clamp (10) and remove the conditioned air hose (11) from the skirting lining panel flange (12).
- (8) Disconnect the electrical connector (1).

- (9) Remove the LH wardrobe (2).


EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR

LH Wardrobe Option 2 - Removal/Installation

Figure 403



EFFECTIVITY: AIRCRAFT WITH AIRSTAIRS DOOR
LH Wardrobe Option 2 with Shroud - Removal/Installation
Figure 404



TASK 25-26-04-400-804-A

EFFECTIVITY: AIRCRAFT WITH LH WARDROBE OPTION 2

5. LH WARDROBE OPTION 2 - INSTALLATION

A. General

(1) This task gives the procedure to install the LH wardrobe option 2.

B. References

REFERENCE	DESIGNATION
AMM TASK 21-60-00-700-801-A/500	TEMPERATURE CONTROL SYSTEM - OPERATION-AL CHECK
AMM TASK 25-27-05-400-801-A/400	-
AMM TASK 33-21-00-700-801-A/500	PASSENGER CABIN LIGHTS - OPERATIONAL TEST
AMM TASK 33-25-00-700-801-A/500	READING AND ATTENDANT CALL LIGHTS (1) - OP-ERATIONAL TEST
AMM TASK 33-50-00-700-801-A/500	EMERGENCY LIGHTS - OPERATIONAL CHECK
AMM TASK 52-73-00-700-801-A/500	AIRSTAIRS MAIN DOOR WARNING MESSAGE - OP-ERATIONALLY CHECK
SRM 51-20-01	-

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

SPECIFICATION (BRAND)	DESCRIPTION	QTY
RTV 780 (black)	Sealant	AR

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin
1	Helps the other technician	Passenger cabin

I. LH Wardrobe - Installation (Figure 403)

SUBTASK 420-014-A

EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR

- (1) Remove the sealant residues (SRM 51-20-01) from the related area.
- (2) Put the LH wardrobe (2) in position.
- (3) Connect the electrical connector (1).
- (4) Attach the conditioned air hose (8) to the skirting lining panel flange (9) with the clamp (7).
- (5) Put the LH wardrobe (2) in its installation position.
- (6) Attach the LH wardrobe (2) to the sidewall track (10) with the bolts (13) and washers (14).
- (7) Attach the LH wardrobe (2) to the track engage fitting assemblies (6) on the floor track (5) with the bolts (3) and washers (4).
- (8) Install the sidewall fitting covers (11) with the screws (12).
- (9) Install the emergency equipment into the LH wardrobe (2).
- (10) Apply the sealant in the forward portion of the LH wardrobe (SRM 51-20-01).

J. LH Wardrobe with Shroud - Installation (Figure 404)

SUBTASK 420-015-A

EFFECTIVITY: AIRCRAFT WITH AIRSTAIRS DOOR

- (1) Remove the sealant residues (SRM 51-20-01) from the related area.
- (2) Put the LH wardrobe (2) in position.
- (3) Connect the electrical connector (1).
- (4) Attach the conditioned air hose (11) to the skirting lining panel flange (12) with the clamp (10).
- (5) Put the LH wardrobe (2) in its installation position.
- (6) Attach the LH wardrobe (2) to the sidewall track (13) with the bolts (16) and washers (17).
- (7) Attach the LH wardrobe (2) to the track engage fitting assemblies (9) on the floor track (8) with the bolts (6) and washers (7).
- (8) Install the sidewall fitting covers (14) with the screws (15).
- (9) Install the shroud (5) with the screws (3) and washers (4).
- (10) Install the emergency equipment into the LH wardrobe (2).
- (11) Apply the sealant in the forward portion of the LH wardrobe (SRM 51-20-01).

K. Follow-on

SUBTASK 842-009-A

- (1) Remove the DO-NOT-SET-TO-ATTD-POSITION tag from the air conditioning/pneumatic control panel, installed on the overhead panel.
- (2) Close the EMERG circuit breaker and remove the DO-NOT-CLOSE tag from it (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
- (3) On the overhead panel, set the EMERG LT switch to ARM position and remove the DO-NOT-MOVE-FROM-OFF tag from it.
- (4) Do an operational test of the emergency lights ([AMM TASK 33-50-00-700-801-A/500](#)).
- (5) Do an operational test of the attendant call and the passenger service units (PSUs) ([AMM TASK 33-25-00-700-801-A/500](#)).
- (6) Do an operational test of the cabin lights ([AMM TASK 33-21-00-700-801-A/500](#)).
- (7) Do an operational test of the cabin temperature control ([AMM TASK 21-60-00-700-801-A/500](#)).
- (8) Do an operational test of the main door internal control panel ([AMM TASK 52-73-00-700-801-A/500](#)) (except for aircraft with side-hinged main door installed).
- (9) Install the main door curtain (AMM TASK 25-27-05-400-801-A/400).

