

VOR/NAV 3 CONTROL PANEL - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to remove and install the VOR/NAV 3 Control Panel.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
34-32-07-000-801-A	VOR/NAV 3 CONTROL PANEL - REMOVAL	ALL
34-32-07-400-801-A	VOR/NAV 3 CONTROL PANEL - INSTALLATION	ALL

TASK 34-32-07-000-801-A

EFFECTIVITY: ALL

2. VOR/NAV 3 CONTROL PANEL - REMOVAL

A. General

(1) This procedure gives the instructions to remove the VOR/NAV 3 Control Panel.

B. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
223/224		Cockpit

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	In the cockpit

H. Preparation

SUBTASK 841-002-A

- (1) On the circuit breaker panel, open the VOR/ILS 3 circuit breaker and attach a DO-NOT-CLOSE tag to it.
- (2) (Aircraft with VOR/NAV 3 control panel model CTL-23C) On the circuit breaker panel, open the VHF 3 circuit breaker and attach a DO-NOT-CLOSE tag to it.

I. Removal [\(Figure 401\)](#) [\(Figure 402\)](#)


SUBTASK 020-002-A

- (1) Loosen and remove the three screws (1) which attach the VOR/NAV 3 Control Panel (2) to the main instrument panel or to the control pedestal.
- (2) Carefully pull the VOR/NAV 3 Control Panel (2) from its housing to get access to the electrical connector (3).
- (3) Disconnect the electrical connector (3) from the VOR/NAV 3 Control Panel (2).
- (4) Remove the VOR/NAV 3 Control Panel (2).

EFFECTIVITY: ALL

VOR/NAV 3 Control Panel model CTL-23C - Removal/Installation

Figure 401




145AMM340439.MCE

EFFECTIVITY: ALL

VOR/NAV 3 Control Panel model CTL-32 - Removal/Installation

Figure 402



145AMM340435.MCE

TASK 34-32-07-400-801-A
EFFECTIVITY: ALL

3. VOR/NAV 3 CONTROL PANEL - INSTALLATION

A. General

(1) This procedure gives the instructions to install the VOR/NAV 3 Control Panel.

B. References

REFERENCE	DESIGNATION
AMM TASK 23-12-00-700-802-A/500	VHF-3 FUNCTIONAL TEST
AMM TASK 34-32-00-700-801-A/500	VOR/ILS SYSTEM OPERATIONAL TEST

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
223/224		Cockpit

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	In the cockpit

I. Installation (Figure 401) (Figure 402)

SUBTASK 420-002-A

- (1) Hold the VOR/NAV 3 control panel (2) and connect the electrical connector (3).
- (2) Put the VOR/NAV 3 Control Panel (2) in its installation position.
- (3) Install and tighten the three screws (1).

J. Follow-on

SUBTASK 842-002-A

- (1) On the circuit breaker panel, close the VOR/ILS 3 circuit breaker and remove the DO-NOT-CLOSE tag from it.

- (2) (Aircraft with VOR/NAV 3 control panel model CTL-23C) On the circuit breaker panel, close the VHF 3 circuit breaker and remove the DO-NOT-CLOSE tag from it.
- (3) Do the VOR/ILS Functional Test ([AMM TASK 34-32-00-700-801-A/500](#)).
- (4) (Aircraft with VOR/NAV 3 control panel model CTL-23C) Do the VHF 3 Functional Test ([AMM TASK 23-12-00-700-802-A/500](#)).