

## INSPECTION LIGHTS - ADJUSTMENT/TEST

*EFFECTIVITY: ALL*

1. General

- A. This section gives the procedures to do the test of the Inspection Lights.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
33-44-00-700-801-A	INSPECTION LIGHTS - OPERATIONAL TEST	ALL

TASK 33-44-00-700-801-A  
EFFECTIVITY: ALL

## 2. INSPECTION LIGHTS - OPERATIONAL TEST

### A. General

(1) This task gives the procedures to do the Operational Test of the Inspection Lights.

### B. References

REFERENCE	DESIGNATION
<a href="#">AMM SDS 33-44-00/1</a>	
<a href="#">AMM TASK 20-40-01-860-801-A/200</a>	ENERGIZATION OF THE AIRCRAFT WITH AN EXTERNAL POWER SOURCE

### C. Zones and Accesses

Not Applicable

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Cockpit

### I. Preparation

**SUBTASK 841-002-A**

(1) Energize the aircraft with the External DC Power Supply ( [AMM TASK 20-40-01-860-801-A/200](#) ).

(2) Make sure that the Circuit Breaker below is closed:

– INSP LIGHT ([AMM SDS 33-44-00/1](#)).

### J. Operationally Test Inspection Lights ([Figure 501](#))

**SUBTASK 710-002-A**

(1) Do the test of the Inspection Lights as follows:

(a) Set the INSP light switch, on the overhead panel, to the ON position.

Result:

1 The left inspection light, on the left wing-to-fairing forward panel, comes on.

2 The right inspection light, on the right wing-to-fairing forward panel, comes on.

(b) Set the INSP light switch, on the overhead panel, to the OFF position.

Result:

1 The left inspection light, on the left wing-to-fairing forward panel, goes off.

2 The right inspection light, on the right wing-to-fairing forward panel, goes off.

K. Follow-on




*SUBTASK 842-002-A*

(1) Deenergize the aircraft ( [AMM TASK 20-40-01-860-801-A/200](#) ).

EFFECTIVITY: ALL

Inspection Lights

Figure 501



DET. A

145AMM330041.MCE A