

## FLOOD/STORM LIGHT ASSEMBLY - REMOVAL/INSTALLATION

*EFFECTIVITY: ALL*

### 1. General

- A. This section gives the procedures to remove/install the flood/storm light assemblies.
- B. There are three flood/storm light assemblies, two for pilot and central zones and one flood/storm light assembly for the copilot zone.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
33-15-03-000-801-A	FLOOD/STORM LIGHT ASSEMBLY - RE-MOVAL	ALL
33-15-03-400-801-A	FLOOD/STORM LIGHT ASSEMBLY - IN-STALLATION	ALL

TASK 33-15-03-000-801-A

*EFFECTIVITY: ALL*

## 2. FLOOD/STORM LIGHT ASSEMBLY - REMOVAL

### A. General

(1) This task gives the procedures to remove one of the three flood/storm light assemblies.

### B. Zones and Accesses

<i>ZONE</i>	<i>PANEL/DOOR</i>	<i>LOCATION</i>
223/224		Cockpit

### C. Tools and Equipment

Not Applicable

### D. Auxiliary Items

Not Applicable

### E. Consumable Materials

Not Applicable

### F. Expandable Parts

Not Applicable

### G. Persons Recommended

<i>QTY</i>	<i>FUNCTION</i>	<i>PLACE</i>
1	Does the task	Where applicable

### H. Preparation

*SUBTASK 841-002-A*

(1) On the (left or right) light panel of the glareshield panel, set the FLOODLT knob to the OFF position.

### I. Removal [\(Figure 401\)](#)


*SUBTASK 020-002-A*

- (1) Disconnect the electrical connectors (1) from the flood/storm light assembly.
- (2) Loosen the dzus fasteners (3) which attach the flood/storm light assembly (2) to the glareshield panel bottom.
- (3) Remove the flood/storm light assembly (2).

EFFECTIVITY: ALL

Flood/storm Light Assembly - Removal/Installation

Figure 401



145AMM330063.MCE C

TASK 33-15-03-400-801-A

EFFECTIVITY: ALL

### 3. FLOOD/STORM LIGHT ASSEMBLY - INSTALLATION

#### A. General

(1) This task gives the procedures to install one of the three flood/storm light assemblies.

#### B. References

REFERENCE	DESIGNATION
<a href="#">AMM TASK 33-15-00-700-801-A/500</a>	FLOOD/STORM LIGHTS - OPERATIONAL CHECK

#### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
223/224		Cockpit

#### D. Tools and Equipment

Not Applicable

#### E. Auxiliary Items

Not Applicable

#### F. Consumable Materials

Not Applicable

#### G. Expandable Parts

Not Applicable

#### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Where applicable

#### I. Installation (Figure 401)

##### SUBTASK 420-002-A

- (1) Put the flood/storm light assembly (2) in its installation position.
- (2) Tighten the dzus fasteners (3).
- (3) Connect the electrical connectors (1) to the flood/storm light assembly.

#### J. Follow-on

##### SUBTASK 842-002-A

- (1) Do the Flood/Storm Lights Operational Test ( [AMM TASK 33-15-00-700-801-A/500](#) ).