

## CROSS BLEED VALVE - REMOVAL/INSTALLATION

*EFFECTIVITY: ALL*

1. General

- A. This section gives the procedures to remove and install the cross-bleed valve.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
36-10-01-000-801-A	CROSS-BLEED VALVE - REMOVAL	ALL
36-10-01-400-801-A	CROSS-BLEED VALVE - INSTALLATION	ALL
36-10-01-000-802-A	FILTER - REMOVAL	ALL
36-10-01-400-802-A	FILTER - INSTALLATION	ALL

TASK 36-10-01-000-801-A

EFFECTIVITY: ALL

## 2. CROSS-BLEED VALVE - REMOVAL

### A. General

(1) This procedure gives the instructions to remove the cross-bleed valve.

### B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
272	272DR	Fuselage rear section I

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	In the aft electronic compartment

### I. Preparation

**SUBTASK 841-002-A**

- (1) Remove access panel 272DR (AMM MPP 06-41-01/100).
- (2) On the circuit breaker panel, open the CROSS BLEED circuit breaker and attach a DO-NOT-CLOSE tag to it.

### J. Removal (Figure 401)

**SUBTASK 020-002-A**

**WARNING: DO NOT TOUCH THE BLEED-AIR SYSTEM DUCTS OR COMPONENTS IMMEDIATELY AFTER THE ENGINE OR APU STOPS BECAUSE OF THE HIGH BLEED-AIR TEMPERATURE.**


- (1) Disconnect the electrical connector (6).

- (2) Release the Marman clamp (8) to disconnect the cross-bleed valve (4).
- (3) Remove the bolt (1), washer (2), and nut (7) to disconnect the anti-rotation support (9).
- (4) Install the plastic plugs to the ducts (3) and (5).

EFFECTIVITY: ALL

Cross-bleed Valve - Removal/Installation

Figure 401



145AMM360048.MCE B

TASK 36-10-01-400-801-A  
EFFECTIVITY: ALL

3. CROSS-BLEED VALVE - INSTALLATION

A. General

(1) This procedure gives the instructions to install the cross-bleed valve.

B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
AMM TASK 36-00-00-700-803-A/500	AIR BLEED SYSTEM - OPERATIONAL TEST
AMM TASK 36-00-00-860-802-A/200	PNEUMATIC ENERGY - AIR BLEED THROUGH THE APU
AMM TASK 36-11-09-200-803-A/600	AIR-BLEED LINES - LEAK INSPECTION

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
272	272DR	Fuselage rear section I

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	In the aft electronic compartment

I. Installation (Figure 401)

*SUBTASK 420-002-A*

- (1) Remove the plastic plugs from the ducts (3) and (5).
- (2) Put the cross-bleed valve (4) with the arrow in the bleed-air flow direction in the installation position.
- (3) Install the washer (2), bolt (1), and nut (7) to connect the anti-rotation support (9).
- (4) Connect the cross-bleed valve ducts (3) and (5) and tighten the Marman clamp (8) to the torque shown in (Figure 401).

- (5) Tighten the bolt (1) and nut (7) that attach the cross-bleed valve to the support (9).
- (6) Connect the electrical connector (6).

J. Follow-on

*SUBTASK 842-002-A*

- (1) On the circuit breaker panel, close the CROSS BLEED circuit breaker and remove the DO-NOT-CLOSE tag from it.
- (2) Do the operational test of the air bleed system ( [AMM TASK 36-00-00-700-803-A/500](#)) or bleed the air through the APU ( [AMM TASK 36-00-00-860-802-A/200](#)) and do a check for leakage at the cross-bleed valve clamps ( [AMM TASK 36-11-09-200-803-A/600](#)).
- (3) Install access panel 272DR (AMM MPP 06-41-01/100).

TASK 36-10-01-000-802-A

EFFECTIVITY: ALL

#### 4. FILTER - REMOVAL

##### A. General

(1) This task gives the instructions to remove the filter from the cross-bleed valve.

##### B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-

##### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
272	272DR	Fuselage rear section I

##### D. Tools and Equipment

Not Applicable

##### E. Auxiliary Items

Not Applicable

##### F. Consumable Materials

Not Applicable

##### G. Expandable Parts

Not Applicable

##### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	In the aft electronic compartment

##### I. Preparation

###### *SUBTASK 841-003-A*

- (1) Remove access panel 272DR (AMM MPP 06-41-01/100).
- (2) On the circuit breaker panel, open the CROSS BLEED circuit breaker and attach a DO-NOT-CLOSE tag to it.

##### J. Removal (Figure 402)

###### *SUBTASK 020-003-A*

**WARNING: DO NOT TOUCH THE BLEED-AIR SYSTEM DUCTS OR COMPONENTS IMMEDIATELY AFTER THE ENGINE OR APU STOPS BECAUSE OF THE HIGH BLEED-AIR TEMPERATURE.**

- (1) Remove the plug (1) from the cross-bleed valve.




- 
- (2) Remove the O-ring (2) and spring (3) from the filter (4).
  - (3) Remove the filter (4) from the cross-bleed valve.
  - (4) Install the plug (1) on the cross-bleed valve.



EFFECTIVITY: ALL

Filter - Removal/Installation

Figure 402



1 TORQUE: 4.0 – 4.5 N.m (35 – 40 lb.in)

145AMM360261A.MCE

TASK 36-10-01-400-802-A

EFFECTIVITY: ALL

## 5. FILTER - INSTALLATION

### A. General

(1) This task gives the instructions to install the filter in the cross-bleed valve.

### B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
272	272DR	Fuselage rear section I

### D. Tools and Equipment

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Torque wrench (Range: 0 - 75 lb.in)	To tighten the plug	

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	In the aft electronic compartment

### I. Installation (Figure 402)

#### SUBTASK 420-003-A

(1) Remove the plug (1) from the cross-bleed valve.

**CAUTION:** REFER TO FIGURE 402 FOR THE CORRECT INSTALLATION POSITION OF THE FILTER IN THE CROSS-BLEED VALVE.

(2) Install the filter (4) in the cross-bleed valve.

(3) Install the O-ring (2) and spring (3) on the filter (4).

(4) Install the plug (1) in the cross-bleed valve.

- (5) Tighten the plug (1) to the specified torque (Figure 402).

J. Follow-on

*SUBTASK 842-003-A*

- (1) Install the access panel 272DR (AMM MPP 06-41-01/100).
- (2) On the circuit breaker panel, close the CROSS BLEED circuit breaker and remove the DO-NOT-CLOSE tag from it.

