

INTEGRATED COMPUTERS - ADJUSTMENT/TEST

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to do the test of the integrated computers.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
31-42-00-700-801-A	INTEGRATED COMPUTERS - OPERATIONAL TEST	ALL

TASK 31-42-00-700-801-A

EFFECTIVITY: ALL

2. INTEGRATED COMPUTERS - OPERATIONAL TEST

A. General

(1) This task gives the procedures to do the operational test of the integrated computers.

B. References

REFERENCE	DESIGNATION
AMM SDS 23-12-00/1	
AMM SDS 23-51-00/1	
AMM SDS 23-81-00/1	
AMM SDS 31-41-00/1	
AMM SDS 31-42-00/1	
AMM SDS 32-30-00/1	
AMM SDS 34-22-00/1	
AMM SDS 34-31-00/1	
AMM SDS 34-32-00/1	
AMM SDS 34-43-00/1	
AMM SDS 34-51-00/1	
AMM SDS 34-52-00/1	
AMM SDS 34-53-00/1	
AMM TASK 20-40-01-860-801-A/200	ENERGIZATION OF THE AIRCRAFT WITH AN EXTERNAL POWER SOURCE

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
223/224		Cockpit

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Cockpit

I. Preparation

SUBTASK 841-002-A

- (1) Make sure that the aircraft is safe for maintenance.
- (2) Energize the aircraft with the external DC power supply ([AMM TASK 20-40-01-860-801-A/200](#)).
- (3) Make sure that these systems are operational and on:
 - VHF System ([AMM SDS 23-12-00/1](#)).
 - Airborne Audio System ([AMM SDS 23-51-00/1](#)).
 - Radio Management System ([AMM SDS 23-81-00/1](#)).
 - EICAS ([AMM SDS 31-41-00/1](#)).
 - Integrated Computer System ([AMM SDS 31-42-00/1](#)).
 - EFIS ([AMM SDS 34-22-00/1](#)).
 - Radio Altimeter System ([AMM SDS 34-31-00/1](#)).
 - VOR/ILS/GS/MB System ([AMM SDS 34-32-00/1](#)).
 - TCAS ([AMM SDS 34-43-00/1](#)).
 - DME System ([AMM SDS 34-51-00/1](#)).
 - Mode-S Transponder ([AMM SDS 34-52-00/1](#)).
 - ADF System ([AMM SDS 34-53-00/1](#)).

J. Integrated Computers - Operational Test Procedures ([Figure 501](#)) ([Figure 502](#)) ([Figure 503](#)) ([Figure 504](#)) ([Figure 505](#)) ([Figure 506](#))

SUBTASK 710-002-A

- (1) With the aircraft on the ground (WOW) ([AMM SDS 32-30-00/1](#)), do the test of the integrated computers as follows:
 - (a) On the DC-550 1 display controller (left side) ([AMM SDS 34-22-00/1](#)), on the glareshield panel, use the RA knob (RA-TEST switch) to set 920 RA (DH) on PFD 1.
 - (b) On the DC-550 1 display controller, on the glareshield panel, push and hold the RA-TEST switch.

Result:

 - 1 The test indications of PFD 1 (first level), MFD 1, and EICAS come into view.

- 2 After a few seconds, PFD 1 (left side) shows the Honeywell test page (second level), with the IC-600 IBIT indications and respective status.

NOTE: At this time, the status of the indications must change from FAIL to PASS. If the indication status stays in FAIL, you must repair the failure.

- (c) On DC-550 1, release the RA-TEST switch.
- (d) On the DC-550 2 display controller (right side) ([AMM SDS 34-22-00/1](#)), on the glareshield panel, use the RA knob (RA-TEST switch) to set 920 RA (DH) on PFD 2.

- (e) On the DC-550 2 display controller, push and hold the RA-TEST switch.

Result:

- 1 The test indications of PFD 2 (first level) and MFD 2 come into view.
- 2 After a few seconds, PFD 2 (right side) shows the Honeywell test page (second level), with the IC-600 IBIT indications and respective status.

NOTE: At this time, the status of the indications must change from FAIL to PASS. If the indication status stays in FAIL, you must repair the failure.



- (f) On DC-550 2, release the RA-TEST switch.

K. Follow-on

SUBTASK 842-002-A

- (1) Deenergize the aircraft ([AMM TASK 20-40-01-860-801-A/200](#)).

EFFECTIVITY: ALL
DC-550 Display Controller
Figure 501





DET. A

145AMM340021.MCE A

EFFECTIVITY: ALL

PFDs Test Indication - First Level

Figure 502




DET. A

145AMM310060.MCE A

EFFECTIVITY: ALL

PFD 1 Test Indication - Second Level

Figure 503




DET. A

145AMM310061.MCE B

EFFECTIVITY: ALL

PFD 2 Test Indication - Second Level



Figure 504



DET. A

145AMM310062.MCE A



EFFECTIVITY: ALL
MFDs Test Indication
Figure 505



DET. A

145AMM310063.MCE A

EFFECTIVITY: ALL
EICAS Test Indication
Figure 506



DET. A

145AMM310064.MCE A