

## DISPLAY CONTROLLER (DC-550) - REMOVAL/INSTALLATION

*EFFECTIVITY: ALL*

### 1. General

- A. This section gives the procedure to remove/install the DC-550 Display Controller Panels.
- B. The DC-550 Display Controller Panels are installed on the Instruments Panel.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
34-22-04-000-801-A	DC-550 DISPLAY CONTROLLER PANEL - REMOVAL	ALL
34-22-04-400-801-A	DC-550 DISPLAY CONTROLLER PANEL - INSTALLATION	ALL

TASK 34-22-04-000-801-A

*EFFECTIVITY: ALL*

## 2. DC-550 DISPLAY CONTROLLER PANEL - REMOVAL

### A. General

(1) This task gives the procedure to remove the DC-550 Display Controller Panels.

### B. Zones and Accesses

Not Applicable

### C. Tools and Equipment

Not Applicable

### D. Auxiliary Items

Not Applicable

### E. Consumable Materials

Not Applicable

### F. Expandable Parts

Not Applicable

### G. Persons Recommended

<i>QTY</i>	<i>FUNCTION</i>	<i>PLACE</i>
1	Does the task	Cockpit

### H. Preparation

#### *SUBTASK 841-002-A*

(1) On the Circuit Breaker Panel, open the Display Control 1 or Display Control 2 circuit breaker and attach a DO-NOT-CLOSE tag to it.

### I. Removal [\(Figure 401\)](#)


#### *SUBTASK 020-002-A*

- (1) Loosen the dzus fastener (1).
- (2) Pull the DC-550 Display Controller Panel (2) to gain access to the connector (3).
- (3) Disconnect the connector (3) from the DC-550 Display Controller Panel (2).
- (4) Remove the DC-550 Display Controller Panel (2).

EFFECTIVITY: ALL

DC-550 Display Controller Panels - Removal/Installation

Figure 401



145AMM340209.MCE A

TASK 34-22-04-400-801-A

EFFECTIVITY: ALL

### 3. DC-550 DISPLAY CONTROLLER PANEL - INSTALLATION

#### A. General

(1) This task gives the procedure to install the DC-550 Display Controller Panels.

#### B. References

REFERENCE	DESIGNATION
<a href="#">AMM TASK 34-22-00-700-801-A/500</a>	ELECTRONIC FLIGHT INSTRUMENT SYSTEM - OPERATIONAL CHECK

#### C. Zones and Accesses

Not Applicable

#### D. Tools and Equipment

Not Applicable

#### E. Auxiliary Items

Not Applicable

#### F. Consumable Materials

Not Applicable

#### G. Expandable Parts

Not Applicable

#### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Cockpit

#### I. Installation (Figure 401)

##### *SUBTASK 420-002-A*

- (1) Connect the connector (3) in the DC-550 Display Controller Panel (2).
- (2) Put the DC-550 Display Controller Panel (2) in position.
- (3) Tighten the dzus fastener (1).

#### J. Follow-on

##### *SUBTASK 410-002-A*

- (1) On the Circuit Breaker Panel, close the Display Control 1 or Display Control 2 circuit breaker and remove the DO-NOT-CLOSE tag from it.
- (2) Do the EFIS OPERATIONAL CHECK ( [AMM TASK 34-22-00-700-801-A/500](#) ).