

## ELECTRIC PULSE/LATCHING ON-OFF VALVE - MAINTENANCE PRACTICES

*EFFECTIVITY: AIRCRAFT FOR 16 PASSENGERS*

### 1. General

- A. This section gives the maintenance practices for the Electric Pulse/Latching On-Off Valve.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
35-20-10-900-801-A	ELECTRIC PULSE/LATCHING ON-OFF VALVE - RESTORATION	AIRCRAFT FOR 16 PASSENGERS

TASK 35-20-10-900-801-A

*EFFECTIVITY: AIRCRAFT FOR 16 PASSENGERS*

## 2. ELECTRIC PULSE/LATCHING ON-OFF VALVE - RESTORATION

### A. General

- (1) Refer to the latest revision of Pacific Precision Products ACMM 35-20-02 to restore the Electric Pulse/Latching On-Off Valve.
- (2) The Electric Pulse/Latching On-Off Valve is installed in the closeout panel beside the galley.

### B. References

<i>REFERENCE</i>	<i>DESIGNATION</i>
AMM TASK 35-20-10-000-801-A/400	-
AMM TASK 35-20-10-400-801-A/400	-
Pacific Precision Products ACMM 35-20-02	-

### C. Zones and Accesses

Not Applicable

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

Not Applicable

### I. Preparation

#### *SUBTASK 841-004-A*

- (1) Remove the Electric Pulse/Latching On-Off Valve (AMM TASK 35-20-10-000-801-A/400).

### J. Restore Electric Pulse/Latching On-Off Valve

#### *SUBTASK 900-004-A*

- (1) Refer to the latest revision of Pacific Precision Products ACMM 35-20-02 to restore the Electric Pulse/Latching On-Off Valve.

### K. Follow-on

#### *SUBTASK 842-004-A*

- (1) Install the Electric Pulse/Latching On-Off Valve (AMM TASK 35-20-10-400-801-A/400).