

## ENGINE - SERVICING

*EFFECTIVITY: ALL*

### 1. General

- A. This section gives the procedures for the engine oil servicing.
- B. The engine oil system is serviced as necessary. The oil that is used to service the engine must be in the table of approved oils given in [AMM MPP 20-30-02/200](#).
- C. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
<a href="#">12-12-01-600-801-A</a>	ENGINE - SERVICING	ALL

TASK 12-12-01-600-801-A

EFFECTIVITY: ALL

## 2. ENGINE - SERVICING

### A. General

- (1) This task gives the procedure to replenish the engine oil tanks. The oil that is used to service the engine must be in the table of approved oils given in [AMM MPP 20-30-02/200](#).

### B. References

REFERENCE	DESIGNATION
<a href="#">AMM MPP 06-43-00/100</a>	- COMPONENT LOCATION
<a href="#">AMM MPP 20-30-02/200</a>	- MAINTENANCE PRACTICES
<a href="#">AMM MPP 71-00-00/200</a>	- MAINTENANCE PRACTICES

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	413BB	Cowling door, LH
423	423BB	Cowling door, RH

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To give access to the engine	1

### F. Consumable Materials

SPECIFICATION (BRAND)	DESCRIPTION	QTY
MIL-PRF-23699STD, MIL-PRF-23699HTS or MIL-PRF-7808	Engine oil	AR

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine

I. Preparation

*SUBTASK 841-002-A*

**WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN [AMM MPP 71-00-00/200](#) TO PREVENT INJURY TO THE PERSONS AND DAMAGE TO THE MATERIAL.**

- (1) On the overhead circuit breaker panel, open the START 1 and START 2 circuit breakers and attach DO-NOT-CLOSE tags to them.

**WARNING: DO NOT OPEN OR KEEP ENGINE ACCESS DOORS OPEN IF THE WIND IS MORE THAN 50 KNOTS.**

- (2) Open access door 413BB of the LH engine and access door 423BB of the RH engine ([AMM MPP 06-43-00/100](#)).

J. Engine Oil - Servicing

*SUBTASK 610-002-A*

- (1) Refer to the latest revision of Rolls-Royce MM CSP 34022.

K. Follow-on

*SUBTASK 842-002-A*

- (1) On the overhead circuit breaker panel, remove the DO-NOT-CLOSE tags and close the START 1 and START 2 circuit breakers.
- (2) Close access door 413BB of the LH engine and access door 423BB of the RH engine ([AMM MPP 06-43-00/100](#)).

