
LANDING GEAR TIRES - SERVICING

EFFECTIVITY: ALL

1. General

- A. The procedures for the servicing on the landing gear tires is given in [AMM TASK 32-49-01-600-801-A/300](#) (for the main landing gear) and [AMM TASK 32-49-04-600-801-A/300](#) (for the nose landing gear).

