

RELIEF VALVE - ADJUSTMENT/TEST

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to do the check of the check/relief valve.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

<i>TASK NUMBER</i>	<i>DESCRIPTION</i>	<i>EFFECTIVITY</i>
28-21-03-700-801-A ◆	CHECK RELIEF VALVE - FUNCTIONAL CHECK	ALL

TASK 28-21-03-700-801-A

EFFECTIVITY: ALL

2. CHECK RELIEF VALVE - FUNCTIONAL CHECK

A. General

- (1) To do the check, it is necessary to remove the check valve from the aircraft fuel system.

B. References

REFERENCE	DESIGNATION
AMM MPP 28-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 28-21-03-000-801-A/400	CHECK/RELIEF VALVE - REMOVAL
AMM TASK 28-21-03-000-802-A/400	CHECK/RELIEF VALVE - REMOVAL
AMM TASK 28-21-03-400-801-A/400	CHECK/RELIEF VALVE - INSTALLATION
AMM TASK 28-21-03-400-802-A/400	CHECK/RELIEF VALVE - INSTALLATION

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Wing stub

I. Preparation

SUBTASK 841-002-A

WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN AMM MPP 28-00-00/200 TO PREVENT INJURY TO PERSONS AND DAMAGE TO THE MATERIAL.

- (1) Remove the check/relief valve (AMM TASK 28-21-03-000-801-A/400) or (AMM TASK 28-21-03-000-802-A/400) as applicable.

J. Functionally Check Relief Valve

SUBTASK 720-002-A

- (1) Do the functional check (on a bench) of the check/relief valve. Refer to the last revision of Parker Hannifin ACMM 28-22-09.

K. Follow-on

SUBTASK 842-002-A

- (1) Install the check/relief valve ([AMM TASK 28-21-03-400-801-A/400](#)) or ([AMM TASK 28-21-03-400-802-A/400](#)) as applicable.

