

CENTER WING LEADING EDGE - INTERNAL - INSPECTION/CHECK

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to do the visual inspection of center the wing leading edge for general condition.
- B. Related Zones: 512/612.
- C. Zone Boundaries: STA Y = -3815.00 (rib 9) thru STA YA = -6937.00 (rib17).
- D. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
05-20-96-200-801-A	CENTER WING LEADING EDGE - INTERNAL GENERAL VISUAL INSPECTION	ALL

TASK 05-20-96-200-801-A  
EFFECTIVITY: ALL

## 2. CENTER WING LEADING EDGE - INTERNAL GENERAL VISUAL INSPECTION

### A. General

- (1) This task gives instructions to do the internal general visual inspection (GVI) of wing, at zones 512/612, within a touching distance of the items examined.
- (2) The function of the internal general visual inspection (GVI) is to find damage, failure, or irregular conditions that can be easily seen.

### B. References

REFERENCE	DESIGNATION
<a href="#">AMM TASK 57-42-00-000-801-A/400</a>	LEADING EDGE II - REMOVAL
<a href="#">AMM TASK 57-42-00-400-801-A/400</a>	LEADING EDGE II - INSTALLATION

### C. Zones and Accesses

Not Applicable

### D. Tools and Equipment

ITEM	DESCRIPTION	PURPOSE	QTY
Standard	Stand	To get access to the inspection area	

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Center wing leading edge

### I. Preparation

#### *SUBTASK 841-002-A*

- (1) On the circuit breaker panel, open the WING circuit breaker and attach a DO-NOT-CLOSE tag to it.
- (2) Put the stand in position.
- (3) Remove the center wing leading edge ( [AMM TASK 57-42-00-000-801-A/400](#)).

J. Internal General Visual Inspection ([Figure 601](#))

*SUBTASK 212-002-A*

- (1) Examine the interior of the zone for loose rivets, skin deformation, nicks, cracks, dents, scratches, gouges, creases, erosion, corrosion, deteriorated protective treatment, and foreign objects ([Figure 601](#)).
- (2) Examine the interior of the zone for leakage on the skin, signs of friction, tension, and signs of overheating.

K. Follow-on


*SUBTASK 842-002-A*

- (1) Install the center wing leading edge ( [AMM TASK 57-42-00-400-801-A/400](#)).
- (2) On the circuit breaker panel, close the WING circuit breaker and remove the DO-NOT-CLOSE tag from it.
- (3) Remove the stand.

EFFECTIVITY: ALL

Center Wing Leading Edge - Internal General Visual Inspection

Figure 601



145AMM050216.MCE A