

---

LANDING GEAR - SERVICING

*EFFECTIVITY: ALL*

1. General

- A. The procedure for the lubrication on the Main Landing Gear and Nose Landing Gear is given in [AMM TASK 32-34-00-600-801-A/300](#).

