

AILERON SERVO - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to remove and install the aileron autopilot servo of the Automatic Flight-Control System and its support.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
22-11-03-000-801-A	AILERON AUTOPILOT SERVO - REMOVAL	ALL
22-11-03-400-801-A	AILERON AUTOPILOT SERVO - INSTALLATION	ALL
22-11-03-000-802-A	SUPPORT OF THE AILERON AUTOPILOT SERVO - REMOVAL	ALL
22-11-03-400-802-A	SUPPORT OF THE AILERON AUTOPILOT SERVO - INSTALLATION	ALL

TASK 22-11-03-000-801-A

EFFECTIVITY: ALL

2. AILERON AUTOPILOT SERVO - REMOVAL

A. General

- (1) This procedure gives the instructions to remove the aileron autopilot servo of the Automatic Flight-Control System.

B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
123	123BL	Below the cockpit floor

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Below the cockpit floor

I. Preparation

SUBTASK 841-002-A

- (1) On the Circuit Breaker Panel, open the AP 1 circuit breaker and attach a DO-NOT-CLOSE tag to it.
- (2) Remove access door 123BL (AMM MPP 06-41-01/100).

J. Removal (Figure 401)

SUBTASK 020-002-A

- (1) Cut the lockwires.
- (2) Remove the screw (1) and washers (2) (4 positions) that attach the aileron autopilot servo (4) to the support (3).




- (3) Disconnect the electrical connector (5).
- (4) Remove the aileron autopilot servo (4).

EFFECTIVITY: ALL

Aileron Autopilot Servo - Removal/Installation

Figure 401



145AMM220001.MCE A

TASK 22-11-03-400-801-A
EFFECTIVITY: ALL

3. AILERON AUTOPILOT SERVO - INSTALLATION

A. General

- (1) This procedure gives the instructions to install the aileron autopilot servo of the Automatic Flight-Control System.

B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
AMM TASK 22-11-00-700-803-A/500	AUTOPILOT - FUNCTIONAL TEST

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
123	123BL	Below the cockpit floor

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

SPECIFICATION (BRAND)	DESCRIPTION	QTY
MS20995C20	Lockwire	AR

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Below the cockpit floor

I. Installation (Figure 401)

SUBTASK 420-002-A

- (1) Connect the electrical connector (5) to the aileron autopilot servo (4).
- (2) Put the aileron autopilot servo (4) on the support (3).
- (3) Install the screw (1) and washers (2) (4 positions) to attach the aileron autopilot servo (4) to the support (3).
- (4) Safety the screw (1) with lockwire.

J. Follow-on

SUBTASK 842-002-A

- (1) On the Circuit Breaker Panel, close the AP 1 circuit breaker and remove the DO-NOT-CLOSE tag from it.
- (2) Do the Autopilot-Functional Test ([AMM TASK 22-11-00-700-803-A/500](#)).
- (3) Install access door 123BL (AMM MPP 06-41-01/100).

TASK 22-11-03-000-802-A
EFFECTIVITY: ALL

4. SUPPORT OF THE AILERON AUTOPILOT SERVO - REMOVAL

A. General

- (1) This procedure gives the instructions to remove the support of the aileron autopilot servo of the Automatic Flight-Control System.

B. References

REFERENCE	DESIGNATION
AMM TASK 22-11-03-000-801-A/400	AILERON AUTOPILOT SERVO - REMOVAL
IPC 27-11-00	AILERON PRIMARY MECHANICAL CONTROL

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
123	123BL	Below the cockpit floor

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expendable Parts

ITEM	IPC REFERENCE (VENDOR REFERENCE)	QTY
Locking clips	IPC 27-11-00	4

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Below the cockpit floor

I. Preparation

SUBTASK 841-003-A

- (1) Remove the aileron autopilot servo ([AMM TASK 22-11-03-000-801-A/400](#)).

J. Removal ([Figure 402](#))

SUBTASK 020-003-A

- (1) Remove locking clips (4) and (6) from the turnbuckle (3) and (5) and discard them.
- (2) Loosen the turnbuckles (3) and (5) to disconnect the control cables (2) and (7).




-
- (3) Remove the bolts (8) and washers (9) (4 positions) that attach the support (1) of the aileron autopilot servo to the support (10) at the fuselage structure.
 - (4) Remove the support (1).

EFFECTIVITY: ALL

Support of the Aileron Autopilot Servo - Removal/Installation

Figure 402



EM145AMM220022B.DGN

TASK 22-11-03-400-802-A

EFFECTIVITY: ALL

5. SUPPORT OF THE AILERON AUTOPILOT SERVO - INSTALLATION

A. General

- (1) This procedure gives the instructions to install the support of the aileron autopilot servo of the Automatic Flight-Control System.

B. References

REFERENCE	DESIGNATION
AMM TASK 22-11-03-400-801-A/400	AILERON AUTOPILOT SERVO - INSTALLATION
AMM TASK 27-11-01-700-802-A/500	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
123	123BL	Below the cockpit floor

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Below the cockpit floor

I. Installation (Figure 402)

SUBTASK 420-003-A

- (1) Put the support (1) of the aileron autopilot servo on the support (10) at the fuselage structure.
- (2) Install the bolts (8) and washers (9) (4 positions) to attach the support (1) of the aileron autopilot servo to the support (10) at the fuselage structure.
- (3) Connect the control cables (2) and (7) through the turnbuckles (3) and (5).

J. Follow-on

SUBTASK 842-003-A

- (1) Install the aileron autopilot servo ([AMM TASK 22-11-03-400-801-A/400](#)).

-
- (2) Apply tension to the control cables (AMM TASK 27-11-01-700-802-A/500).

