

## APU AIR INTAKE DUCT - REMOVAL/INSTALLATION

*EFFECTIVITY: ALL*

1. General

- A. This section gives the procedures to remove/install the APU air intake duct.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
49-16-01-000-801-A	APU AIR INTAKE DUCT - REMOVAL	ALL
49-16-01-400-801-A	APU AIR INTAKE DUCT - INSTALLATION	ALL

TASK 49-16-01-000-801-A

EFFECTIVITY: ALL

## 2. APU AIR INTAKE DUCT - REMOVAL

### A. General

- (1) Obey these instructions to remove the APU air intake duct.

### B. References

REFERENCE	DESIGNATION
AMM MPP 49-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 49-11-00-000-801-A/400	APU COWLING - REMOVAL
AMM TASK 49-15-00-000-801-A/400	APU COWLING - REMOVAL
AMM TASK 49-16-03-000-801-A/400	APU AIR-INLET COVER ASSEMBLY - REMOVAL

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
313		APU cowling

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the work area	1

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	APU

### I. Preparation

SUBTASK 841-002-A

**WARNING: BEFORE YOU DO THE TASK OBEY THE SAFETY PRECAUTIONS GIVEN IN ( AMM MPP 49-00-00/200) TO PREVENT INJURY TO THE PERSONS AND DAMAGE TO THE MATERIAL.**

- (1) On the circuit breaker panel, open the APU FUEL SOV circuit breaker and attach DO-NOT-CLOSE tag to it.

- (2) On the left power control and distribution box, open the APU GEN START circuit breaker and attach DO-NOT-CLOSE tag to it.
- (3) Remove the APU cowling ( [AMM TASK 49-11-00-000-801-A/400](#) or [AMM TASK 49-15-00-000-801-A/400](#)), as applicable.

J. Removal ([Figure 401](#))


*SUBTASK 020-002-A*

- (1) Remove the intake duct as follow:
  - (a) Remove the screws (1).
  - (b) Remove the screen (2), gasket (3), and air intake duct (4).
  - (c) Discard the gasket (3).
- (2) For aircraft with APU cowling 145-54858 series, the air intake duct will be removed during the removal of the air inlet cover assembly ( [AMM TASK 49-16-03-000-801-A/400](#)).

EFFECTIVITY: ALL

APU Air Intake Duct - Removal/Installation

Figure 401



1 POST-MOD SB 145-49-0014

145AMM490026.MCE B

TASK 49-16-01-400-801-A  
EFFECTIVITY: ALL

### 3. APU AIR INTAKE DUCT - INSTALLATION

#### A. General

(1) Obey these instructions to install the APU air intake duct.

#### B. References

REFERENCE	DESIGNATION
AMM TASK 49-11-00-400-801-A/400	APU COWLING - INSTALLATION
AMM TASK 49-15-00-400-801-A/400	APU COWLING - INSTALLATION
AMM TASK 49-16-03-400-801-A/400	APU AIR-INLET COVER ASSEMBLY - INSTALLATION
IPC 53-32-00	REAR II

#### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
313		APU cowling

#### D. Tools and Equipment

Not Applicable

#### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the work area	1

#### F. Consumable Materials

Not Applicable

#### G. Expendable Parts

ITEM	IPC REFERENCE (VENDOR REFERENCE)	QTY
Gasket	IPC 53-32-00	2

#### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	APU

#### I. Installation (Figure 401)

##### SUBTASK 420-002-A

(1) Install the air intake duct (4), gasket (3), and screen (2) with screws (1). Tighten the screws (1).

- (2) For aircraft with APU cowling 145-54858 series, the air intake duct will be installed during the installation of the air inlet cover assembly ( [AMM TASK 49-16-03-400-801-A/400](#)).

J. Follow-on

*SUBTASK 842-002-A*

- (1) Install the APU cowling ( [AMM TASK 49-11-00-400-801-A/400](#) or [AMM TASK 49-15-00-400-801-A/400](#)), as applicable.
- (2) On the circuit breaker panel, remove the DO-NOT-CLOSE tag and close the APU FUEL SOV circuit breaker.
- (3) On the left power control distribution box, remove the DO-NOT-CLOSE tag and close the APU GEN START circuit breaker.