

AC STATIC INVERTER - ADJUSTMENT/TEST

EFFECTIVITY: FOR AIRCRAFT WITH AC STATIC INVERTER INSTALLED

1. General

- A. This section gives the procedures to do the operational test of the AC static inverter fan.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
24-20-01-700-801-A	AC STATIC INVERTER FAN - OPERATIONAL TEST	FOR AIRCRAFT WITH AC STATIC INVERTER INSTALLED

TASK 24-20-01-700-801-A

EFFECTIVITY: FOR AIRCRAFT WITH AC STATIC INVERTER INSTALLED

2. AC STATIC INVERTER FAN - OPERATIONAL TEST

A. General

(1) The function of this test is to make sure that the AC static inverter fan operates correctly.

B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
AMM SDS 24-20-00/1	
AMM TASK 20-40-01-860-801-A/200	ENERGIZATION OF THE AIRCRAFT WITH AN EXTERNAL POWER SOURCE
AMM TASK 29-10-00-860-802-A/200	HYDRAULIC SYSTEM - PRESSURIZATION WITH EMDP
AMM TASK 32-00-02-910-801-A/200	SAFETY PIN OF THE NLG DOORS SOLENOID VALVE - INSTALLATION AND REMOVAL
S.B.145-32-0036	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
113	113AZ	Nose-landing-gear compartment

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Nose-landing-gear compartment
1	Does the task	Cockpit

I. Preparation

SUBTASK 841-002-A

(1) On aircraft PRE-MOD [S.B.145-32-0036](#), make sure that the pressure in hydraulic system 1 is fully released ([AMM TASK 29-10-00-860-802-A/200](#)).

- (2) On aircraft POST-MOD [S.B.145-32-0036](#), install the safety pin of the NLG door solenoid valve ([AMM TASK 32-00-02-910-801-A/200](#)).
- (3) Open access panel113AZ (AMM MPP 06-41-01/100).
- (4) Energize the aircraft with the External DC-Power Supply ([AMM TASK 20-40-01-860-801-A/200](#)).

J. Test Procedure ([Figure 501](#))

SUBTASK 710-002-A

- (1) Do the task as follows:
 - (a) Make sure that the AC PWR pushbutton, on the electrical panel, on the overhead panel, is set at AUTO.
 - (b) (For aircraft with P/N PC-251-123F or SPC-10(Y)) Go near the AC static inverter ([AMM SDS 24-20-00/1](#)).

Result:

 - 1 Listen for the operation sound of the AC static inverter fan.
 - (c) Set the AC PWR pushbutton to OFF.

Result:

 - 1 On the AC PWR pushbutton, the striped bar comes on.
 - 2 The EICAS display shows the 115 V AC BUS OFF, WINDSHEAR INOP, and GPWS INOP caution messages.
 - 3 The master CAUTION lights flash.
 - (d) Push a master CAUTION light.

Result:

 - 1 The master CAUTION lights go off.
 - (e) (For aircraft with P/N PC-251-123F or SPC-10(Y)) Go near the AC static inverter.

Result:

 - 1 The AC static inverter fan stops.
 - (f) Set the AC PWR pushbutton to AUTO.

Result:

 - 1 On the AC PWR pushbutton, the striped bar goes off.
 - 2 On the EICAS display, the 115 V AC BUS OFF, WINDSHEAR INOP, and GPWS INOP caution messages go out of view.
 - (g) (For aircraft with P/N PC-251-123F or SPC-10(Y)) Go near the AC static inverter.

Result:

 - 1 Listen for the operation sound of the AC static inverter fan.

K. Follow-on

SUBTASK 842-002-A



- (1) Deenergize the aircraft ([AMM TASK 20-40-01-860-801-A/200](#)).
- (2) Close access panel113AZ (AMM MPP 06-41-01/100).

- (3) On aircraft POST-MOD [S.B.145-32-0036](#), remove the safety pin of the NLG door solenoid valve ([AMM TASK 32-00-02-910-801-A/200](#)).


EFFECTIVITY: FOR AIRCRAFT WITH AC STATIC INVERTER INSTALLED

AC Static-Inverter-Fan Operational Test

Figure 501




DET. B
MASTER CAUTION
LIGHT



DET. A
ELECTRICAL PANEL

AC PWR
PUSHBUTTON



DET. C
EICAS DISPLAY

145AMM240019.MCE A

