

## OIL STORAGE SYSTEM - INSPECTION/CHECK

*EFFECTIVITY: AIRCRAFT WITH APU T-62T-40C14*

### 1. General

- A. This section gives the procedures to do the check of the APU oil level through the oil level sight glass.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
49-96-00-200-801-A ◆	OIL-LEVEL SIGHT GLASS - INSPECTION	AIRCRAFT WITH APU T-62T-40C14

TASK 49-96-00-200-801-A

EFFECTIVITY: AIRCRAFT WITH APU T-62T-40C14

## 2. OIL-LEVEL SIGHT GLASS - INSPECTION

### A. General

- (1) The sight glass is installed near the filler port on the left lower side of the reduction drive assembly.

### B. References

REFERENCE	DESIGNATION
AMM MPP 06-42-00/100	-
<a href="#">AMM TASK 12-12-02-600-801-A/300</a>	AUXILIARY-POWER-UNIT FILLING

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
313	313CL	APU Cowling

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Ladder	To get access to the APU work area	1

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	APU work area

### I. Preparation

SUBTASK 841-002-A

**WARNING: MAKE SURE THE APU CONTROL MASTER SWITCH IS IN THE “OFF” POSITION TO PREVENT AN APU ACCIDENTAL OPERATION.**

- (1) On the circuit breaker panel, open these circuit breakers and attach DO-NOT-CLOSE tags to them:

– APU FUEL SOV.

- (2) On the left power control and distribution box, open the APU GEN START circuit breaker and attach DO-NOT-CLOSE tag to it.
- (3) Put the ladder in position and open the APU access panel 313CL (AMM MPP 06-42-00/100).

J. Check Oil Level and Service Oil System as required ([Figure 601](#))

*SUBTASK 210-002-A*

- (1) Do a visual check of the APU oil level through the oil level sight glass. Add lubricating oil as required ( [AMM TASK 12-12-02-600-801-A/300](#)).

K. Follow-on


*SUBTASK 842-002-A*

- (1) Close the APU access panel 313CL (AMM MPP 06-42-00/100) and remove the ladder.
- (2) Remove the DO-NOT-CLOSE tags and close these circuit breakers.
  - APU FUEL SOV.
- (3) On the left power control and distribution box, remove the DO-NOT-CLOSE tag and close the APU GEN START circuit breaker.

EFFECTIVITY: AIRCRAFT WITH APU T-62T-40C14

Oil-Level Sight Glass - Component Location

Figure 601



145AMM490260.MCE