

**SIDE-HINGED MAIN-DOOR RUBBER TRIM SEAL - MAINTENANCE PRACTICES**

*EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR*

1. General

- A. This section gives the procedure to replace the rubber trim seal of the main door.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
52-18-04-960-801-A ◆	RUBBER TRIM SEAL OF THE MAIN DOOR - REPLACEMENT	AIRCRAFT WITH SIDE-HINGED MAIN DOOR

**TASK 52-18-04-960-801-A**

**EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR**

**2. RUBBER TRIM SEAL OF THE MAIN DOOR - REPLACEMENT**

**A. General**

(1) This task gives the procedure to replace the rubber trim seal of the main door.

**B. References**

REFERENCE	DESIGNATION
<a href="#">AMM TASK 52-18-04-000-801-A/400</a>	SIDE-HINGED MAIN-DOOR RUBBER TRIM SEAL - REMOVAL
<a href="#">AMM TASK 52-18-04-400-801-A/400</a>	SIDE-HINGED MAIN-DOOR RUBBER TRIM SEAL - INSTALLATION

**C. Zones and Accesses**

Not Applicable

**D. Tools and Equipment**

Not Applicable

**E. Auxiliary Items**

Not Applicable

**F. Consumable Materials**

Not Applicable

**G. Expandable Parts**

Not Applicable

**H. Persons Recommended**

QTY	FUNCTION	PLACE
1	Does the task	Main door

**I. Replacement of the Rubber Trim Seal of the Main Door**

**SUBTASK 960-002-A**

(1) Remove the rubber trim seal ([AMM TASK 52-18-04-000-801-A/400](#)).

(2) Discard the rubber trim seal.

(3) Install a new rubber trim seal ([AMM TASK 52-18-04-400-801-A/400](#)).