

## LAVATORY OXYGEN BOX - INSPECTION/CHECK

*EFFECTIVITY: ALL*

1. General

- A. This section gives the procedures for the inspection/check of the lavatory oxygen box.
- B. The lavatory oxygen box is located in the lavatory ceiling panel. The lavatory is located in the passenger cabin of the aircraft.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
35-20-07-200-801-A	LAVATORY OXYGEN BOX - INSPECTION	ALL

TASK 35-20-07-200-801-A  
EFFECTIVITY: ALL

## 2. LAVATORY OXYGEN BOX - INSPECTION

### A. General

(1) The function of this inspection is to make sure that the oxygen module is in good condition.

### B. References

REFERENCE	DESIGNATION
<a href="#">AMM TASK 35-20-06-200-801-A/600</a>	OXYGEN MODULE - INSPECTION

### C. Zones and Accesses

Not Applicable

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Performs the task	Passenger cabin

### I. Inspection - Lavatory Oxygen Box

#### SUBTASK 220-002-A

NOTE: To do the inspection of the oxygen module, have a direct source of strong light.

(1) Examine the oxygen module box in the lavatory ( [AMM TASK 35-20-06-200-801-A/600](#) ).