

**CENTER FUSELAGE III - WING STUB MIDDLE SECTION - EXTERNAL - INSPECTION/CHECK**

*EFFECTIVITY: EMB-145LR/LU/MR/MP/MK AND EMB-135LR/KE/KL MODELS*

1. General

- A. This section gives the procedures to do the visual inspection of center fuselage III - wing stub middle section for general condition.
- B. Related Zone: 157.
- C. Zone Boundaries: STA Y = -230.0 thru STA Y = 230.0.
- D. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
05-30-22-200-801-A	CENTER FUSELAGE III - WING STUB MIDDLE SECTION - EXTERNAL GENER- AL VISUAL INSPECTION	EMB-145LR/LU/MR/MP/ MK AND EMB-135LR/KE/KL MODELS

TASK 05-30-22-200-801-A

EFFECTIVITY: EMB-145LR/LU/MR/MP/MK AND EMB-135LR/KE/KL MODELS

## 2. CENTER FUSELAGE III - WING STUB MIDDLE SECTION - EXTERNAL GENERAL VISUAL INSPECTION

### A. General

- (1) This task gives instructions to do the external general visual inspection (GVI) of center fuselage III, at zone 157, within a touching distance of the items examined.
- (2) The function of the external general visual inspection (GVI) is to find damage, failure, or irregular conditions that can be easily seen.

### B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
<a href="#">AMM MPP 28-00-00/200</a>	- MAINTENANCE PRACTICES
<a href="#">AMM TASK 12-11-01-600-802-A/300</a>	FUEL-TANK PRESSURE DEFUELING - SERVICING
AMM TASK 28-41-00-200-801-A/600	-
AMM TASK 53-01-02-000-801-A/400	-
AMM TASK 53-01-02-000-802-A/400	-
AMM TASK 53-01-02-400-801-A/400	-
AMM TASK 53-01-02-400-802-A/400	-

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
192	192AL	Wing-to-fuselage fairing
192	192BR	Wing-to-fuselage fairing
251	251CF	Passenger cabin floor
251	251DF	Passenger cabin floor
251	251EF	Passenger cabin floor
251	251FF	Passenger cabin floor
251	251JF	Passenger cabin floor
251	251KF	Passenger cabin floor
252	252BF	Passenger cabin floor
252	252CF	Passenger cabin floor

### D. Tools and Equipment

ITEM	DESCRIPTION	PURPOSE	QTY
Standard	Flashlight	To make the inspection of the area easier	

### E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Center fuselage III - wing-stub middle section

I. Preparation (Figure 601)

SUBTASK 841-008-B

**WARNING:** BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN **AMM MPP 28-00-00/200** TO PREVENT INJURY TO PERSONS AND DAMAGE TO THE MATERIAL.

- (1) Make sure that the aircraft is defueled ( **AMM TASK 12-11-01-600-802-A/300**).
- (2) Use table 601 to remove passenger-cabin floor panels as applicable to your aircraft (AMM TASK 53-01-02-000-801-A/400) or (AMM TASK 53-01-02-000-802-A/400) (Figure 601).

Table 601 - PASSENGER-CABIN FLOOR PANELS

AIRCRAFT	PANELS
EMB-145	251CF, 251DF, 252BF, 252CF, 251FF and 251EF
EMB-135	251JF, 251KF, 251DF, 252BF, 252CF, 251FF and 251EF

- (3) Open access panels 192AL and 192BR (AMM MPP 06-41-01/100).

J. External General Visual Inspection (Figure 602)

SUBTASK 212-008-B

- (1) Examine the wing stub structure for loose rivets, nicks, cracks, dents, distortion, erosion, and corrosion (Figure 602).

K. Follow-on

SUBTASK 842-008-B


- (1) Do an inspection on the fuel quantity indication harness (AMM TASK 28-41-00-200-801-A/600).

**NOTE:** The inspection of fuel quantity indication harness is a part of Critical Design Configuration Control Limitations (CDCCL) in the Airworthiness Limitations of the Aircraft Maintenance Program.

- (2) Use table 601 to install passenger-cabin floor panels as applicable to your aircraft (AMM TASK 53-01-02-400-801-A/400) or (AMM TASK 53-01-02-400-802-A/400).

- 
- (3) Close access panels 192AL and 193BR (AMM MPP 06-41-01/100).

EFFECTIVITY: EMB-145LR/LU/MR/MP/MK AND EMB-135LR/KE/KL MODELS  
Center Fuselage III - Wing-Stub Middle Section - Passenger Cabin Floor Panels  
Figure 601




**1** APPLICABLE TO EMB-145 (ALL) MODELS

**2** APPLICABLE TO EMB-135 (ALL) MODELS

145AMM050156.MCE

EFFECTIVITY: EMB-145LR/LU/MR/MP/MK AND EMB-135LR/KE/KL MODELS  
Center Fuselage III - Wing-Stub Middle Section - External General Visual Inspection  
Figure 602



EXTERNALLY INSPECT TO WING STUB STRUCTURE.

145AMM050180.MCE