

BAGGAGE-COMPARTMENT FIRE EXTINGUISHER PRESSURE SWITCH - REMOVAL/INSTALLATION

EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT

1. General

- A. This section gives the procedures to remove and install the pressure switch of the baggage-compartment fire-extinguisher bottles.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
26-23-03-000-801-A	PRESSURE SWITCH OF THE BAGGAGE-COMPARTMENT FIRE-EXTINGUISHER BOTTLES- REMOVAL	CLASS-C BAGGAGE COMPARTMENT
26-23-03-400-801-A	PRESSURE SWITCH OF THE BAGGAGE-COMPARTMENT FIRE-EXTINGUISHER BOTTLES- INSTALLATION	CLASS-C BAGGAGE COMPARTMENT

TASK 26-23-03-000-801-A

EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT

2. PRESSURE SWITCH OF THE BAGGAGE-COMPARTMENT FIRE-EXTINGUISHER BOTTLES-REMOVAL

A. General

- (1) For this procedure, it is necessary to remove the fire extinguisher bottles from the aircraft.
- (2) To do this task, refer to the instructions in the Pacific Scientific CMM ATA 26-23-46 (for high-rate bottle) and Pacific Scientific CMM ATA 26-23-47 (for metering bottle).

B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
AMM TASK 26-23-01-000-801-A/400	BAGGAGE FIRE EXTINGUISHER BOTTLES - REMOVAL
Pacific Scientific CMM ATA 26-23-46	-
Pacific Scientific CMM ATA 26-23-47	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
272	272DR	Electronic compartment

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Ladder	To get access to the electronic compartment	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Electronic compartment

I. Preparation

SUBTASK 841-002-A

- (1) On the circuit breaker panel, open the BAGGAGE FIRE EXTG circuit breaker and attach a DO-NOT-CLOSE tag to it.
- (2) Put the ladder in the work area.
- (3) Open access door 272DR (AMM MPP 06-41-01/100) to get access to the electronic compartment.
- (4) Remove the baggage-compartment fire-extinguisher bottles ([AMM TASK 26-23-01-000-801-A/400](#)).

J. Removal

SUBTASK 020-002-A

- (1) Remove the pressure switch of the baggage-compartment fire-extinguisher bottles. Refer to the last revision of Pacific Scientific CMM ATA 26-23-46 (for high-rate bottle) and Pacific Scientific CMM ATA 26-23-47 (for metering bottle).

TASK 26-23-03-400-801-A

EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT

3. PRESSURE SWITCH OF THE BAGGAGE-COMPARTMENT FIRE-EXTINGUISHER BOTTLES-INSTALLATION

A. General

- (1) To do this task, refer to the instructions in the Pacific Scientific CMM ATA 26-23-46 (for high-rate bottle) and Pacific Scientific CMM ATA 26-23-47 (for metering bottle).

B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
AMM TASK 26-23-01-400-801-A/400	BAGGAGE FIRE EXTINGUISHER BOTTLES - INSTALLATION
Pacific Scientific CMM ATA 26-23-46	-
Pacific Scientific CMM ATA 26-23-47	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
272	272DR	Electronic compartment

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Ladder	To get access to the electronic compartment	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Electronic compartment

I. Installation

SUBTASK 420-002-A

WARNING: MAKE SURE THAT THE "BAGGAGE FIRE EXTG" CIRCUIT BREAKER IS OPEN AND SAFETIED.

- (1) Install the pressure switch of the baggage-compartment fire-extinguisher bottles. Refer to the last revision of Pacific Scientific CMM ATA 26-23-46 (for high-rate bottle) and Pacific Scientific CMM ATA 26-23-47 (for metering bottle).

J. Follow-on

SUBTASK 842-002-A

- (1) Install the baggage-compartment fire-extinguishing bottles ([AMM TASK 26-23-01-400-801-A/400](#)).
- (2) Close access door 272DR (AMM MPP 06-41-01/100).
- (3) On the circuit breaker panel, close the BAGGAGE FIRE EXTG circuit breaker and remove the DO-NOT-CLOSE tag from it.
- (4) Remove the ladder from the work area.

