

TRANSMITTER BATTERY - MAINTENANCE PRACTICES

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to replace the battery installed in the Emergency Locator Transmitter (ELT).
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
25-61-04-900-801-A ♦	ELT BATTERY - REPLACEMENT	ALL

TASK 25-61-04-900-801-A

EFFECTIVITY: ALL

2. ELT BATTERY - REPLACEMENT

A. General

(1) This task gives the procedures to replace the ELT battery.

B. References

REFERENCE	DESIGNATION
AMM TASK 25-61-01-000-801-A/400	EMERGENCY LOCATOR TRANSMITTER (ELT 110-4) - REMOVAL
AMM TASK 25-61-01-000-802-A/400	EMERGENCY LOCATOR TRANSMITTER (ELT SA-TORI) - REMOVAL
AMM TASK 25-61-01-000-803-A/400	EMERGENCY LOCATOR TRANSMITTER (ELT C406-2) - REMOVAL
AMM TASK 25-61-01-400-801-A/400	EMERGENCY LOCATOR TRANSMITTER (ELT 110-4) - INSTALLATION
AMM TASK 25-61-01-400-802-A/400	EMERGENCY LOCATOR TRANSMITTER (ELT SA-TORI) - INSTALLATION
AMM TASK 25-61-01-400-803-A/400	EMERGENCY LOCATOR TRANSMITTER (ELT C406-2) - INSTALLATION
ARTEX CMM 570-1015	-
ARTEX CMM 570-5000	-
CMM ELT96A 25 60 000 000 / ELT97A 25 60 000 000	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
262		Center fuselage IV, on the right side

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	ELT unit

I. Preparation

SUBTASK 841-002-A

(1) Remove the ELT:

- On aircraft with ELT ARTEX 110-4, refer to [AMM TASK 25-61-01-000-801-A/400](#).
- On aircraft with ELT SATORI, refer to [AMM TASK 25-61-01-000-802-A/400](#).
- On aircraft with ELT ARTEX C406-2, refer to [AMM TASK 25-61-01-000-803-A/400](#).

J. Replace ELT Battery

SUBTASK 960-002-A

(1) Replace the battery:

- On aircraft with ELT ARTEX 110-4, refer to the latest revision of ARTEX CMM 570-1015.
- On aircraft with ELT SATORI, refer to the latest revision of CMM ELT96A 25 60 000 000 / ELT97A 25 60 000 000.
- On aircraft with ELT ARTEX C406-2, refer to the latest revision of ARTEX CMM 570-5000.

K. Follow-on

SUBTASK 842-002-A

(1) Install the ELT:

- On aircraft with ELT ARTEX 110-4, refer to [AMM TASK 25-61-01-400-801-A/400](#).
- On aircraft with ELT SATORI, refer to [AMM TASK 25-61-01-400-802-A/400](#).
- On aircraft with ELT ARTEX C406-2, refer to [AMM TASK 25-61-01-400-803-A/400](#).

