

## HORIZONTAL-STABILIZER ACTUATOR - INSPECTION/CHECK

*EFFECTIVITY: ALL*

### 1. General

- A. This section gives the procedures to do a check of the horizontal-stabilizer actuator for no-back operation and dual load path integrity.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
27-40-02-200-801-A ◆	HORIZONTAL STABILIZER ACTUATOR INTEGRITY AND ATTACHMENTS - DE- TAILED VISUAL INSPECTION	ALL

TASK 27-40-02-200-801-A

EFFECTIVITY: ALL

## 2. HORIZONTAL STABILIZER ACTUATOR INTEGRITY AND ATTACHMENTS - DETAILED VISUAL INSPECTION

### A. General

- (1) This task gives the procedures to do a check of the horizontal-stabilizer actuator for no-back operation and dual load path integrity.
- (2) [Figure 601](#) shows the location of the no-back test pinion on the horizontal stabilizer actuator.

### B. References

REFERENCE	DESIGNATION
AMM MPP 06-42-00/100	-
<a href="#">AMM TASK 20-40-01-860-801-A/200</a>	ENERGIZATION OF THE AIRCRAFT WITH AN EXTERNAL POWER SOURCE
<a href="#">AMM TASK 27-40-02-000-801-A/400</a>	HORIZONTAL STABILIZER ACTUATOR - REMOVAL
<a href="#">AMM TASK 27-40-02-400-801-A/400</a>	HORIZONTAL STABILIZER ACTUATOR - INSTALLATION
<a href="#">AMM TASK 27-40-02-600-801-A/300</a>	HORIZONTAL-STABILIZER ACTUATOR - GEAR OIL FILLING
IPC 27-43-00	HORIZONTAL STABILIZER HARNESS

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
324	324EL	Vertical stabilizer
324	324FR	Vertical stabilizer

### D. Tools and Equipment

ITEM	DESCRIPTION	PURPOSE	QTY
<a href="#">GSE 036</a>	Hydraulic Platform	To get access to the horizontal stabilizer	
<a href="#">GSE 044</a>	Headset ramp	For communications	
Commercially available	Torque wrench	To apply torques	
Commercially available	Stopwatch	To measure the time	

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

SPECIFICATION (BRAND)	DESCRIPTION	QTY
MS20995C20	Lockwire	AR

G. Expendable Parts

ITEM	IPC REFERENCE (VENDOR REFERENCE)	QTY
Cotter pin	IPC 27-43-00	2

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Cockpit
1	Does the task	Horizontal stabilizer

I. Preparation

**SUBTASK 841-002-A**

- (1) Make sure that the aircraft is safe for maintenance.
- (2) Do not do other tasks on the elevator and rudder.
- (3) Remove access panels 324EL and 324FR (AMM MPP 06-42-00/100).
- (4) Energize the aircraft with the External DC Power Supply ( [AMM TASK 20-40-01-860-801-A/200](#)).

J. Inspect (Detailed Inspection) Horizontal Stabilizer Actuator Integrity and Attachments ([Figure 601](#))

**SUBTASK 220-002-A**

- (1) Do a visual inspection on the actuator, attachment pins, and brackets for structural integrity. Make sure that there are not cracks in the actuator, gear box housings, and in the main-housing redundant upper and lower brackets. Refer to [Figure 601](#).
- (2) Remove the retaining screw and the red lever from the no-back test pinion installed on the actuator left side. Refer to [Figure 601](#).
- (3) Remove the right side upper pin that attaches the actuator to the horizontal stabilizer surface upper bracket. Refer to [AMM TASK 27-40-02-000-801-A/400](#).
- (4) Do the procedure below to examine the left attachment of the actuator to the horizontal stabilizer.
  - (a) With your hands, pull down and push up the horizontal-stabilizer leading edge, to apply a load to the actuator. Make sure that the horizontal stabilizer does not move.
  - (b) On the pilot control yoke, set the trim switch to the UP position, to move the horizontal-stabilizer leading edge down.
    - After the horizontal-stabilizer leading edge moves down to the commanded position, apply a load to push it up (opposite load to the actuator movement), with your hands. Make sure that the horizontal stabilizer does not move.

- (c) On the pilot control yoke, set the trim switch to the DOWN position, to move the horizontal-stabilizer leading edge up.
    - After the horizontal-stabilizer leading edge moves up to the commanded position, apply a load to pull it down (opposite load to the actuator movement), with your hands. Make sure that the horizontal stabilizer does not move.
  - (d) On the control pedestal, set the BACKUP trim switch to the UP position, to move the horizontal-stabilizer leading edge down.
    - After the horizontal-stabilizer leading edge moves down to the commanded position, apply a load to push it up (opposite load to the actuator movement), with your hands. Make sure that the horizontal stabilizer does not move.
  - (e) On the control pedestal, set the BACKUP trim switch to the DOWN position, to move the horizontal-stabilizer leading edge up.
    - After the horizontal-stabilizer leading edge moves up to the commanded position, apply a load to pull it down (opposite load to the actuator movement), with your hands. Make sure that the horizontal stabilizer does not move.
- (5) Do step 4 again, and then go to step 6.
- (6) Install the right side upper pin that attaches the actuator to the horizontal stabilizer surface upper bracket. Refer to [AMM TASK 27-40-02-400-801-A/400](#).
- (7) Remove the left side upper pin which attaches the actuator to the horizontal stabilizer surface upper bracket. Refer to [AMM TASK 27-40-02-000-801-A/400](#).
- (8) Do the procedure below to examine the right attachment of the actuator to the horizontal stabilizer.
- (a) With your hands, pull down and push up the horizontal-stabilizer leading edge to apply a load to the actuator. Make sure that the horizontal stabilizer does not move.
  - (b) On the pilot control yoke, set the trim switch to the UP position, to move the horizontal-stabilizer leading edge down.
    - After the horizontal-stabilizer leading edge moves down to the commanded position, apply a load to push it up (opposite load to the actuator movement), with your hands. Make sure that the horizontal stabilizer does not move.
  - (c) On the pilot control yoke, set the trim switch to the DOWN position, to move the horizontal-stabilizer leading edge up.
    - After the horizontal-stabilizer leading edge moves up to the commanded position, apply a load to pull it down (opposite load to the actuator movement), with your hands. Make sure that the horizontal stabilizer does not move.

- (d) On the control pedestal, set the BACKUP trim switch to the UP position, to move the horizontal-stabilizer leading edge down.
  - After the horizontal-stabilizer leading edge moves down to the commanded position, apply a load to push it up (opposite load to the actuator movement), with your hands. Make sure that the horizontal stabilizer does not move.
- (e) On the control pedestal, set the BACKUP trim switch to the DOWN position, to move the horizontal-stabilizer leading edge up.
  - After the horizontal-stabilizer leading edge moves up to the commanded position, apply a load to pull it down (opposite load to the actuator movement), with your hands. Make sure that the horizontal stabilizer does not move.
- (9) Do step 8 again, and then go to step 10.
- (10) Install the left side upper pin that attaches the actuator to the horizontal stabilizer surface upper bracket. Refer to [AMM TASK 27-40-02-400-801-A/400](#).
- (11) On the pilot control yoke, set the trim switch to the DOWN position for 2 to 3 seconds. This is to move the horizontal-stabilizer leading edge up and extend the horizontal stabilizer actuator.
  - After you extend the horizontal stabilizer actuator, apply clockwise and counterclockwise torques of 4 lb.in to the no-back pinion.
  - The no-back pinion can possibly turn counterclockwise, but it must always lock in the clockwise direction.
- (12) Do step 11 five times.
- (13) On the pilot control yoke, set the trim switch to the UP position for 2 to 3 seconds. This is to move the horizontal-stabilizer leading edge down and retract the horizontal stabilizer actuator.
  - After you retract the horizontal stabilizer actuator, apply clockwise and counterclockwise torques of 4 lb.in to the no-back pinion.
  - The no-back pinion can possibly turn clockwise, but it must always lock in the counterclockwise direction.
- (14) Do step 13 five times.
- (15) Install the retaining screw and red lever to the no-back test pinion. Apply a torque of 0.79 to 1.02 N.m (7 to 9 lb.in) to the retaining screw and safety it. Refer to [Figure 601](#).
- (16) Refill the Horizontal Stabilizer Actuator and do a check for external leakage. Refer to [AMM TASK 27-40-02-600-801-A/300](#).

K. Follow-on

*SUBTASK 842-002-A*


- (1) Install access panels 324EL and 324FR (AMM MPP 06-42-00/100).

- (2) De-energize the aircraft ( [AMM TASK 20-40-01-860-801-A/200](#) ).

EFFECTIVITY: ALL

Horizontal Stabilizer Actuator - Inspection

Figure 601 - Sheet 1




145AMM270070.MCE C

EFFECTIVITY: ALL

Horizontal Stabilizer Actuator - Inspection

Figure 601 - Sheet 2



1 TORQUE: 0.72-1.02 N.m (7-9 lb.in)

145AMM270297.MCE B