

## FLOTATION VEST - MAINTENANCE PRACTICES

*EFFECTIVITY: ALL*

### 1. General

- A. This section refers you to the publication necessary to put the flotation vest back to a serviceable condition.
- B. The crew flotation vest is installed on the back of the LH/RH cockpit crew seats, in the structure of the forward flight attendant seat, below the inboard seat of the last row of double passenger-seats, and in the RH aft console.
- C. Optionally, the passenger flotation vest is installed in a pouch below each passenger seat.
- D. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
25-60-02-900-801-A ◆	FLOTATION VEST - RESTORE	ALL

TASK 25-60-02-900-801-A

EFFECTIVITY: ALL

## 2. FLOTATION VEST - RESTORE

### A. General

- (1) The function of this inspection is to find degradation and violation of the packaging of the flotation vest.

### B. References

REFERENCE	DESIGNATION
CMM Air Cruisers 25-64-02	-
CMM C&D ZODIAC 63600-501	-
CMM Hoover Industries 2000-105Y	-
CMM Hoover Industries 3505-101CW	-
CMM Hoover Industries 3505-101W	-
CMM Hoover Industries 3505-111CW	-
CMM Nordisk 35-21-02	-
CMM RFD Beaufort Limited MK20SV	-
CMM RFD Beaufort Limited MK22SV	-
CMM RFD Beaufort Limited MK3	-

### C. Zones and Accesses

Not Applicable

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	On the back of the LH/RH cockpit crew seats, in the structure of the forward flight attendant seat, below the inboard seat of the last row of double passenger-seats, in the RH aft console, and in a pouch under each passenger seat

I. Restore Flotation Vest

*SUBTASK 900-006-A*

- (1) Remove the flotation vest from the pouch.
- (2) Do the inspection of the flotation vest as follows:
  - (a) Inspect the flotation vest for violation of its packaging.

NOTE: Use the procedures described on the servicing and maintenance section of the latest revision of the CMM according to the list below, to put the flotation vest back to a serviceable condition:

- CMM Hoover Industries 3505-101CW.
- CMM Hoover Industries 3505-101W.
- CMM Hoover Industries 3505-111CW.
- CMM Hoover Industries 2000-105Y.
- CMM RFD Beaufort Limited MK3.
- CMM RFD Beaufort Limited MK20SV.
- CMM RFD Beaufort Limited MK22SV.
- CMM C&D ZODIAC 63600-501.
- CMM Nordisk 35-21-02.
- CMM Air Cruisers 25-64-02.

- (3) Put the flotation vest back into the pouch.

