

APU FIRE EXTINGUISHER BOTTLE PRESSURE SWITCH - ADJUSTMENT/TEST

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to do the check of the pressure switch of the APU fire extinguishing bottle.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
26-22-02-700-801-A ♦	PRESSURE GAUGE AND SWITCH OF APU FIRE EXTINGUISHING BOTTLE - FUNCTIONAL CHECK	ALL

TASK 26-22-02-700-801-A

EFFECTIVITY: ALL

2. PRESSURE GAUGE AND SWITCH OF APU FIRE EXTINGUISHING BOTTLE - FUNCTIONAL CHECK

A. General

- (1) To do this check, it is necessary to remove the fire extinguishing bottle from the aircraft.
- (2) To do the task, refer to the instructions in Pacific Scientific CMM 26-20-202.

B. References

REFERENCE	DESIGNATION
AMM MPP 06-42-00/100	-
AMM MPP 49-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 26-22-01-000-801-A/400	APU FIRE-EXTINGUISHER BOTTLE - REMOVAL
AMM TASK 26-22-01-400-801-A/400	APU FIRE-EXTINGUISHER BOTTLE - INSTALLATION
Pacific Scientific CMM 26-20-202	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
312	312AR	Tail cone compartment

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Ladder	To get access to the tail cone compartment	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Tail cone compartment

I. Preparation

SUBTASK 841-002-A

WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN [AMM MPP 49-00-00/200](#) TO PREVENT INJURY TO PERSONS AND DAMAGE TO MATERIAL.

- (1) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them:
 - APU FIRE EXTG.
 - APU CONTROL.
- (2) Install the ladder in the work area.
- (3) Open access panel 312AR (AMM MPP 06-42-00/100) to get access to the tail cone compartment.
- (4) Remove the APU fire extinguishing bottle ([AMM TASK 26-22-01-000-801-A/400](#)).

J. Functionally Check APU Fire Extinguishing Bottle Pressure Switch

SUBTASK 720-002-A

- (1) Do a functional check of the pressure gauge and switch of the APU fire extinguishing bottle. Refer to the last revision of Pacific Scientific CMM 26-20-202.

K. Follow-on

SUBTASK 842-002-A

- (1) Install the APU fire extinguishing bottle ([AMM TASK 26-22-01-400-801-A/400](#)).
- (2) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them:
 - APU FIRE EXTG.
 - APU CONTROL.
- (3) On the EICAS display make sure that the message APU EXTBTL INOP is not shown.
- (4) Close access panel 312AR (AMM MPP 06-42-00/100).
- (5) Remove the ladder.

