

INTERPHONE CONTROL UNIT (ICU) - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to remove and install the interphone control unit.
- B. The interphone control unit is installed on the overhead panel.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
23-31-02-000-801-A	INTERPHONE CONTROL UNIT - REMOVAL	AIRCRAFT WITH INTERPHONE CONTROL UNIT INSTALLED
23-31-02-400-801-A	INTERPHONE CONTROL UNIT - INSTALLATION	AIRCRAFT WITH INTERPHONE CONTROL UNIT INSTALLED

TASK 23-31-02-000-801-A

EFFECTIVITY: AIRCRAFT WITH INTERPHONE CONTROL UNIT INSTALLED

2. INTERPHONE CONTROL UNIT - REMOVAL

A. General

- (1) The procedures for the removal of the interphone control unit is given in the Control Panel Typical Removal ([AMM TASK 20-13-10-000-801-A/400](#)).

B. References

REFERENCE	DESIGNATION
AMM TASK 20-13-10-000-801-A/400	CONTROL PANELS - REMOVAL (TYPICAL)

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

Not Applicable

TASK 23-31-02-400-801-A

EFFECTIVITY: AIRCRAFT WITH INTERPHONE CONTROL UNIT INSTALLED

3. INTERPHONE CONTROL UNIT - INSTALLATION

A. General

- (1) The procedures for the installation of the interphone control unit is given in the Control Panel Typical Installation ([AMM TASK 20-13-10-400-801-A/400](#)).

B. References

REFERENCE	DESIGNATION
AMM TASK 20-13-10-400-801-A/400	CONTROL PANELS - INSTALLATION (TYPICAL)

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

Not Applicable

