

## MAIN-DOOR COURTESY LIGHT - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

### 1. General

- A. This section gives the procedures to remove and install the main-door courtesy-light lamp and the main-door courtesy-light assembly.
- B. The main-door courtesy light is installed on the main-door ceiling panel and helps to light the stairs, entry area, aisle toward the cockpit, and the passenger cabin.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
33-26-04-000-801-A	MAIN-DOOR COURTESY-LIGHT LAMP - REMOVAL	ALL
33-26-04-400-801-A	MAIN-DOOR COURTESY-LIGHT LAMP - INSTALLATION	ALL
33-26-04-000-802-A	MAIN-DOOR COURTESY-LIGHT ASSEMBLY - REMOVAL	ALL
33-26-04-400-802-A	MAIN-DOOR COURTESY-LIGHT ASSEMBLY - INSTALLATION	ALL

TASK 33-26-04-000-801-A

*EFFECTIVITY: ALL*

## 2. MAIN-DOOR COURTESY-LIGHT LAMP - REMOVAL

### A. General

(1) This task gives the procedures to remove the main-door courtesy-light lamp.

### B. Zones and Accesses

<i>ZONE</i>	<i>PANEL/DOOR</i>	<i>LOCATION</i>
233	233ALC	Passenger cabin (main-door ceiling panel)

### C. Tools and Equipment

Not Applicable

### D. Auxiliary Items

Not Applicable

### E. Consumable Materials

Not Applicable

### F. Expandable Parts

Not Applicable

### G. Persons Recommended

<i>QTY</i>	<i>FUNCTION</i>	<i>PLACE</i>
1	Does the task	Passenger cabin (main-door ceiling panel)

### H. Preparation

*SUBTASK 841-002-A*

- (1) Make sure that courtesy light switch, on the entrance panel, is in the OFF position and attach a DO-NOT-TURN-ON tag to it.

### I. Removal [\(Figure 401\)](#)


*SUBTASK 020-002-A*

- (1) Carefully pull the lens (2) to remove it.
- (2) Remove the courtesy lamp (3) from the light housing assembly (1).

EFFECTIVITY: ALL

Main-Door Courtesy-Light Lamp - Removal/Installation

Figure 401



145AMM330180.MCE A

TASK 33-26-04-400-801-A

EFFECTIVITY: ALL

### 3. MAIN-DOOR COURTESY-LIGHT LAMP - INSTALLATION

#### A. General

(1) This task gives the procedures to install the main-door courtesy-light lamp.

#### B. References

REFERENCE	DESIGNATION
<a href="#">AMM TASK 33-26-00-700-801-A/500</a>	COURTESY/STAIR LIGHTS - OPERATIONAL TEST

#### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
233	233ALC	Passenger cabin (main-door ceiling panel)

#### D. Tools and Equipment

Not Applicable

#### E. Auxiliary Items

Not Applicable

#### F. Consumable Materials

Not Applicable

#### G. Expandable Parts

Not Applicable

#### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin (main-door ceiling panel)

#### I. Installation (Figure 401)

##### SUBTASK 420-002-A

(1) Install the courtesy lamp (3) in the light housing assembly (1).

(2) Carefully install the lens (2).

#### J. Follow-on

##### SUBTASK 842-002-A

(1) Remove the DO-NOT-TURN-ON tag from the courtesy light switch.

(2) Do the Courtesy/Stair lights test ( [AMM TASK 33-26-00-700-801-A/500](#) ).

TASK 33-26-04-000-802-A

EFFECTIVITY: ALL

#### 4. MAIN-DOOR COURTESY-LIGHT ASSEMBLY - REMOVAL

##### A. General

(1) This task gives the procedures to remove the main-door courtesy-light assembly.

##### B. References

REFERENCE	DESIGNATION
AMM TASK 25-22-04-000-801-A/400	-
AMM TASK 25-22-04-000-802-A/400	-

##### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
233	233ALC	Passenger cabin (main-door ceiling panel)

##### D. Tools and Equipment

Not Applicable

##### E. Auxiliary Items

Not Applicable

##### F. Consumable Materials

Not Applicable

##### G. Expandable Parts

Not Applicable

##### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin (main-door ceiling panel)

##### I. Preparation

###### *SUBTASK 841-003-A*

- (1) Make sure that courtesy light switch, on the entrance panel, is in the OFF position and attach a DO-NOT-TURN-ON tag to it.
- (2) Remove the main-door ceiling panel. Refer to (AMM TASK 25-22-04-000-801-A/400) or (AMM TASK 25-22-04-000-802-A/400), as applicable.

##### J. Removal [\(Figure 402\)](#)

###### *SUBTASK 020-003-A*

- (1) Carefully pull the lens (8) to remove it.




- (2) Remove the screws (1) and washers (2) that attach the light housing assembly (3) to the main-door ceiling panel.
- (3) Remove the screws (6) and washers (4) and (7) that attach the terminal lugs (5) to the light housing assembly (3).
- (4) Remove the light housing assembly (3).

EFFECTIVITY: ALL

Main-Door Courtesy-Light Assembly - Removal/Installation

Figure 402



145AMM330173.MCE A

TASK 33-26-04-400-802-A

EFFECTIVITY: ALL

5. MAIN-DOOR COURTESY-LIGHT ASSEMBLY - INSTALLATION

A. General

(1) This task gives the procedures to install the main-door courtesy-light assembly.

B. References

REFERENCE	DESIGNATION
AMM TASK 25-22-04-400-801-A/400	-
AMM TASK 25-22-04-400-802-A/400	-
<a href="#">AMM TASK 33-26-00-700-801-A/500</a>	COURTESY/STAIR LIGHTS - OPERATIONAL TEST

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
233	233ALC	Passenger cabin (main-door ceiling panel)

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin (main-door ceiling panel)

I. Installation (Figure 402)

**SUBTASK 420-003-A**

- (1) Install the screws (6) and washers (4) and (7) to attach the terminal lugs (5) to the light housing assembly (3).
- (2) Put the light housing assembly (3) in its installation position.
- (3) Install the screws (1) and washers (2) that attach the light housing assembly (3) to the main-door ceiling panel.
- (4) Carefully install the lens (8).



J. Follow-on

*SUBTASK 842-003-A*

- (1) Install the main-door ceiling panel. Refer to (AMM TASK 25-22-04-400-801-A/400) or (AMM TASK 25-22-04-400-802-A/400), as applicable.
- (2) Remove the DO-NOT-TURN-ON tag from the courtesy light switch.
- (3) Do the Courtesy/Stair lights test ( [AMM TASK 33-26-00-700-801-A/500](#)).

