

CENTER FUSELAGE IV - PASSENGER CABIN LH/RH SIDES - EXTERNAL - INSPECTION/CHECK

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to do the visual inspection of center fuselage IV - passenger cabin LH/RH sides for general condition.
- B. Related Zones: 261/262.
- C. (Applicable to EMB-145 (ALL) models) Zone Boundaries: STA X = 17727.0 thru STA X = 20793.0.
(Applicable to EMB-135 (ALL) models) Zone Boundaries: STA X = 15721.0 thru STA X = 17253.0.
- D. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
05-20-35-200-801-A ♦	CENTER FUSELAGE IV - PASSENGER CABIN LH/RH SIDES - EXTERNAL GENERAL VISUAL INSPECTION	ALL

TASK 05-20-35-200-801-A

EFFECTIVITY: ALL

2. CENTER FUSELAGE IV - PASSENGER CABIN LH/RH SIDES - EXTERNAL GENERAL VISUAL INSPECTION

A. General

- (1) This task gives instructions to do SMRD Zonal Task 53-Z261-213-001-A00.
- (2) You must do the external general visual inspection (GVI) of center fuselage IV, at zones 261/262, within a touching distance of the items examined.
- (3) The function of the external general visual inspection (GVI) is to find damage, failure, or irregular conditions that can be easily seen.

B. References

<i>REFERENCE</i>	<i>DESIGNATION</i>
AMM TASK 12-22-00-600-801-A/300	LIGHT DIRT - SERVICING
AMM TASK 12-22-00-600-802-A/300	HEAVY DIRT - SERVICING
AMM TASK 56-20-01-100-801-A/700	PASSENGER CABIN WINDOWS - CLEANING
AMM TASK 56-20-01-200-801-A/600	PASSENGER CABIN WINDOWS - INSPECTION/ CHECK

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

<i>ITEM</i>	<i>DESCRIPTION</i>	<i>PURPOSE</i>	<i>QTY</i>
Standard	Ladder	To get access to the inspection area	

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

<i>QTY</i>	<i>FUNCTION</i>	<i>PLACE</i>
1	Does the task	Center fuselage IV - passenger cabin LH/RH sides

I. Preparation

SUBTASK 841-002-A

- (1) Put the ladder in position.

- (2) If necessary, clean the inspection area ([AMM TASK 56-20-01-100-801-A/700](#)) and ([AMM TASK 12-22-00-600-801-A/300](#)) or ([AMM TASK 12-22-00-600-802-A/300](#)) as applicable.

J. External General Visual Inspection ([Figure 601](#)) ([Figure 602](#))

SUBTASK 212-002-A

- (1) Examine the fuselage zone for loose rivets, skin deformation, sealant condition, nicks, cracks, dents, scratches, gouges, creases, dents, erosion, corrosion, painting bad condition, and deteriorated protective treatment.
- (2) Examine the fuselage skin panel at stringer and frames/bulkheads for loose rivets, nicks, cracks, dents, erosion, corrosion, and deteriorated protective treatment.
- (3) Examine the fuselage skin longitudinal and circumferential splice for loose rivets, nicks, cracks, dents, erosion, corrosion, and deteriorated protective treatment.
- (4) Examine the passenger cabin windows frames for loose rivets, nicks, cracks, dents, erosion, corrosion, and deteriorated protective treatment.
- (5) Examine the passenger cabin windows for delamination and crazing ([AMM TASK 56-20-01-200-801-A/600](#)).
- (6) Examine the passenger cabin windows aerodynamic sealing for scratched, scored, cracked and ruptured ([Figure 602](#)).

K. Follow-on


SUBTASK 842-002-A

- (1) Remove the ladder.

EFFECTIVITY: ALL

Center Fuselage IV - Passenger Cabin LH/RH Sides - External General Visual Inspection

Figure 601




EXTERNALLY INSPECT THE FUSELAGE SKIN PANEL AT STRINGER, FRAMES/BULKHEADS, SKIN LONGITUDINAL AND CIRCUMFERENTIAL SPLICES.

145AMM050083.MCE A

EFFECTIVITY: ALL

External Inspection of Passenger Cabin Windows Aerodynamic Sealing

Figure 602



1 EXTERNALLY INSPECT THE AERODYNAMIC SEALING.

EM145AMM050078B.DGN

