
COCKPIT ESCAPE HATCHES EXITS - SERVICING

EFFECTIVITY: ALL

1. General

- A. The procedure for the lubrication of the Cockpit Escape Hatches is given in [AMM TASK 56-11-01-600-801-A/300](#).

