

## APU AIR INLET DUCT - INSPECTION/CHECK

EFFECTIVITY: ALL

### 1. General

- A. This section gives the procedures to do an inspection on the APU air-inlet duct.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
49-16-02-200-801-A	APU AIR-INLET DUCT - INSPECTION	FOR AIRCRAFT WITH- OUT EXHAUST SI- LENCER
49-16-02-200-802-A	AIR-INLET SEAL/AIR-INLET DUCT INTER- FACE CLEARANCE/MISALIGNMENT- IN- SPECTION	FOR AIRCRAFT WITH APU T-62T-40C14 AND APU COWLING WITH SILENCER

TASK 49-16-02-200-801-A

*EFFECTIVITY: FOR AIRCRAFT WITHOUT EXHAUST SILENCER*

## 2. APU AIR-INLET DUCT - INSPECTION

### A. General

- (1) Obey these instructions to do an inspection on the APU air-inlet assembly.

### B. References

REFERENCE	DESIGNATION
AMM TASK 49-11-00-000-801-A/400	APU COWLING - REMOVAL
AMM TASK 49-11-00-400-801-A/400	APU COWLING - INSTALLATION
AMM TASK 49-15-00-000-801-A/400	APU COWLING - REMOVAL
AMM TASK 49-15-00-400-801-A/400	APU COWLING - INSTALLATION

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
313	313CL	APU

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Ladder	To get access to the APU work area	1

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	APU work area

### I. Preparation

*SUBTASK 841-002-A*

- (1) On the circuit breaker panel, open the APU FUEL SOV circuit breaker and attach a DO-NOT-CLOSE tag to it.
- (2) On the left power control and distribution box, open the APU GEN START circuit breaker and attach a DO-NOT-CLOSE tag to it.

- (3) Put the workstand under the APU work area.
- (4) Remove the APU cowling ( [AMM TASK 49-11-00-000-801-A/400](#) or [AMM TASK 49-15-00-000-801-A/400](#)), as applicable.

J. Inspection of APU Air Inlet Assembly (Duct, Screen and Seal) ([Figure 601](#))

*SUBTASK 212-002-A*

- (1) Do a visual inspection on the duct, screen, and seal of the APU air intake installed at the APU cowling. Repair or replace the defective parts, as applicable.
- (2) Do a visual inspection on the duct and sealing surface of the APU air inlet installed at the APU. Repair or replace the defective parts, as applicable.

K. Follow-on


*SUBTASK 842-002-A*

- (1) Install the APU cowling ( [AMM TASK 49-11-00-400-801-A/400](#) or [AMM TASK 49-15-00-400-801-A/400](#)), as applicable.
- (2) Remove the DO-NOT-CLOSE tag and close the APU FUEL SOV circuit breaker.
- (3) On the left power control and distribution box, remove the DO-NOT-CLOSE tag and close the APU GEN START circuit breaker.
- (4) Remove the workstand from the APU work area.

EFFECTIVITY: FOR AIRCRAFT WITHOUT EXHAUST SILENCER

APU Air Inlet Duct - Inspection

Figure 601



EM145AMM490421A.DGN

TASK 49-16-02-200-802-A

EFFECTIVITY: FOR AIRCRAFT WITH APU T-62T-40C14 AND APU COWLING WITH SILENCER

3. AIR-INLET SEAL/AIR-INLET DUCT INTERFACE CLEARANCE/MISALIGNMENT- INSPECTION

A. General

- (1) Obey these instructions to do an inspection for clearance and/or misalignment on the air-inlet seal/air-inlet duct interface.

B. References

REFERENCE	DESIGNATION
AMM MPP 06-42-00/100	-
<a href="#">AMM TASK 49-16-04-000-801-A/400</a>	APU AIR-INLET SILENCER SEAL - REMOVAL
<a href="#">AMM TASK 49-16-04-400-801-A/400</a>	APU AIR-INLET SILENCER SEAL - INSTALLATION
<a href="#">AMM TASK 53-32-00-000-801-A/400</a>	TAIL CONE - REMOVAL
<a href="#">AMM TASK 53-32-00-400-801-A/400</a>	TAIL CONE - INSTALLATION
IPC 49-16-00	APU AIR INTAKE

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
313	313CL	APU

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Ladder	To get access to the APU work area	1

F. Consumable Materials

Not Applicable

G. Expendable Parts

ITEM	IPC REFERENCE (VENDOR REFERENCE)	QTY
Shim	IPC 49-16-00	1

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	APU work area

I. Preparation

SUBTASK 841-003-A

- (1) On the circuit breaker panel, open the APU FUEL SOV circuit breaker and attach a DO-NOT-CLOSE tag to it.
- (2) On the left power control and distribution box, open the APU GEN START circuit breaker and attach a DO-NOT-CLOSE tag to it.
- (3) Put the workstand under the APU work area.
- (4) Open access door 313CL (AMM MPP 06-42-00/100).
- (5) Remove the tail cone ( [AMM TASK 53-32-00-000-801-A/400](#)).

NOTE: For this procedure, the rudder must be out of its neutral position.

J. Air-Inlet Seal/Air-Inlet Duct Interface Clearance/Misalignment- Visual Inspection ([Figure 602](#)) ([Figure 603](#))

SUBTASK 212-003-A

- (1) Loosen the bolts that attach the APU starter-generator air outlet to the right side of the APU cowling.
- (2) Do a visual inspection from the APU cowling rear and from the opening of the APU starter-generator exhaust-duct air outlet. Make sure that there is no clearance and/or misalignment between the air inlet duct and the air inlet seal. Refer to DET. C of [Figure 602](#).
- (3) If you find a clearance, do these steps to remove it (see [Figure 602](#)):
  - (a) Remove the APU air-inlet silencer seal ( [AMM TASK 49-16-04-000-801-A/400](#)).
  - (b) Install one or more shims, as necessary, on the APU air-inlet duct and then install the APU air-inlet silencer seal back ( [AMM TASK 49-16-04-400-801-A/400](#)).
  - (c) Put the APU air inlet back to its initial configuration.
  - (d) Install the bolts that attach the APU starter-generator air outlet to the right side of the APU cowling.
- (4) If you find a misalignment, do these steps to remove it (see [Figure 603](#)):
  - (a) Loosen the fasteners (2) from the APU air-inlet duct (1).

CAUTION: DO NOT MOVE THE APU AIR-INLET DUCT BEFORE YOU LOOSEN THE FASTENERS AND DO NOT AXIALLY MOVE THE APU AIR-INLET DUCT. IF YOU DO NOT OBEY THESE PRECAUTIONS, DAMAGE TO THE APU AIR-INLET DUCT O-RINGS WILL OCCUR.

- (b) Hold the APU air-inlet duct and move it radially to align the air inlet duct with the air inlet seal.
- (c) Tighten the fasteners (2) back.

K. Follow-on


*SUBTASK 842-003-A*

- (1) Install the tail cone ( [AMM TASK 53-32-00-400-801-A/400](#)).
- (2) Close access door 313CL (AMM MPP 06-42-00/100).
- (3) Remove the DO-NOT-CLOSE tag and close the APU FUEL SOV circuit breaker.
- (4) On the left power control and distribution box, remove the DO-NOT-CLOSE tag and close the APU GEN START circuit breaker.
- (5) Remove the workstand from the APU work area.

EFFECTIVITY: FOR AIRCRAFT WITH APU T-62T-40C14 AND APU COWLING WITH SILENCER

Air-Inlet Seal/Air-Inlet Duct Interface Clearance - Visual Inspection

Figure 602




**1** VALID FOR AIRCRAFT WITH APU COWLING WITH SILENCER  
EXCEPT 145-54858-SERIES COWLING.

**2** VALID FOR AIRCRAFT WITH APU COWLING 145-54858 SERIES.

EM145AMM490317B.DGN

*EFFECTIVITY: FOR AIRCRAFT WITH APU T-62T-40C14 AND APU COWLING WITH SILENCER*  
Air-Inlet Seal/Air-Inlet Duct Interface Misalignment - Visual Inspection  
Figure 603



EM145AMM490142A.DGN

