

## FASTEN-SEAT-BELT SWITCH - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

### 1. General

- A. This section gives the procedures to remove and install the switch of the fasten-seat-belt switch.
- B. The switch of the fasten-seat-belt switch is installed in the cockpit, on the overhead panel.
- C. Obey the safety precautions below, when you work on the switch of the fasten-seat-belt switch.
  - Disconnect the electrical power.
  - Always use insulated tools when you work on or near electrical circuits.
- D. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

| TASK NUMBER        | DESCRIPTION                             | EFFECTIVITY |
|--------------------|---|-------------|
| 33-23-03-000-801-A | FASTEN-SEAT-BELT SWITCH - REMOV-AL      | ALL         |
| 33-23-03-400-801-A | FASTEN-SEAT-BELT SWITCH - INSTAL-LATION | ALL         |

TASK 33-23-03-000-801-A

EFFECTIVITY: ALL

## 2. FASTEN-SEAT-BELT SWITCH - REMOVAL

### A. General

(1) This procedure gives the instructions to remove the switch of the fasten-seat-belt switch.

### B. References

| REFERENCE                                       | DESIGNATION                                     |
|---|---|
| <a href="#">AMM TASK 20-13-03-000-801-A/400</a> | SWITCHES AND POTENTIOMETERS - REMOVAL (TYPICAL) |

### C. Zones and Accesses

Not Applicable

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

| QTY | FUNCTION      | PLACE   |
|-----|---------------|---------|
| 1   | Does the task | Cockpit |

### I. Preparation

*SUBTASK 841-002-A*

(1) On the Circuit Breaker Panel, open the PASS SIGNS circuit breaker and attach a DO-NOT-CLOSE tag to it.

### J. Removal ([Figure 401](#))



*SUBTASK 020-002-A*

(1) To remove the switch of the fasten-seat-belt switch, refer to the procedure Switches and Potentiometers - Removal ([AMM TASK 20-13-03-000-801-A/400](#)).

EFFECTIVITY: ALL

Fasten-Seat-Belt Switch - Location

Figure 401



DET. B

145AMM330117.MCE A

TASK 33-23-03-400-801-A

EFFECTIVITY: ALL

### 3. FASTEN-SEAT-BELT SWITCH - INSTALLATION

#### A. General

(1) This procedure gives the instructions to install the switch of the fasten seat belt sign.

#### B. References

| REFERENCE                                       | DESIGNATION  |
|---|--|
| <a href="#">AMM TASK 20-13-03-400-801-A/400</a> | SWITCHES AND POTENTIOMETERS - INSTALLATION (TYPICAL) |
| <a href="#">AMM TASK 33-23-00-700-801-A/500</a> | PASSENGER WARNING SIGNS - OPERATIONAL TEST           |

#### C. Zones and Accesses

Not Applicable

#### D. Tools and Equipment

Not Applicable

#### E. Auxiliary Items

Not Applicable

#### F. Consumable Materials

Not Applicable

#### G. Expandable Parts

Not Applicable

#### H. Persons Recommended

| QTY | FUNCTION      | PLACE   |
|-----|---------------|---------|
| 1   | Does the task | Cockpit |

#### I. Installation (Figure 401)

##### SUBTASK 420-002-A

(1) To install the switch of the fasten-seat-belt switch, refer to the procedure Switches and Potentiometers - Installation ([AMM TASK 20-13-03-400-801-A/400](#)).

#### J. Follow-on

##### SUBTASK 842-002-A

(1) On the Circuit Breaker Panel, close the PASS SIGNS circuit breaker and remove the DO-NOT-CLOSE tag from it.

(2) Do an operational check on the Passenger Warning Signs ( [AMM TASK 33-23-00-700-801-A/500](#)).