

FUELING/DEFUELING ADAPTER CAP - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to remove and install the fueling/defueling adapter cap.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

| TASK NUMBER | DESCRIPTION | EFFECTIVITY |
|--------------------|--|-------------|
| 28-23-21-000-801-A | FUELING/DEFUELING ADAPTER CAP - REMOVAL | ALL |
| 28-23-21-400-801-A | FUELING/DEFUELING ADAPTER CAP - INSTALLATION | ALL |

TASK 28-23-21-000-801-A

EFFECTIVITY: ALL

2. FUELING/DEFUELING ADAPTER CAP - REMOVAL

A. General

(1) This procedure gives the instructions to remove the fueling/defueling adapter cap.

B. References

| REFERENCE | DESIGNATION |
|--------------------------------------|-------------------------|
| AMM MPP 06-41-01/100 | - |
| AMM MPP 28-00-00/200 | - MAINTENANCE PRACTICES |

C. Zones and Accesses

| ZONE | PANEL/DOOR | LOCATION |
|------|------------|----------------------------------|
| 191 | 191BR | Forward wing-to-fuselage fairing |

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

| QTY | FUNCTION | PLACE |
|-----|---------------|----------------------------------|
| 1 | Does the task | Forward wing-to-fuselage fairing |

I. Preparation

SUBTASK 841-002-A

WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN [AMM MPP 28-00-00/200](#) TO PREVENT INJURY TO PERSONS AND DAMAGE TO THE MATERIAL.

(1) Open access panel 191BR (AMM MPP 06-41-01/100) to get access to the fueling/defueling adapter cap.

J. Removal ([Figure 401](#))

SUBTASK 020-002-A

(1) Push and turn the fueling/defueling adapter cap (3) counterclockwise to remove it.

(2) Push the clip (1) from the ring (4) to remove the cable (2).




-
- (3) Remove the fueling/defueling adapter cap (3).

EFFECTIVITY: ALL

Fueling/Defueling Adapter Cap - Removal/Installation

Figure 401



145AMM280927.MCE

TASK 28-23-21-400-801-A
EFFECTIVITY: ALL

3. FUELING/DEFUELING ADAPTER CAP - INSTALLATION

A. General

(1) This procedure gives the instructions to install the fueling/defueling adapter cap.

B. References

| REFERENCE | DESIGNATION |
|---------------------------------|-------------------------|
| AMM MPP 06-41-01/100 | - |
| AMM MPP 28-00-00/200 | - MAINTENANCE PRACTICES |
| AMM TASK 28-41-00-200-801-A/600 | - |

C. Zones and Accesses

| ZONE | PANEL/DOOR | LOCATION |
|------|------------|----------------------------------|
| 191 | 191BR | Forward wing-to-fuselage fairing |

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

| QTY | FUNCTION | PLACE |
|-----|---------------|----------------------------------|
| 1 | Does the task | Forward wing-to-fuselage fairing |

I. Installation (Figure 401)

SUBTASK 420-002-A

WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN AMM MPP 28-00-00/200 TO PREVENT INJURY TO PERSONS AND DAMAGE TO THE MATERIAL.

- (1) Put the fueling/defueling adapter cap (3) in position.
- (2) Install the clip (1) on the ring (4).
- (3) Push and turn the fueling/defueling adapter cap (3) clockwise to attach it.

J. Follow-on

SUBTASK 842-002-A

- (1) Do an inspection on the fuel quantity indication harness (AMM TASK 28-41-00-200-801-A/600).

NOTE: The inspection of fuel quantity indication harness is a part of Critical Design Configuration Control Limitations (CDCCL) in the Airworthiness Limitations of the Maintenance Review Board Report (MRB).

- (2) Close access panel 191BR (AMM MPP 06-41-01/100).