

BAGGAGE-DOOR ACTUATING AND LOCKING MECHANISM - ADJUSTMENT/TEST

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures for the operational test and adjustment of the baggage-door actuating and locking mechanism, gaps and steps.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
52-31-00-700-801-A ♦	BAGGAGE-DOOR ACTUATING AND LOCKING MECHANISM - OPERATIONAL TEST/ADJUSTMENT	ALL

TASK 52-31-00-700-801-A

EFFECTIVITY: ALL

2. BAGGAGE-DOOR ACTUATING AND LOCKING MECHANISM - OPERATIONAL TEST/ADJUSTMENT

A. General

- (1) This task gives the procedure to do the operational test and adjustment of the baggage-door actuating and locking mechanism, gaps and steps.

B. References

REFERENCE	DESIGNATION
AMM SDS 52-30-00/1	
AMM TASK 25-51-02-000-801-A/400	BAGGAGE DOOR LINING - REMOVAL
AMM TASK 25-51-02-400-801-A/400	BAGGAGE DOOR LINING - INSTALLATION
AMM TASK 52-30-01-000-801-A/400	BAGGAGE DOOR - REMOVAL
AMM TASK 52-30-01-400-801-A/400	BAGGAGE DOOR - INSTALLATION
AMM TASK 52-31-00-000-801-A/400	BAGGAGE-DOOR ACTUATING AND LOCKING MECHANISM - REMOVAL
AMM TASK 52-32-00-000-801-A/400	BAGGAGE-DOOR LIFTING AND LOWERING MECHANISM - REMOVAL
AMM TASK 52-32-00-400-801-A/400	BAGGAGE-DOOR LIFTING AND LOWERING MECHANISM - INSTALLATION
AMM TASK 52-76-01-820-801-A/500	BAGGAGE DOOR WARNING MICROSWITCHES - ADJUSTMENT

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
813		Baggage door

D. Tools and Equipment

ITEM	DESCRIPTION	PURPOSE	QTY
GSE 339	Baggage Door Eccentric Adjustment Wrench	To adjust the eccentric of the baggage door	
Commercially available	Workstand	To get access to the side-hinged main door	
Commercially available	Rig pin, 4.5 mm (0.18") in diameter and 97 mm (3.85") in length	Rigging of the mechanisms	
Commercially available	Cable Tensiometer	Adjust the tension in the cables	

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Flashlight	For lighting of the locks of the baggage door	1

F. Consumable Materials

SPECIFICATION (BRAND)	DESCRIPTION	QTY
MS20995C32	Lockwire	AR
MEP 09-060	Non-Chromate Corrosion Inhibiting Compound (CA-1000-NC)	AR

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	On the inner side of the baggage compartment
1	Helps the other technician	On the outside of the baggage compartment

I. Preparation

SUBTASK 841-002-A

- (1) Remove the baggage door lining to get access to the locking mechanism ([AMM TASK 25-51-02-000-801-A/400](#)).

WARNING: AFTER YOU DISCONNECT THE DOOR LIFTING AND LOWERING MECHANISM CABLE, THE DOOR WILL BE HEAVIER AND INJURIES TO PERSON CAN OCCUR.

- (2) Disconnect the door lifting and lowering mechanism cable, according to [AMM TASK 52-32-00-000-801-A/400](#).

J. Operational Test/Adjustment Procedures ([Figure 501](#)) ([Figure 502](#)) ([Figure 503](#)) ([Figure 504](#)) ([Figure 505](#)) ([Figure 506](#)) ([Figure 507](#)) ([Figure 508](#))

SUBTASK 710-002-A

- (1) Check and adjustment of the locks of the baggage door ([Figure 501](#), [Figure 502](#) and [Figure 503](#)).

NOTE: Do a check on the bushings, installed in the gear box and in the lever, for general conditions. If necessary, replace the bushings.

- (a) If necessary, remove the baggage door ([AMM TASK 52-30-01-000-801-A/400](#)).
- (b) Put the handle of the baggage door in the fully closed and locked position.

NOTE: The cable tension can be adjusted with the baggage door installed in the aircraft or not.

- (c) Apply a tension of 70 ± 5 lb to the cables of the actuating and locking mechanism of the baggage door, with the baggage door closed. (Refer to [Figure 508](#)).

NOTE: Cable diameter is 5/32 in (3.97 mm).

- (d) Pull the vent panel through the locking handle ([Figure 501](#)):

- 1 The vent panel stays closed by spring action.
- 2 The locks (1) ([Figure 502](#)) must be engaged with the recesses of the upper cranks (2) (forward and aft upper cranks). If not, adjust the cables as follows:
 - a Put the rig pin (1) ([Figure 503](#)) in the support and bellcrank holes (2). If it is not possible, cut the lockwires (5) of the rods (6), remove the cotter pin (10), nut (9), washers (8), and bolt (7) which attach the each rods and turn the rods until you can put the rig pin in the holes.
 - b Install the bolt, washers, nut, and a new cotter pin to attach each rods.
 - c Install the new lockwire if it was removed.
 - d Cut the clips (3) to release the cables.
 - e Turn the turnbuckles (4) to loosen the two cables of each lock.
 - f Make sure that the lock is engaged with the recess of the upper cranks (6) (forward and aft upper cranks).
 - g Turn the turnbuckle of the cable which permits the lock to start to move away from the recess of the upper crank.
 - h Turn the other turnbuckle until the lock lightly touches the recess of the upper crank.

WARNING: BE CAREFUL WHEN YOU USE CA-1000-NC BECAUSE IT IS TOXIC. USE SAFETY GOGGLES AND PROTECTIVE CLOTHING WHEN YOU HANDLE IT. DO NOT BREATHE ITS GASES AND WORK IN A WELL VENTILATED AREA.

- i Apply CA-1000-NC, during the connection of the turnbuckles, if they were disconnected ([AMM TASK 52-31-00-000-801-A/400](#)).
- j Remove the rig pin and put it in the lock hole to make sure that the lock is in the correct position.
- k If it is very difficult to remove the rig pin or if the locks are not engaged in the recesses of the upper cranks, adjust the cables directly.
- ! Make sure that the locks are engaged in the recesses of the upper cranks.

- m Look at the red mark on the microswitch actuation pin. If it is out of the correct values, away from the microswitch support, adjust the baggage door warning microswitches ([AMM TASK 52-76-01-820-801-A/500](#)).
- 3 Push the vent panel through the locking handle:
 - a The vent panel stays open by spring action.
- 4 If applicable, install the baggage door ([AMM TASK 52-30-01-400-801-A/400](#)).
- (e) Install the baggage door if it was removed from the fuselage ([AMM TASK 52-30-01-400-801-A/400](#)).
- (2) Check and adjustment of the step of the baggage door ([Figure 504](#) and [Figure 505](#)).
 - (a) Fully close and lock the baggage door ([AMM SDS 52-30-00/1](#)).
 - (b) From the outside of the aircraft, do a check of the step values between the door and the fuselage frame for each point ([Figure 504](#)).

Table 501

Check Points	Permitted Step	
	Minimum	Maximum
1 to 9	-3.0 mm (-0.12 in)	0.0 mm (0.00 in)
11 and 13	-3.0 mm (-0.12 in)	0.0 mm (0.00 in)
10, 12, and 14	Not Controlled	

- (c) If the step values are satisfactory and it does not take too much power to open and close the door, go to step (3). If the values are unsatisfactory, adjust the door step as follows ([Figure 505](#)):
 - 1 Remove the lockwire, the bolt, and the lock from the four door rollers (DET. B in [Figure 505](#)).
 - 2 From the inside of the aircraft, one technician operates GSE 339 (DET. C in [Figure 505](#)) while the other technician, outside the aircraft, does the check of the step values.

NOTE: Make sure that the step obeys the permitted values and the door is not hard to open or close.

 - 3 Go back to step (b).
- (3) Check and adjustment of the gap of the baggage door ([Figure 504](#), [Figure 506](#) and [Figure 507](#)).
 - (a) Fully close and lock the baggage door ([AMM SDS 52-30-00/1](#)).
 - (b) From the inside of the aircraft, measure the gap between the door guide and the fuselage ([Figure 507](#)).

NOTE: • Gap or interference permitted between the door guide and the fuselage is 1.0 mm (+0.0 mm; -0.5 mm) (Figure 507).

- If necessary, remove or add shims between the guide and the door (DET. D in Figure 506), as applicable, to get gap or interference between the door guide and the fuselage.

- (c) From the outside of the aircraft, do a check of the gap values between the door and the fuselage frame for each point (Figure 504).

Table 502

Check Points	Permitted Gap	
	Minimum	Maximum
1 to 8	1.0 mm (0.04 in)	5.0 mm (0.20 in)
9, 11, and 13	2.0 mm (0.08 in)	7.0 mm (0.28 in)
10, 12, and 14	1.0 mm (0.04 in)	6.0 mm (0.24 in)

- (d) If the gap obeys the permitted values, the adjustment is completed. If not, adjust the door gap as follows (Figure 506):

- 1 Remove the door to remove or add shims under the guides (AMM TASK 52-30-01-000-801-A/400).
- 2 For horizontal gap adjustments (Points 1 thru 8 in Figure 504), remove or add shims between the door and the door guides as applicable (DET. D in Figure 506).

NOTE: • If you add a shim on one side, you must remove the shim from the other side.

- Make sure, after the adjustment, that the gap or interference between the door guide and the fuselage is 1.0 mm (+0.0 mm; -0.5 mm) (Figure 507).

- 3 For vertical gap adjustments (Points 9 thru 14 in Figure 504), remove or add shims between the door and the door roller support as applicable (DET. B and DET. C in Figure 506).

NOTE: If you add a shim on the top, you must remove the shim from the bottom.

- 4 Install the door (AMM TASK 52-30-01-400-801-A/400).
- 5 Go back to step (c).

K. Follow-on


SUBTASK 842-002-A

- (1) Install the baggage door lining (AMM TASK 25-51-02-400-801-A/400).
- (2) Connect the cable of the door lifting and lowering mechanism, according to AMM TASK 52-32-00-400-801-A/400.

EFFECTIVITY: ALL


Baggage-Door Actuating and Locking Mechanism - Component Locations

Figure 501



145AMM520138.MCE C

EFFECTIVITY: ALL
Baggage-Door Upper Crank
Figure 502




145AMM520562.MCE

EFFECTIVITY: ALL



Baggage-Door Cables and Rods

Figure 503




145AMM520561.MCE

EFFECTIVITY: ALL
Baggage-Door Check Points
Figure 504




145AMM520447.MCE

EFFECTIVITY: ALL
Baggage-Door Step Adjustment
Figure 505



EFFECTIVITY: ALL
Baggage-Door Gap Adjustment
Figure 506




145AMM520448.MCE

EFFECTIVITY: ALL



Baggage-Door Gap Adjustment

Figure 507



EM145AMM520455A.DGN

EFFECTIVITY: ALL
Cable Tensiometer
Figure 508



1 TENSION: 70 ± 5 lb. (311 ± 22 N).

EM145AMM520633A.DGN