

## ATTENDANT CONTROL PANEL - REMOVAL/INSTALLATION

*EFFECTIVITY: ALL*

### 1. General

- A. This section gives the procedures to remove and install the attendant control panel.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
25-27-09-000-801-A	ATTENDANT CONTROL PANEL - REMOV- AL	ALL
25-27-09-400-801-A	ATTENDANT CONTROL PANEL - INSTAL- LATION	ALL

TASK 25-27-09-000-801-A

EFFECTIVITY: ALL

## 2. ATTENDANT CONTROL PANEL - REMOVAL

### A. General

(1) This task gives the procedures to remove the attendant control panel.

### B. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
231		Passenger cabin

### C. Tools and Equipment

Not Applicable

### D. Auxiliary Items

Not Applicable

### E. Consumable Materials

Not Applicable

### F. Expandable Parts

Not Applicable

### G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin

### H. Removal [\(Figure 401\)](#)


#### SUBTASK 020-002-A

- (1) On the overhead panel, make sure that the PASS CABIN rotary switch is not set to the ATTD position and attach a DO-NOT-SET-TO-ATTD-POSITION tag.
- (2) On the circuit breaker panel, open the EMERG LIGHT circuit breaker and attach a DO-NOT-CLOSE tag to it (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
- (3) Remove the screws (3) (4 positions).
- (4) Pull the attendant control panel (2) to get access to the electrical connector (1).
- (5) Disconnect the electrical connector (1).
- (6) Remove the attendant control panel (2).

EFFECTIVITY: ALL

Attendant Control Panel - Removal/Installation

Figure 401



145AMM330118.MCE B

TASK 25-27-09-400-801-A

EFFECTIVITY: ALL

### 3. ATTENDANT CONTROL PANEL - INSTALLATION

#### A. General

(1) This task gives the procedures to install the attendant control panel.

#### B. References

REFERENCE	DESIGNATION
AMM TASK 21-60-00-700-801-A/500	TEMPERATURE CONTROL SYSTEM - OPERATIONAL CHECK
AMM TASK 33-21-00-700-801-A/500	PASSENGER CABIN LIGHTS - OPERATIONAL TEST
AMM TASK 33-25-00-700-801-A/500	READING AND ATTENDANT CALL LIGHTS (1) - OPERATIONAL TEST
AMM TASK 33-50-00-700-801-A/500	EMERGENCY LIGHTS - OPERATIONAL CHECK

#### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
231		Passenger cabin

#### D. Tools and Equipment

Not Applicable

#### E. Auxiliary Items

Not Applicable

#### F. Consumable Materials

Not Applicable

#### G. Expandable Parts

Not Applicable

#### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin

#### I. Installation (Figure 401)

##### *SUBTASK 420-002-A*

- (1) Connect the electrical connector (1) to the attendant control panel (2).
- (2) Put the attendant control panel (2) on the windscreen assembly.
- (3) Attach the attendant control panel (2) to the windscreen assembly with the screws (3) (4 positions).

J. Follow-on

*SUBTASK 842-002-A*

- (1) On the overhead panel, remove the DO-NOT-SET-TO-ATTD-POSITION tag.
- (2) On the circuit breaker panel, close the EMERG circuit breaker and remove the DO-NOT-CLOSE tag from it (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
- (3) Do an operational test of the emergency lights ( [AMM TASK 33-50-00-700-801-A/500](#)).
- (4) Do an operational test of the attendant call and the passenger service units (PSU) ( [AMM TASK 33-25-00-700-801-A/500](#)).
- (5) Do an operational test of the cabin lights ( [AMM TASK 33-21-00-700-801-A/500](#)).
- (6) Do an operational test of the cabin temperature control ( [AMM TASK 21-60-00-700-801-A/500](#)).

