

## CONTROL MODULE ASSEMBLY - ADJUSTMENT/TEST

*EFFECTIVITY: ALL*

### 1. General

- A. This section gives the procedures to do the test of the control module assembly.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

<i>TASK NUMBER</i>	<i>DESCRIPTION</i>	<i>EFFECTIVITY</i>
33-21-01-700-801-A	CONTROL MODULE ASSEMBLY - OPERATIONAL TEST	ALL

TASK 33-21-01-700-801-A  
EFFECTIVITY: ALL

## 2. CONTROL MODULE ASSEMBLY - OPERATIONAL TEST

### A. General

- (1) This task gives the procedures to do the operational test of the control module assembly.
- (2) The control module assembly is a device that contains control circuits for the systems below:
  - (a) Cabin Lighting System;
  - (b) Emergency Lighting System;
  - (c) Main Door System;
  - (d) Passenger Address System.

### B. References

REFERENCE	DESIGNATION
<a href="#">AMM TASK 33-21-00-700-801-A/500</a>	PASSENGER CABIN LIGHTS - OPERATIONAL TEST
<a href="#">AMM TASK 33-25-00-700-801-A/500</a>	READING AND ATTENDANT CALL LIGHTS (1) - OPERATIONAL TEST
<a href="#">AMM TASK 33-50-00-700-801-A/500</a>	EMERGENCY LIGHTS - OPERATIONAL CHECK
<a href="#">AMM TASK 52-12-00-700-801-A/500</a>	MAIN-DOOR ALTERNATIVE OPENING SYSTEM - OPERATIONAL CHECK

### C. Zones and Accesses

Not Applicable

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin

### I. Test Procedure

#### SUBTASK 710-002-A

- (1) To do the test of the control module assembly, do the operational tests below:

- Passenger Cabin Lights - Operational Test ( [AMM TASK 33-21-00-700-801-A/500](#)).
- Reading and Attendant Call Lights - Operational Test ( [AMM TASK 33-25-00-700-801-A/500](#)).
- Emergency Lights - Operational Check ( [AMM TASK 33-50-00-700-801-A/500](#)).
- Main-Door Alternative Opening System - Operational Check ( [AMM TASK 52-12-00-700-801-A/500](#)).

