

CD PLAYER - REMOVAL/INSTALLATION

EFFECTIVITY: ACFT MODEL(S) EMB-145

1. General

- A. This section gives the procedures to remove and install the CD player.
- B. The CD player is installed in the forward galley, zone 232.
- C. To do these procedures, use AMM TASK 23-32-01-000-801-A/400 and AMM TASK 23-32-01-400-801-A/400 or AMM TASK 23-32-01-000-802-A/400 and AMM TASK 23-32-01-400-802-A/400 or AMM TASK 23-32-01-000-803-A/400 and AMM TASK 23-32-01-400-803-A/400, as applicable.
- D. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
23-32-01-000-801-A	CD PLAYER - REMOVAL	ACFT MODEL(S) EMB-145
23-32-01-400-801-A	CD PLAYER - INSTALLATION	ACFT MODEL(S) EMB-145
23-32-01-000-802-A	CD PLAYER - REMOVAL	ACFT MODEL(S) EMB-145
23-32-01-400-802-A	CD PLAYER - INSTALLATION	ACFT MODEL(S) EMB-145
23-32-01-000-803-A	CD PLAYER - REMOVAL	ACFT MODEL(S) EMB-145
23-32-01-400-803-A	CD PLAYER - INSTALLATION	ACFT MODEL(S) EMB-145

TASK 23-32-01-000-801-A

EFFECTIVITY: ACFT MODEL(S) EMB-145

2. CD PLAYER - REMOVAL

A. General

(1) This task gives the procedures for the removal of the CD player.

B. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
232		Forward galley

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Forward galley

H. Preparation [\(Figure 401\)](#)

SUBTASK 841-006-A

- (1) On the circuit breaker panel, open the circuit breakers listed below and attach a DO-NOT-CLOSE tag to them:
 - MUSIC (Location Tip: SHED DC BUS 1/SERVICE/MUSIC).
 - PA (Location Tip: ESSENTIAL DC BUS 2/COMM/PA).
- (2) Remove the screws (2) that attach the door (3) to the forward galley (1).
- (3) Remove the door (3).
- (4) Pull and hold the table lock (10).
- (5) Pull the table (7) and remove it from the forward galley (1).
- (6) Remove the shroud (8) to get access to the screw (17).

I. Removal ([Figure 401](#))


SUBTASK 020-006-A

- (1) Remove the screw (17) that attaches the CD player compartment (6) to the forward galley (1).
- (2) Open the door (12) to get access to the screw (13).
- (3) Remove the screw (13) that attaches the CD player compartment (6) to the forward galley (1).
- (4) Remove the screws (5) and washers (4).
- (5) Carefully pull the CD player compartment (6) to get access to the audio connector (15) and electrical connector (14).
- (6) Disconnect the audio connector (15) and the electrical connector (14).
- (7) Remove the screws (16) that attach the trim frame (11) to the CD player compartment (6).
- (8) Remove the trim frame (11).
- (9) Remove the CD player (9) from the CD player compartment (6).

EFFECTIVITY: ACFT MODEL(S) EMB-145

CD Player - Removal/Installation

Figure 401



145AMM230192.MCE A

TASK 23-32-01-400-801-A

EFFECTIVITY: ACFT MODEL(S) EMB-145

3. CD PLAYER - INSTALLATION

A. General

(1) This task gives the procedures for the installation of the CD player.

B. References

REFERENCE	DESIGNATION
AMM TASK 23-32-00-700-801-A/500	-
AMM TASK 23-32-00-700-804-A/500	-
AMM TASK 23-32-00-700-808-A/500	-
AMM TASK 23-32-00-700-809-A/500	-
AMM TASK 23-32-00-700-810-A/500	-
AMM TASK 23-32-00-700-811-A/500	-
AMM TASK 23-32-00-700-812-A/500	-
AMM TASK 23-32-00-700-813-A/500	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
232		Forward galley

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Forward galley

I. Installation (Figure 401)

SUBTASK 420-006-A

(1) Put the CD player (9) into the CD player compartment (6).

(2) Put the trim frame (11) in position.

- (3) Install the screws (16) that attach the trim frame (11) to the CD player compartment (6).
- (4) Connect the audio connector (15) and the electrical connector (14).
- (5) Carefully, put the CD player compartment (6) into the forward galley (1).
- (6) Install the screws (5) and washers (4) that attach the CD player compartment (6) to the forward galley (1).
- (7) Install the screw (13).
- (8) Close the door (12).
- (9) Install the screw (17).

J. Follow-on (Figure 401)

SUBTASK 842-006-A

- (1) On the circuit breaker panel, close the circuit breakers listed below and remove the DO-NOT-CLOSE tag from them:
 - MUSIC (Location Tip: SHED DC BUS 1/SERVICE/MUSIC).
 - PA (Location Tip: ESSENTIAL DC BUS 2/COMM/PA).
- (2) (Aircraft with CD player model DEH-245) Do the CD player model DEH-245 operational test (AMM TASK 23-32-00-700-801-A/500).
- (3) (Aircraft with CD player model DEH-1000) Do the CD player model DEH-1000 operational test (AMM TASK 23-32-00-700-804-A/500).
- (4) (Aircraft with CD player model DEH-1400) Do the CD player model DEH-1400 operational test (AMM TASK 23-32-00-700-808-A/500).
- (5) (Aircraft with CD player model DEH-1600) Do the CD player model DEH-1600 operational test (AMM TASK 23-32-00-700-809-A/500).
- (6) (Aircraft with CD player model DEH-1700) Do the CD player model DEH-1700 operational test (AMM TASK 23-32-00-700-810-A/500).
- (7) (Aircraft with CD player model DEH-1800) Do the CD player model DEH-1800 operational test (AMM TASK 23-32-00-700-811-A/500).
- (8) (Aircraft with CD player model DEH-1900) Do the CD player model DEH-1900 operational test (AMM TASK 23-32-00-700-812-A/500).
- (9) (Aircraft with CD player model DEH-1300) Do the CD player model DEH-1300 operational test (AMM TASK 23-32-00-700-813-A/500).
- (10) Put the shroud (8) in position.
- (11) Pull and hold the table lock (10).
- (12) Put the table (7) into the forward galley (1).

- (13) Put the door (3) in position in the forward galley (1).
- (14) Install the screws (2) that attach the door (3) to the forward galley (1).

TASK 23-32-01-000-802-A

EFFECTIVITY: ACFT MODEL(S) EMB-145

4. CD PLAYER - REMOVAL

A. General

(1) This task gives the procedures for the removal of the CD player.

B. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
232		Forward galley

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Forward galley

H. Preparation [\(Figure 402\)](#)

SUBTASK 841-007-A

(1) On the circuit breaker panel, open the circuit breakers listed below and attach a DO-NOT-CLOSE tag to them:

- MUSIC (Location Tip: SHED DC BUS 1/SERVICE/MUSIC).
- PA (Location Tip: ESSENTIAL DC BUS 2/COMM/PA).

I. Removal [\(Figure 402\)](#)

SUBTASK 020-007-A


- (1) Open the door (11) to get access to the screws (3) and washers (2).
- (2) Remove the screws (3) and washers (2) that attach the CD player compartment (5) to the forward galley (1).
- (3) Remove the screws (10) that attach the CD player compartment (5) to the forward galley (1).
- (4) Carefully pull the CD player compartment (5) to get access to the audio connector (9) and electrical connector (8).

- (5) Disconnect the audio connector (9) and the electrical connector (8).
- (6) Remove the screws (4) that attach the trim frame (6) to the CD player compartment (5).
- (7) Remove the trim frame (6).
- (8) Remove the CD player (7) from the CD player compartment (5).

EFFECTIVITY: ACFT MODEL(S) EMB-145

CD Player - Removal/Installation

Figure 402



145AMM230193.MCE B

TASK 23-32-01-400-802-A

EFFECTIVITY: ACFT MODEL(S) EMB-145

5. CD PLAYER - INSTALLATION

A. General

(1) This task gives the procedures for the installation of the CD player.

B. References

REFERENCE	DESIGNATION
AMM TASK 23-32-00-700-801-A/500	-
AMM TASK 23-32-00-700-804-A/500	-
AMM TASK 23-32-00-700-808-A/500	-
AMM TASK 23-32-00-700-809-A/500	-
AMM TASK 23-32-00-700-810-A/500	-
AMM TASK 23-32-00-700-811-A/500	-
AMM TASK 23-32-00-700-812-A/500	-
AMM TASK 23-32-00-700-813-A/500	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
232		Forward galley

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Forward galley

I. Installation (Figure 402)

SUBTASK 420-007-A

(1) Carefully, put the CD player (7) into the CD player compartment (5).

(2) Put the trim frame (6) in position.

- (3) Install the screws (4) that attach the trim frame (6) to the CD player compartment (5).
- (4) Connect the audio connector (9) and the electrical connector (8).
- (5) Carefully, put the CD player compartment (5) into the forward galley (1).
- (6) Install the screws (3) and washers (2) that attach the CD player compartment (5) to the forward galley (1).
- (7) Install the screws (10) that attach the CD player compartment (5) to the forward galley (1).

J. Follow-on (Figure 402)

SUBTASK 842-007-A

- (1) On the circuit breaker panel, close the circuit breakers listed below and remove the DO-NOT-CLOSE tag from them:
 - MUSIC (Location Tip: SHED DC BUS 1/SERVICE/MUSIC).
 - PA (Location Tip: ESSENTIAL DC BUS 2/COMM/PA).
- (2) (Aircraft with CD player model DEH-245) Do the CD player model DEH-245 operational test (AMM TASK 23-32-00-700-801-A/500).
- (3) (Aircraft with CD player model DEH-1000) Do the CD player model DEH-1000 operational test (AMM TASK 23-32-00-700-804-A/500).
- (4) (Aircraft with CD player model DEH-1400) Do the CD player model DEH-1400 operational test (AMM TASK 23-32-00-700-808-A/500).
- (5) (Aircraft with CD player model DEH-1600) Do the CD player model DEH-1600 operational test (AMM TASK 23-32-00-700-809-A/500).
- (6) (Aircraft with CD player model DEH-1700) Do the CD player model DEH-1700 operational test (AMM TASK 23-32-00-700-810-A/500).
- (7) (Aircraft with CD player model DEH-1800) Do the CD player model DEH-1800 operational test (AMM TASK 23-32-00-700-811-A/500).
- (8) (Aircraft with CD player model DEH-1900) Do the CD player model DEH-1900 operational test (AMM TASK 23-32-00-700-812-A/500).
- (9) (Aircraft with CD player model DEH-1300) Do the CD player model DEH-1300 operational test (AMM TASK 23-32-00-700-813-A/500).
- (10) Close the door (11).

TASK 23-32-01-000-803-A

EFFECTIVITY: ACFT MODEL(S) EMB-145

6. CD PLAYER - REMOVAL

A. General

(1) This task gives the procedures for the removal of the CD player.

B. References

REFERENCE	DESIGNATION
AMM TASK 26-14-02-000-801-A/400	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
232		Forward galley

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Forward galley

I. Preparation (Figure 401)

SUBTASK 841-008-A

- (1) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them:
 - MUSIC (Location Tip: SHED DC BUS 1/SERVICE/MUSIC).
 - PA (Location Tip: ESSENTIAL DC BUS 2/COMM/PA).
- (2) Remove the screw (5) and washer (6) that attach the support (4) to the forward galley (1).
- (3) Remove the support (4).
- (4) Carefully remove the shroud (14).
- (5) Open the door (16).


- (6) Pull the waste container (15) and remove it from the forward galley (1).
- (7) Open the door (18) to get access to the Smoke Detector Panel (7).
- (8) Remove the Smoke Detector Panel (7) (AMM TASK 26-14-02-000-801-A/400).
- (9) Remove the screws (2) that attach the magnetic catch (3) to the forward galley (1).
- (10) Remove the magnetic catch (3).

J. Removal (Figure 401)

SUBTASK 020-008-A

- (1) Remove the screws (17) that attach the CD player compartment (9) to the forward galley (1).
- (2) Carefully pull the CD player compartment (9) to get access to the audio connector (10) and electrical connector (11).
- (3) Disconnect the audio connector (10) and the electrical connector (11).
- (4) Remove the screws (8) that attach the trim frame (13) to the CD player compartment (9).
- (5) Remove the trim frame (13).
- (6) Remove the CD player (12) from the CD player compartment (9).

Figure 403



TASK 23-32-01-400-803-A

EFFECTIVITY: ACFT MODEL(S) EMB-145

7. CD PLAYER - INSTALLATION

A. General

(1) This task gives the procedures for the installation of the CD player.

B. References

REFERENCE	DESIGNATION
AMM TASK 23-32-00-700-802-A/500	-
AMM TASK 23-32-00-700-805-A/500	-
AMM TASK 23-32-00-700-808-A/500	-
AMM TASK 23-32-00-700-809-A/500	-
AMM TASK 23-32-00-700-810-A/500	-
AMM TASK 23-32-00-700-811-A/500	-
AMM TASK 23-32-00-700-812-A/500	-
AMM TASK 23-32-00-700-813-A/500	-
AMM TASK 26-14-02-400-801-A/400	-
TASK 23-32-01-700-802-A	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
232		Forward galley

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Forward galley

I. Installation (Figure 401)

SUBTASK 420-008-A

(1) Open the door (18).

- (2) Carefully, put the CD player (12) into the CD player compartment (9).
- (3) Put the trim frame (13) in position.
- (4) Install the screws (8) that attach the trim frame (13) to the CD player compartment (9).
- (5) Connect the audio connector (10) and the electrical connector (11).
- (6) Carefully, put the CD player compartment (9) into the forward galley (1).
- (7) Install the screws (17) that attach the CD player compartment (9) to the forward galley (1).

J. Follow-on (Figure 401)

SUBTASK 842-008-A

- (1) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them:
 - MUSIC (Location Tip: SHED DC BUS 1/SERVICE/MUSIC).
 - PA (Location Tip: ESSENTIAL DC BUS 2/COMM/PA).
- (2) Do the CD player operational test (TASK 23-32-01-700-802-A).
- (3) (Aircraft with CD player model DEH-245) Do the CD player model DEH-245 operational test (AMM TASK 23-32-00-700-802-A/500).
- (4) (Aircraft with CD player model DEH-1000) Do the CD player model DEH-1000 operational test (AMM TASK 23-32-00-700-805-A/500).
- (5) (Aircraft with CD player model DEH-1400) Do the CD player model DEH-1400 operational test (AMM TASK 23-32-00-700-808-A/500).
- (6) (Aircraft with CD player model DEH-1600) Do the CD player model DEH-1600 operational test (AMM TASK 23-32-00-700-809-A/500).
- (7) (Aircraft with CD player model DEH-1700) Do the CD player model DEH-1700 operational test (AMM TASK 23-32-00-700-810-A/500).
- (8) (Aircraft with CD player model DEH-1800) Do the CD player model DEH-1800 operational test (AMM TASK 23-32-00-700-811-A/500).
- (9) (Aircraft with CD player model DEH-1900) Do the CD player model DEH-1900 operational test (AMM TASK 23-32-00-700-812-A/500).
- (10) (Aircraft with CD player model DEH-1300) Do the CD player model DEH-1300 operational test (AMM TASK 23-32-00-700-813-A/500).
- (11) Put the magnetic catch (3) in position.
- (12) Install the screws (2).
- (13) Put the waste container (15) into the forward galley (1).
- (14) Close the door (16).



-
- (15) Put the shroud (14) in position.
 - (16) Put the support (4) in position.
 - (17) Install the screws (5) and washers (6) that attach the support (4) to the forward galley (1).
 - (18) Install the Smoke Detector Panel (7) (AMM TASK 26-14-02-400-801-A/400).
 - (19) Close the door (18).