

**CENTER FUSELAGE I - PASSENGER CABIN TOP - INTERNAL - INSPECTION/CHECK**

*EFFECTIVITY: ALL*

1. General

- A. This section gives the procedures to do the visual inspection of center fuselage I - passenger cabin top for general condition.
- B. Related Zones: 233/234.
- C. Zone Boundaries: STA X = 4154.5 thru STA X = 7131.0.
- D. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
05-20-20-200-801-A ♦	CENTER FUSELAGE I - PASSENGER CABIN TOP - INTERNAL GENERAL VISU- AL INSPECTION	ALL

TASK 05-20-20-200-801-A

*EFFECTIVITY: ALL*

## 2. CENTER FUSELAGE I - PASSENGER CABIN TOP - INTERNAL GENERAL VISUAL INSPECTION

### A. General

- (1) This task gives instructions to do SMRD Zonal Task 53-Z233-214-001-A00.
- (2) You must do the internal general visual inspection (GVI) of center fuselage I, at zones 233/234, within a touching distance of the items examined.
- (3) The function of the internal general visual inspection (GVI) is to find damage, failure, or irregular conditions that can be easily seen.

### B. References

<i>REFERENCE</i>	<i>DESIGNATION</i>
AMM TASK 12-23-00-600-801-A/300	-
AMM TASK 25-22-04-000-801-A/400	-
AMM TASK 25-22-04-000-802-A/400	-
AMM TASK 25-81-01-000-801-A/400	-
AMM TASK 25-81-01-000-802-A/400	-
AMM TASK 25-81-01-400-801-A/400	-
AMM TASK 25-81-01-400-802-A/400	-

### C. Zones and Accesses

<i>ZONE</i>	<i>PANEL/DOOR</i>	<i>LOCATION</i>
233	233ALC	Passenger cabin panel
233	233BLC	Passenger cabin panel
233	233CLC	Passenger cabin panel
234	234ARC	Passenger cabin panel

### D. Tools and Equipment

<i>ITEM</i>	<i>DESCRIPTION</i>	<i>PURPOSE</i>	<i>QTY</i>
Standard	Flashlight	To make the inspection of the area easier	

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Center fuselage I - passenger cabin top

I. Preparation (Figure 601)

**SUBTASK 841-002-A**

- (1) Use table 601 to remove passenger-cabin headliner panels 233ALC, 233BLC, 233CLC, and 234ARC as applicable from your aircraft (AMM TASK 25-22-04-000-801-A/400) or (AMM TASK 25-22-04-000-802-A/400) (Figure 601).

Table 601 - PASSENGER-CABIN HEADLINER PANELS

AIRCRAFT MODELS	PANELS
EMB-145 ( )	233ALC, 233BLC, and 234ARC
EMB-135 ( )	233ALC, 233BLC, 234ARC and 233CLC <sup>[1]</sup>

[1] This headliner panel is applicable only to EMB-135 ( ) aircraft models.

- (2) Remove the thermoacoustic insulation from center fuselage I to zones 233/234 (AMM TASK 25-81-01-000-801-A/400) or (AMM TASK 25-81-01-000-802-A/400) as applicable.

J. Internal General Visual Inspection (Figure 602)

**SUBTASK 212-002-A**

- (1) Examine the interior of the zone for loose rivets, skin deformation, nicks, cracks, dents, sealant poor condition, scratches, gouges, creases, erosion, corrosion, painting condition, deteriorated protective treatment, and foreign objects.
- (2) Examine the interior of the fuselage skin panel at stringers, frames/bulkheads, and longitudinal and circumferential splices for loose rivets, cracks, skin deformation, painting, erosion, corrosion, and deteriorated protective treatment (Figure 602).
- (3) Examine drains for signs of corrosion. Also do a check for blockage and correct operation (AMM TASK 12-23-00-600-801-A/300).
- (4) Examine the interior of the zone for leakage on the skin, signs of friction, tension, broken strands, and signs of overheating.

K. Follow-on


**SUBTASK 842-002-A**

- (1) Install the thermoacoustic insulation to zones 233/234 (AMM TASK 25-81-01-400-801-A/400) or (AMM TASK 25-81-01-400-802-A/400) as applicable.
- (2) Use table 601 to install passenger-cabin headliner panels as applicable to your aircraft (AMM TASK 25-81-01-400-801-A/400) or (AMM TASK 25-81-01-400-802-A/400).

EFFECTIVITY: ALL

Center Fuselage I - Passenger-Cabin Headliner Panels

Figure 601



1 APPLICABLE TO EMB-145 (ALL) MODELS.


2 APPLICABLE TO EMB-135 (ALL) MODELS.

145AMM050146.MCE

**EFFECTIVITY: ALL**

**Center Fuselage I - Passenger Cabin Top - Internal General Visual Inspection**

**Figure 602**



INTERNALLY INSPECT SKIN PANEL AT STRINGERS AND FRAMES/BULKHEADS.

145AMM050174.MCE

