

ENGINE FIRE EXTINGUISHING SYSTEM - ADJUSTMENT/TEST

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to check the engine fire extinguishing system.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

| TASK NUMBER | DESCRIPTION | EFFECTIVITY |
|----------------------|--|-------------|
| 26-21-00-700-801-A ◆ | ENGINE FIRE EXTINGUISHING SYSTEM - ALL FUNCTIONAL CHECK | |

TASK 26-21-00-700-801-A

EFFECTIVITY: ALL

2. ENGINE FIRE EXTINGUISHING SYSTEM - FUNCTIONAL CHECK

A. General

- (1) This procedure is a check on the fire handles and the electrical circuit of the engine fire extinguishing system for correct operation.

B. References

| REFERENCE | DESIGNATION |
|---------------------------------|--|
| AMM MPP 06-41-00/100 | - |
| AMM SDS 24-36-00/1 | |
| AMM SDS 31-41-00/1 | |
| AMM TASK 20-40-01-860-801-A/200 | ENERGIZATION OF THE AIRCRAFT WITH AN EXTERNAL POWER SOURCE |
| S.B.145-26-0007 | - |

C. Zones and Accesses

| ZONE | PANEL/DOOR | LOCATION |
|------|------------|-----------------------|
| 312 | 312AR | Tail cone compartment |

D. Tools and Equipment

| ITEM | DESCRIPTION | PURPOSE | QTY |
|------------------------|--------------------|--------------------------------|-----|
| Commercially available | Digital Multimeter | To measure continuity/voltage | |
| Commercially available | Ladder | To get access to the tail cone | |

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

| QTY | FUNCTION | PLACE |
|-----|---------------|-----------------------|
| 1 | Does the task | Tail cone compartment |
| 1 | Does the task | Cockpit |

I. Preparation

SUBTASK 841-002-A

- (1) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them.
 - FIRE EXTG BTL A 1/2.
 - FIRE EXTG BTL B 1/2.
- (2) Open access door 312AR (AMM MPP 06-41-00/100) to get access to the tail cone compartment.

WARNING: • **WHEN YOU CONNECT OR DISCONNECT THE ELECTRIC CONNECTOR OF THE BOTTLE CARTRIDGE, OR WHEN YOU KEEP IT DISCONNECTED, YOU MUST BE VERY CAREFUL WITH THE PINS OF ITS RECEPTACLE.**

- **THE CARTRIDGE IS AN EXPLOSIVE DEVICE. ACCIDENTAL DETONATION OF A CARTRIDGE BY ELECTROSTATIC DISCHARGE CAN CAUSE INJURY. FOR SAFE HANDLING, DO NOT TOUCH THE CARTRIDGE CONNECTOR PINS AFTER YOU REMOVE THE PROTECTIVE CAP OR ELECTRICAL CONNECTOR.**

- (3) Disconnect the electrical connectors (1) from the fire extinguishing bottle cartridges (2). Protect the receptacles with plastic caps.
- (4) Energize the aircraft with a DC Power Supply ([AMM TASK 20-40-01-860-801-A/200](#)).
- (5) Set MFD 1 (or 2) to the ELEC page ([AMM SDS 31-41-00/1](#)):
 - (a) Read the battery 1 voltage and record it as V_1 ([AMM SDS 24-36-00/1](#)).
 - (b) Read the battery 2 voltage and record it as V_2 ([AMM SDS 24-36-00/1](#)).

J. Functionally Check Engine Fire Extinguishing System ([Figure 501](#))

SUBTASK 720-002-A

- (1) Do the check as follows:
 - (a) Make sure that there is continuity to ground from pin A of the electrical connectors (1).
- (2) On the circuit breaker panel, close the circuit breakers below:
 - FIRE EXTG BTL A 1/2.
 - FIRE EXTG BTL B 1/2.
- (3) Examine the fire handle 1 as follows:
 - (a) Pull fire handle 1 and turn it left.

Result:

 - 1 The voltage between pins A and B, and pins A and C of connector P0917 must be $V_1 \pm 0.5$ V DC.

- (b) Turn fire handle 1 right.
Result:
1 The voltage between pins A and B, and pins A and C of connector P0920 must be $V_2 \pm 0.5$ V DC.
- (4) Push fire handle 1 to put it back to the normal condition.
- (a) Make sure that there is a voltage of approximately 21.5 V DC between pins A and B, and pins A and C of electrical connectors P0917 and P0920.
- (5) Examine fire handle 2 as follows:
- (a) Pull fire handle 2 and turn it left.
Result:
1 The voltage between pins A and B, and pins A and C of connector P0918 must be $V_1 \pm 0.5$ V DC.
- (b) Turn the fire handle 2 to the right.
Result:
1 The voltage between pins A and B, and pins A and C of connector P0929 must be $V_2 \pm 0.5$ V DC.
- (6) Push fire handle 2 to put it back to the normal condition.
- (a) Make sure that there is a voltage of approximately 21.5 V DC between pins A and B, and A and C of electrical connectors P0918 and P0929.
- (7) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them:
- FIRE EXTG BTL A 1/2.
 - FIRE EXTG BTL B 1/2.
- (8) Install a jumper between pins A and B of connectors P917, P918, P920, and P929.
- (9) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them:
- FIRE EXTG BTL A 1/2.
 - FIRE EXTG BTL B 1/2.
- (10) On the EICAS display, the messages below go out of view:
- E1 EXT BTLA INOP.
 - E2 EXT BTLA INOP.
 - E1 EXT BTLB INOP.
 - E2 EXT BTLB INOP.
- (11) Do a check on the EICAS messages as follows:
- (a) Open the jumper of connector P917.

Result:

1 The message E1 EXT BTLA INOP comes into view on the EICAS display.

- (b) Close the jumper of connector P917.

Result:

1 The message E1 EXT BTLA INOP goes out of view on the EICAS display.

- (c) Open the jumper of connector P918.

Result:

1 The message E2 EXT BTLA INOP comes into view on the EICAS display.

- (d) Close the jumper of connector P918.

Result:

1 The message E2 EXT BTLA INOP goes out of view on the EICAS display.

- (e) Open the jumper of connector P920.

Result:

1 The message E1 EXT BTLB INOP comes into view on the EICAS display.

- (f) Close the jumper of connector P920.

Result:

1 The message E1 EXT BTLB INOP goes out of view on the EICAS display.

- (g) Open the jumper of connector P929.

Result:

1 The message E2 EXT BTLB INOP comes into view on the EICAS display.

- (h) Close the jumper of connector P929.

Result:

1 The message E2 EXT BTLB INOP goes out of view on the EICAS display.

- (i) On the circuit breaker panel, open the FIRE EXT BTLA 1 circuit breaker.

Result:

1 The message E1 EXT BTLA INOP comes into view on the EICAS display.

- (j) On the circuit breaker panel, close the FIRE EXT BTLA 1 circuit breaker.

Result:

1 The message E1 EXT BTLA INOP goes out of view on the EICAS display.

- (k) On the circuit breaker panel, open the FIRE EXT BTLA 2 circuit breaker.

Result:

1 The message E2 EXT BTLA INOP comes into view on the EICAS display.

- (l) On the circuit breaker panel, close the FIRE EXT BTLA 2 circuit breaker.

Result:

1 The message E2 EXT BTLA INOP goes out of view on the EICAS display.

- (m) On the circuit breaker panel, open the FIRE EXT BTLB 1 circuit breaker.

Result:

1 The message E1 EXT BTLB INOP comes into view on the EICAS display.

- (n) On the circuit breaker panel, close the FIRE EXT BTLB 1 circuit breaker.

Result:

1 The message E1 EXT BTLB INOP goes out of view on the EICAS display.

- (o) On the circuit breaker panel, open the FIRE EXT BTLB 2 circuit breaker.
Result:
1 The message E2 EXT BTLB INOP comes into view on the EICAS display.
- (p) On the circuit breaker panel, close the FIRE EXT BTLB 2 circuit breaker.
Result:
1 The message E2 EXT BTLB INOP goes out of view on the EICAS display.
- (12) For aircraft PRE-MOD. [S.B.145-26-0007](#) with EICAS versions up to 17:
- (a) Disconnect the P919 and P930 electrical connectors from the bottle pressure gauge and switches (3).
Result:
1 The EICAS display shows the messages below:
- E1 EXBTBLA INOP.
 - E2 EXBTBLA INOP.
 - E1 EXBTBLB INOP.
 - E2 EXBTBLB INOP.
- (b) Connect the P919 and P930 connectors to the pressure gauge and switches (3).
NOTE: Make sure that the connector colored identification and inscription match those of the ring sticker applied around the bottle pressure gauge guard.
Result:
1 The EICAS messages go out of view.
- (13) For aircraft POST-MOD. [S.B.145-26-0007](#) with EICAS versions up to 17 or with EICAS versions 18 and on:
- (a) Disconnect the P919 and P930 electrical connectors from the pressure gauge and switches (3):
- (b) Install a jumper between pins A and C of the P919 and P930 electrical connectors.
Result:
1 The EICAS display shows the messages below:
- E1 EXBTBLA INOP.
 - E2 EXBTBLA INOP.
 - E1 EXBTBLB INOP.
 - E2 EXBTBLB INOP.
- (c) Remove the jumpers from between pins A and C of the P919 and P930 connectors.
Result:
1 The EICAS messages go out of view.
- (d) Connect the P919 and P930 connectors to the bottle pressure gauge and switches (3).

NOTE: Make sure that the connector colored identification and inscription match those of the ring sticker applied around the bottle pressure gauge guard.

K. Follow-on (Figure 501)

SUBTASK 842-002-A

- (1) Deenergize the aircraft ([AMM TASK 20-40-01-860-801-A/200](#)).
- (2) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them:
 - FIRE EXTG BTL A 1/2.
 - FIRE EXTG BTL B 1/2.
- (3) Remove the jumpers from connectors P917, P918, P920, and P929.

WARNING: • **WHEN YOU CONNECT OR DISCONNECT THE ELECTRIC CONNECTOR OF THE BOTTLE CARTRIDGE, OR WHEN YOU KEEP IT DISCONNECTED, YOU MUST BE VERY CAREFUL WITH THE PINS OF ITS RECEPTACLE.**

- **THE CARTRIDGE IS AN EXPLOSIVE DEVICE. ACCIDENTAL DETONATION OF A CARTRIDGE BY ELECTROSTATIC DISCHARGE CAN CAUSE INJURY. FOR SAFE HANDLING, DO NOT TOUCH THE CARTRIDGE CONNECTOR PINS AFTER YOU REMOVE THE PROTECTIVE CAP OR ELECTRICAL CONNECTOR.**

- (4) Remove from the cartridges receptacle the protective plastic caps, and connect the electrical connectors (1) to the related cartridges (2).


NOTE: Make sure that the connector colored identification and inscription match those of the ring sticker applied around the bottle outlets.

- (5) Close access door 312AR (AMM MPP 06-41-00/100).
- (6) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them:
 - FIRE EXTG BTL A 1/2.
 - FIRE EXTG BTL B 1/2.

EFFECTIVITY: ALL

Functional Check of the Engine Fire Extinguishing System -Component Locations

Figure 501 - Sheet 1




145AMM260046.MCE C


EFFECTIVITY: ALL

Functional Check of the Engine Fire Extinguishing System -Component Locations

Figure 501 - Sheet 2



DET. B



DET. A



1 TORQUE: FINGER TIGHTENING + 45°

EM145AMM260293A.DGN

EFFECTIVITY: ALL

Functional Check of the Engine Fire Extinguishing System -Component Locations

Figure 501 - Sheet 3



DET. A

145AMM260165.MCE A