

## REAR WING-TO-FUSELAGE FAIRING - INTERNAL - INSPECTION/CHECK

*EFFECTIVITY: ALL*

### 1. General

- A. This section gives the procedures to do the visual inspection of rear wing-to-fuselage fairing for general condition.
- B. Related Zone: 193.
- C. (Applicable to EMB-145 (ALL) models) Zone Boundaries: STA X = 16783.5 thru STA X = 20230.0.  
(Applicable to EMB-135 (ALL) models) Zone Boundaries: STA X = 14777.5 thru STA X = 18320.8.
- D. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
05-30-16-200-801-A	REAR WING-TO-FUSELAGE FAIRING - INTERNAL GENERAL VISUAL INSPEC- TION	ALL

TASK 05-30-16-200-801-A

EFFECTIVITY: ALL

## 2. REAR WING-TO-FUSELAGE FAIRING - INTERNAL GENERAL VISUAL INSPECTION

### A. General

- (1) This task gives instructions to do the internal general visual inspection (GVI) of rear wing-to-fuselage fairing, at zone 193, within a touching distance of the items examined.
- (2) The function of the internal general visual inspection (GVI) is to find damage, failure, or irregular conditions that can be easily seen.

### B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
AMM TASK 53-04-30-000-801-A/400	-
AMM TASK 53-04-30-400-801-A/400	-

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
193	193ABB	Rear wing-to-fuselage fairing

### D. Tools and Equipment

ITEM	DESCRIPTION	PURPOSE	QTY
Standard	Flashlight	To make the inspection of the area easier	

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Rear wing-to-fuselage fairing

### I. Preparation

#### SUBTASK 841-002-A

- (1) Remove the rear wing-to-fuselage fairing 193ABB (AMM MPP 06-41-01/100) (AMM TASK 53-04-30-000-801-A/400).

J. Internal General Visual Inspection ([Figure 601](#))

*SUBTASK 212-002-A*

- (1) Examine the interior of the zone for loose rivets, nut, screws, washers, hinges, rings, skin deformation, nicks, cracks, dents, delaminations, sealant condition, scratches, erosion, and deteriorated protective treatment ([Figure 601](#)).

K. Follow-on



*SUBTASK 842-002-A*

- (1) Install the rear wing-to-fuselage fairing 193ABB (AMM MPP 06-41-01/100) (AMM TASK 53-04-30-400-801-A/400).

**EFFECTIVITY: ALL**

Rear Wing-to-Fuselage Fairing - Internal General Visual Inspection

Figure 601



145AMM050251.MCE