

## SIDE-HINGED MAIN-DOOR ACTUATING AND LOCKING MECHANISM - ADJUSTMENT/TEST

*EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR*

### 1. General

- A. This section gives the procedures to do the functional check of the actuating, latching, and locking mechanism of the side-hinged main door.
- B. These procedures are applicable to the locking and unlocking simulations of the side-hinged main door with the internal and external handles.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
52-18-06-700-801-A ♦	SIDE-HINGED MAIN DOOR ACTUATING LATCHING AND LOCKING MECHANISM-FUNCTIONAL CHECK	AIRCRAFT WITH SIDE-HINGED MAIN DOOR

TASK 52-18-06-700-801-A

*EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR*

2. SIDE-HINGED MAIN DOOR ACTUATING LATCHING AND LOCKING MECHANISM- FUNCTIONAL CHECK

A. General

- (1) This task gives the procedures to do the functional check of the actuating, latching, and locking mechanism of the side-hinged main door.

B. References

REFERENCE	DESIGNATION
<a href="#">AMM TASK 52-18-00-820-802-A/500</a>	MAIN-DOOR INTERCONNECTING RODS - ADJUSTMENT
<a href="#">AMM TASK 52-18-00-820-803-A/500</a>	MAIN-DOOR LOCKING-MECHANISM CAMS - TEST
<a href="#">AMM TASK 52-18-00-820-804-A/500</a>	MAIN DOOR CABLES - ADJUSTMENT
<a href="#">AMM TASK 52-18-00-820-805-A/500</a>	MAIN DOOR ROLLERS - ADJUSTMENT
<a href="#">AMM TASK 52-18-00-820-806-A/500</a>	MAIN DOOR-TO-FUSELAGE SKIN GAP - ADJUSTMENT
<a href="#">AMM TASK 52-18-00-820-807-A/500</a>	MAIN DOOR-TO-FUSELAGE SKIN STEP - ADJUSTMENT
<a href="#">AMM TASK 52-18-00-820-808-A/500</a>	MAIN DOOR STOPS - ADJUSTMENT
<a href="#">AMM TASK 52-18-00-820-810-A/500</a>	MAIN-DOOR FOLDING FLAP - ADJUSTMENT

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

Not Applicable

I. Functional Check of Side-Hinged Main Door Actuating, Latching, and Locking Mechanism

*SUBTASK 720-002-A*

- (1) Do a functional check of the actuating, latching, and locking mechanism of the side-hinged main door as follows:

- (a) Adjust the main-door interconnecting rods ([AMM TASK 52-18-00-820-802-A/500](#)).

- (b) Adjust the main-door locking-mechanism cams ([AMM TASK 52-18-00-820-803-A/500](#)).
- (c) Adjust the main door cables ([AMM TASK 52-18-00-820-804-A/500](#)).
- (d) Adjust the main door rollers ([AMM TASK 52-18-00-820-805-A/500](#)).
- (e) Adjust the main door-to-fuselage skin gap ([AMM TASK 52-18-00-820-806-A/500](#)).
- (f) Adjust the main door-to-fuselage skin step ([AMM TASK 52-18-00-820-807-A/500](#)).
- (g) Adjust the main door stops ([AMM TASK 52-18-00-820-808-A/500](#)).
- (h) Adjust the main-door folding flap ([AMM TASK 52-18-00-820-810-A/500](#)).

