

## MAIN-DOOR FRAME RUBBER SEAL - MAINTENANCE PRACTICES

*EFFECTIVITY: ALL*

1. General

- A. This section gives the procedure to replace the main-door frame rubber seal.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
53-21-01-960-801-A ◆	MAIN-DOOR FRAME RUBBER SEAL - RE- PLACEMENT	ALL

TASK 53-21-01-960-801-A

EFFECTIVITY: ALL

## 2. MAIN-DOOR FRAME RUBBER SEAL - REPLACEMENT

### A. General

(1) This task gives the procedure to replace the main-door frame rubber seal.

### B. References

REFERENCE	DESIGNATION
<a href="#">AMM TASK 53-21-01-000-801-A/400</a>	MAIN-DOOR FRAME RUBBER SEAL - REMOVAL
<a href="#">AMM TASK 53-21-01-400-801-A/400</a>	MAIN-DOOR FRAME RUBBER SEAL - INSTALLATION

### C. Zones and Accesses

Not Applicable

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Main door cutout

### I. Replacement of the Main-Door Frame Rubber Seal

#### *SUBTASK 960-002-A*

- (1) Remove the main-door frame rubber seal ( [AMM TASK 53-21-01-000-801-A/400](#)).
- (2) Discard the main-door frame rubber seal.
- (3) Install a new main-door frame rubber seal ( [AMM TASK 53-21-01-400-801-A/400](#)).