

---

**STORM WINDOW MOLDING - REMOVAL/INSTALLATION***EFFECTIVITY: ALL*1. General

- A. This section gives the procedures to remove/install the LH/RH storm window fairing.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

| <i>TASK NUMBER</i> | <i>DESCRIPTION</i>                        | <i>EFFECTIVITY</i> |
|--------------------|---|--------------------|
| 25-12-13-000-801-A | LH/RH STORM WINDOW FAIRING - REMOVAL      | ALL                |
| 25-12-13-400-801-A | LH/RH STORM WINDOW FAIRING - INSTALLATION | ALL                |

TASK 25-12-13-000-801-A

EFFECTIVITY: ALL

## 2. LH/RH STORM WINDOW FAIRING - REMOVAL

### A. General

(1) This task gives the procedures to remove the LH/RH storm window fairing.

### B. Zones and Accesses

Not Applicable

### C. Tools and Equipment

Not Applicable

### D. Auxiliary Items

Not Applicable

### E. Consumable Materials

Not Applicable

### F. Expandable Parts

Not Applicable

### G. Persons Recommended

| QTY | FUNCTION      | PLACE   |
|-----|---------------|---------|
| 1   | Does the task | Cockpit |

### H. Removal (Figure 401) (Figure 402)




#### SUBTASK 020-002-A

- (1) Remove the LH storm window fairing (Figure 401) as follows:
  - (a) Remove the screws (3) and the washers (2) that attach the front fairing (1).
  - (b) Remove the screws (5) and the washers (4) that attach the lower fairing (6).
  - (c) Remove the screws (7) and the washers (8) that attach the rear fairing (9).
- (2) Remove the RH storm window fairing (Figure 402) as follows:
  - (a) Remove the screws (3) and the washers (2) that attach the front fairing (1).
  - (b) Remove the screws (5) and the washers (4) that attach the lower fairing (6).
  - (c) Remove the screws (7) and the washers (8) that attach the rear fairing (9).

**EFFECTIVITY: ALL**

**LH Storm Window Fairing - Removal/Installation**

**Figure 401**




145AMM251796.MCE

EFFECTIVITY: ALL

RH Storm Window Fairing - Removal/Installation

Figure 402



145AMM251798.MCE

TASK 25-12-13-400-801-A

EFFECTIVITY: ALL

### 3. LH/RH STORM WINDOW FAIRING - INSTALLATION

#### A. General

(1) This task gives the procedures to install the LH/RH storm window fairing.

#### B. Zones and Accesses

Not Applicable

#### C. Tools and Equipment

Not Applicable

#### D. Auxiliary Items

Not Applicable

#### E. Consumable Materials

Not Applicable

#### F. Expandable Parts

Not Applicable

#### G. Persons Recommended

| QTY | FUNCTION      | PLACE   |
|-----|---------------|---------|
| 1   | Does the task | Cockpit |

#### H. Installation (Figure 401) (Figure 402)

##### *SUBTASK 420-002-A*

(1) Install the LH storm window fairing (Figure 401) as follows:

- (a) Install the rear fairing (9) with the washers (8) and screws (7).
- (b) Install the lower fairing (6) with the washers (4) and screws (5).
- (c) Install the front fairing (1) with the washers (2) and screws (3).

(2) Install the RH storm window fairing (Figure 402) as follows:

- (a) Install the rear fairing (9) with the washers (8) and screws (7).
- (b) Install the lower fairing (6) with the washers (4) and screws (5).
- (c) Install the front fairing (1) with the washers (2) and screws (3).

