

## TUBING JOINTS - REMOVAL/INSTALLATION

*EFFECTIVITY: ALL*

### 1. General

- A. The procedures for the typical removal of the pneumatic line joints are given in [AMM TASK 36-11-09-000-801-A/400](#), [AMM TASK 36-11-09-000-802-A/400](#) or [AMM TASK 36-11-10-000-801-A/400](#), as applicable.
- B. The procedures for the typical installation of the pneumatic line joints are given in [AMM TASK 36-11-09-400-801-A/400](#), [AMM TASK 36-11-09-400-802-A/400](#) or [AMM TASK 36-11-10-400-801-A/400](#), as applicable.
- C. The procedures for the typical removal of the fuel line joints are given in [AMM TASK 28-21-13-000-801-A/400](#) or [AMM TASK 28-21-13-000-802-A/400](#), as applicable.
- D. The procedures for the typical installation of the fuel line joints are given in [AMM TASK 28-21-13-400-801-A/400](#) or [AMM TASK 28-21-13-400-802-A/400](#), as applicable.

