

---

WASH BASIN - REMOVAL/INSTALLATION

*EFFECTIVITY: ALL*

1. General

- A. The procedure for the removal and installation is given in the AMM TASK 25-40-01-000-801-A/400 (for the removal) and AMM TASK 25-40-01-400-801-A/400 (for the installation).

