

ELT REMOTE SWITCH PANEL - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to remove/install the Emergency Locator Transmitter (ELT) Remote Switch Panel.
- B. The ELT Remote Switch Panel is installed on the instrument panel.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
25-61-02-000-801-A	ELT REMOTE SWITCH PANEL (ELT AR-TEX) - REMOVAL	ALL
25-61-02-400-801-A	ELT REMOTE SWITCH PANEL (ELT AR-TEX) - INSTALLATION	ALL
25-61-02-000-802-A	ELT REMOTE SWITCH PANEL (ELT SA-TORI) - REMOVAL	ALL
25-61-02-400-802-A	ELT REMOTE SWITCH PANEL (ELT SA-TORI) - INSTALLATION	ALL

TASK 25-61-02-000-801-A

EFFECTIVITY: ALL

2. ELT REMOTE SWITCH PANEL (ELT ARTEX) - REMOVAL

A. General

(1) This task gives the procedures to remove the ELT remote switch panel (ELT ARTEX).

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

<i>QTY</i>	<i>FUNCTION</i>	<i>PLACE</i>
1	Does the task	Cockpit - instrument panel

H. Preparation

SUBTASK 841-002-A

(1) On the circuit breaker panel, open the ELT circuit breaker and attach a DO-NOT-CLOSE tag to it.

(2) Get access to the ELT remote switch panel, on the instrument panel.

I. Removal

SUBTASK 020-002-A

(1) Remove the four screws which attach the ELT remote switch panel to the instrument panel.


(2) Disconnect the connector from behind the ELT remote switch panel.

(3) Remove the ELT remote switch panel.

EFFECTIVITY: ALL

ELT Remote Switch Panel (ELT ARTEX) - Removal/Installation

Figure 401



1 AIRCRAFT WITH RMU INSTALLED ON CONTROL PEDESTAL

2 AIRCRAFT WITH RMU INSTALLED ON MAIN INSTRUMENT PANEL

145AMM250020.MCE B

TASK 25-61-02-400-801-A

EFFECTIVITY: ALL

3. ELT REMOTE SWITCH PANEL (ELT ARTEX) - INSTALLATION

A. General

(1) This task gives the procedures to install the ELT remote switch panel (ELT ARTEX).

B. References

REFERENCE	DESIGNATION
AMM TASK 25-61-00-700-801-A/500	EMERGENCY LOCATOR TRANSMITTER SYSTEM (ELT 110-4) - OPERATIONAL CHECK
AMM TASK 25-61-00-700-803-A/500	EMERGENCY LOCATOR TRANSMITTER SYSTEM (ELT C406-2) - OPERATIONAL CHECK

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Cockpit - instrument panel

I. Installation

SUBTASK 420-002-A

- (1) Connect the connector behind the ELT remote switch panel.
- (2) Install and attach the ELT remote switch panel to the instrument panel.

J. Follow-on

SUBTASK 842-002-A

- (1) On the circuit breaker panel, remove the DO-NOT-CLOSE tag from the ELT circuit breaker and close it.
- (2) (FOR AIRCRAFT WITH ELT ARTEX 110-4) Do the Emergency Locator Transmitter System - Operational Check ([AMM TASK 25-61-00-700-801-A/500](#)).

- (3) (FOR AIRCRAFT WITH ELT ARTEX C406-2) Do the Emergency Locator Transmitter System - Operational Check ([AMM TASK 25-61-00-700-803-A/500](#)).

TASK 25-61-02-000-802-A

EFFECTIVITY: ALL

4. ELT REMOTE SWITCH PANEL (ELT SATORI) - REMOVAL

A. General

- (1) This procedure gives the instructions to remove the ELT remote switch panel (ELT SATORI).

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

<i>QTY</i>	<i>FUNCTION</i>	<i>PLACE</i>
1	Does the task	Cockpit - instrument panel

H. Preparation

SUBTASK 841-003-A

- (1) On the circuit breaker panel, open the ELT circuit breaker and attach a DO-NOT-CLOSE tag to it.
- (2) Get access to the ELT remote switch panel, on the instrument panel.

I. Removal


SUBTASK 020-003-A

- (1) Remove the four screws (3) which attach the ELT remote switch panel (2) to the instrument panel.
- (2) Disconnect the connector (1) from behind the ELT remote switch panel (2).
- (3) Remove the ELT remote switch panel (2).

EFFECTIVITY: AIRCRAFT WITH ELT SATORI

ELT Remote Switch Panel (ELT SATORI) - Removal/Installation

Figure 402



1 AIRCRAFT WITH RMU INSTALLED ON CONTROL PEDESTAL

2 AIRCRAFT WITH RMU INSTALLED ON MAIN INSTRUMENT PANEL

145AMM250031.MCE B

TASK 25-61-02-400-802-A

EFFECTIVITY: ALL

5. ELT REMOTE SWITCH PANEL (ELT SATORI) - INSTALLATION

A. General

(1) This procedure gives the instructions to install the ELT remote switch panel (ELT SATORI).

B. References

REFERENCE	DESIGNATION
AMM TASK 25-61-00-700-802-A/500	EMERGENCY-LOCATOR-TRANSMITTER SYSTEM (ELT SATORI) - OPERATIONAL CHECK

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Cockpit - instrument panel

I. Installation

SUBTASK 420-003-A

(1) Connect the connector (1) behind the ELT remote switch panel (2).

(2) Install and attach the ELT remote switch panel (2) to the instrument panel.

J. Follow-on

SUBTASK 842-003-A

(1) On the circuit breaker panel, remove the DO-NOT-CLOSE tag from the ELT circuit breaker and close it.

(2) Do the Emergency Locator Transmitter System (ELT SATORI) - Operational Check ([AMM TASK 25-61-00-700-802-A/500](#)).