

TABLE OF CONTENTS

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-00-01/200	U	Oct 30/15
LANDING GEAR SAFETY PIN - MAINTENANCE PRACTICES		
32-00-01-910-801-A	U	Oct 30/15
LG SAFETY PIN - INSTALLATION AND REMOVAL		
32-00-02/200	U	Oct 30/15
NOSE LANDING GEAR DOORS SAFETY PIN - MAINTENANCE PRACTICES		
32-00-02-910-801-A	U	Oct 30/15
SAFETY PIN OF THE NLG DOORS SOLENOID VALVE - INSTALLATION AND REMOVAL		
32-00-03/200	U	Oct 30/15
LANDING GEAR ELECTRICAL HARNESS AND WIRES - MAINTENANCE PRACTICES		
32-00-03-800-801-A	U	Oct 31/16
LANDING GEAR ELECTRICAL HARNESS AND WIRES - LOCATION AND PART DATA		
32-10-00/600	U	Oct 30/15
MAIN LANDING GEAR AND DOORS - INSPECTION/CHECK		
32-10-00-200-801-A	U	Oct 30/15
MLG DOORS - INSPECTION		
32-10-01/200	U	Oct 30/15
MAIN-LANDING-GEAR LEG - MAINTENANCE PRACTICES		
32-10-01-900-801-A	U	Oct 30/15
MLG LEG - RESTORATION		
32-10-01-900-802-A	U	Oct 30/15
MLG TRAILING ARM ASSY - RESTORATION		
32-10-01/400 CONFIG-1	U	Oct 30/15
EFFECTIVITY: ACFT MODEL(S) EMB-145		
MAIN-LANDING-GEAR LEG - REMOVAL/INSTALLATION		
32-10-01-000-801-A CONFIG-1	U	Apr 28/17
EFFECTIVITY: ACFT MODEL(S) EMB-145		
MAIN LANDING-GEAR LEG - REMOVAL		

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 1 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-10-01-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> MAIN-LANDING-GEAR LEG - INSTALLATION	R	Oct 29/18
32-10-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> MAIN-LANDING-GEAR LEG - REMOVAL/INSTALLATION	U	Oct 30/15
32-10-01-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> MAIN LANDING-GEAR LEG - REMOVAL	U	Apr 28/17
32-10-01-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> MAIN-LANDING-GEAR LEG - INSTALLATION	R	Oct 29/18
32-10-02/200 MAIN-LANDING-GEAR SHOCK ABSORBER - MAINTENANCE PRACTI- CES	U	Oct 30/15
32-10-02-900-801-A MLG SHOCK ABSORBER - RESTORATION	U	Oct 30/15
32-10-02/300 MAIN-LANDING-GEAR SHOCK ABSORBER - SERVICING	U	Oct 30/15
32-10-02-600-801-A MLG SHOCK ABSORBER - SERVICING	U	Apr 27/18
32-10-02/400 MAIN-LANDING-GEAR SHOCK ABSORBER - REMOVAL/INSTALLA- TION	U	Oct 30/15
32-10-02-000-801-A SHOCK ABSORBER OF THE MAIN LANDING GEAR - REMOVAL	U	Oct 30/15
32-10-02-400-801-A SHOCK ABSORBER OF THE MAIN LANDING GEAR - INSTALLATION	U	Oct 30/15
32-10-02/600 MAIN-LANDING-GEAR SHOCK ABSORBER - INSPECTION/CHECK	U	Oct 30/15
32-10-02-200-801-A MLG SHOCK ABSORBER - INSPECTION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 2 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-10-02/800 MAIN-LANDING-GEAR SHOCK ABSORBER - REPAIR	U	Oct 30/15
32-10-02-300-801-A SHOCK ABSORBER - REPAIR	U	Oct 30/15
32-10-03/200 MAIN-LANDING-GEAR MAIN BRACE STRUT - MAINTENANCE PRACTICES	U	Oct 30/15
32-10-03-900-801-A MLG MAIN BRACE STRUT - RESTORATION	U	Oct 30/15
32-10-03-900-802-A MLG LOWER MAIN SIDE STRUT ASSY - RESTORATION	U	Oct 30/15
32-10-03/400 MAIN-LANDING-GEAR MAIN BRACE STRUT - REMOVAL/INSTALLATION	U	Oct 30/15
32-10-03-000-801-A MAIN BRACE STRUT OF THE MAIN LANDING GEAR - REMOVAL	U	Oct 31/17
32-10-03-400-801-A MAIN BRACE STRUT OF THE MAIN LANDING GEAR - INSTALLATION	R	Oct 29/18
32-10-04/200 MAIN LANDING GEAR AUXILIARY BRACE STRUT - MAINTENANCE PRACTICES	U	Oct 30/15
32-10-04-900-801-A MLG AUXILIARY BRACE STRUT - RESTORATION	U	Oct 30/15
32-10-04-900-802-A MLG LOWER SECONDARY SIDE STRUT ASSY - RESTORATION	U	Oct 30/15
32-10-04/400 MAIN LANDING GEAR AUXILIARY BRACE STRUT - REMOVAL/INSTALLATION	U	Oct 30/15
32-10-04-000-801-A AUXILIARY BRACE STRUT OF THE MAIN LANDING GEAR - REMOVAL	U	Feb 16/16

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 3 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-10-04-400-801-A AUXILIARY BRACE STRUT OF THE MAIN LANDING GEAR - INSTAL- LATION	U	Feb 16/16
32-10-05/200 MAIN LANDING GEAR SPRING CARTRIDGE - MAINTENANCE PRACTI- CES	U	Oct 30/15
32-10-05-900-801-A MLG SPRING ASSEMBLY - RESTORATION	U	Oct 31/16
32-10-05/400 MAIN LANDING GEAR SPRING CARTRIDGE - REMOVAL/INSTALLA- TION	U	Oct 30/15
32-10-05-000-801-A SPRING ASSEMBLIES OF THE MAIN LANDING GEAR - REMOVAL	R	Oct 29/18
32-10-05-400-801-A SPRING ASSEMBLIES OF THE MAIN LANDING GEAR - INSTALLA- TION	R	Oct 29/18
32-10-06/400 MAIN LANDING GEAR MAIN DOOR ASSEMBLY - REMOVAL/INSTAL- LATION	U	Oct 30/15
32-10-06-000-801-A MAIN DOOR ASSEMBLY OF THE MAIN LANDING GEAR - REMOVAL	U	Oct 30/15
32-10-06-400-801-A MAIN DOOR ASSEMBLY OF THE MAIN LANDING GEAR - INSTALLA- TION	U	Oct 30/15
32-10-07/400 MAIN LANDING GEAR AUXILIARY DOOR ASSEMBLY - REMOVAL/ INSTALLATION	U	Oct 30/15
32-10-07-000-801-A AUXILIARY DOOR ASSEMBLY OF THE MAIN LANDING GEAR - RE- MOVAL	R	Oct 29/18
32-10-07-400-801-A AUXILIARY DOOR ASSEMBLY OF THE MAIN LANDING GEAR - IN- STALLATION	R	Oct 29/18
32-10-08/400 MAIN-LANDING-GEAR TRAILING ARM - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-10-08-000-801-A TRAILING ARM OF THE MAIN LANDING GEAR - REMOVAL	U	Oct 30/15
32-10-08-400-801-A TRAILING ARM OF THE MAIN LANDING GEAR - INSTALLATION	U	Oct 30/15
32-10-08/600 MAIN-LANDING-GEAR TRAILING ARM - INSPECTION/CHECK	U	Oct 31/16
32-10-08-200-801-A MLG WHEEL AXLE - INSPECTION	U	Oct 31/16
32-10-08/800 MAIN-LANDING-GEAR TRAILING ARM - REPAIR	U	Oct 30/15
32-10-08-300-801-A MLG WHEEL AXLE - REPAIR	U	Oct 30/15
32-10-09/400 TRAILING ARM CARDAN OF THE MAIN LANDING GEAR - REMOVAL/ INSTALLATION	U	Oct 30/15
32-10-09-000-801-A TRAILING ARM CARDAN OF THE MAIN LANDING GEAR - REMOVAL	U	Oct 30/15
32-10-09-400-801-A TRAILING ARM CARDAN OF THE MAIN LANDING GEAR - INSTALLA- TION	U	Oct 30/15
32-10-09/600 TRAILING ARM CARDAN OF THE MAIN LANDING GEAR - INSPEC- TION/CHECK	U	Oct 30/15
32-10-09-200-801-A TRAILING ARM CARDAN OF THE MAIN LANDING GEAR - INSPEC- TION	U	Oct 30/15
32-10-10/400 MAIN SIDE-STRUT CARDAN JOINT OF THE MAIN LANDING GEAR - REMOVAL/INSTALLATION	U	Oct 30/15
32-10-10-000-801-A MAIN SIDE-STRUT CARDAN JOINT OF THE MAIN LANDING GEAR - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 5 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-10-10-400-801-A MAIN SIDE-STRUT CARDAN JOINT OF THE MAIN LANDING GEAR - INSTALLATION	U	Oct 30/15
32-10-11/400 UPPER SECONDARY STRUT CARDAN OF THE MAIN LANDING GEAR - REMOVAL/INSTALLATION	U	Oct 30/15
32-10-11-000-801-A UPPER SECONDARY STRUT CARDAN OF THE MAIN LANDING GEAR - REMOVAL	U	Oct 30/15
32-10-11-400-801-A UPPER SECONDARY STRUT CARDAN OF THE MAIN LANDING GEAR - INSTALLATION	U	Oct 30/15
32-10-12/400 MAIN LANDING-GEAR DOOR POLYURETHANE FILM - REMOVAL/ INSTALLATION	U	Oct 30/15
32-10-12-000-801-A MAIN LANDING-GEAR DOOR POLYURETHANE FILM - REMOVAL	U	Oct 30/15
32-10-12-400-801-A MAIN LANDING-GEAR DOOR POLYURETHANE FILM - INSTALLA- TION	U	Oct 30/15
32-10-12/600 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> MAIN LANDING-GEAR DOOR POLYURETHANE FILM - INSPECTION/ CHECK	U	Oct 30/15
32-10-12-200-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> MAIN LANDING-GEAR DOOR POLYURETHANE FILM - INSPECTION/ CHECK	U	Oct 30/15
32-10-12/600 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> MAIN LANDING-GEAR DOOR POLYURETHANE FILM - INSPECTION/ CHECK	U	Apr 28/17
32-10-12-200-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> MAIN LANDING-GEAR DOOR POLYURETHANE FILM - INSPECTION/ CHECK	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 6 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-20-01/200	U	Oct 30/15
NOSE-LANDING-GEAR LEG - MAINTENANCE PRACTICES		
32-20-01-900-801-A	U	Oct 30/15
NLG LEG - RESTORATION		
32-20-01-900-802-A	U	Oct 30/15
NLG SLIDING TUBE ASSY - RESTORATION		
32-20-01-900-803-A	U	Oct 30/15
NLG STEERING CUFF ASSY - RESTORATION		
32-20-01-900-804-A	U	Oct 30/15
NLG TORQUE LINK ASSY - RESTORATION		
32-20-01/300	U	Oct 30/15
NOSE-LANDING-GEAR LEG - SERVICING		
32-20-01-600-801-A	U	Oct 30/15
NLG SHOCK ABSORBER - SERVICING		
32-20-01-600-802-A	U	Oct 30/15
NLG SHOCK ABSORBER - SERVICING (CHARGING)		
32-20-01/400	U	Oct 31/16
NOSE-LANDING-GEAR LEG - REMOVAL/INSTALLATION		
32-20-01-000-801-A	U	Oct 30/15
NOSE LANDING-GEAR LEG - REMOVAL		
32-20-01-400-801-A	U	Oct 30/15
NOSE LANDING-GEAR LEG - INSTALLATION		
32-20-01-000-802-A	U	Oct 31/16
NOSE LANDING-GEAR UPLOCK PIN - REMOVAL		
32-20-01-400-802-A	U	Oct 31/16
NOSE LANDING-GEAR UPLOCK PIN - INSTALLATION		
32-20-01/500	U	Oct 30/15
NOSE-LANDING-GEAR LEG - ADJUSTMENT/TEST		
32-20-01-700-801-A	U	Oct 31/16
NLG LEG CENTERING CAM - FUNCTIONAL CHECK		
32-20-01/600	U	Oct 30/15
NOSE-LANDING-GEAR LEG - INSPECTION/CHECK		

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 7 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-20-01-200-801-A NLG - INSPECTION	U	Oct 30/15
32-20-02/200 NOSE-LANDING-GEAR MAIN BRACE STRUT - MAINTENANCE PRAC- TICES	U	Oct 30/15
32-20-02-900-801-A NLG MAIN BRACE STRUT - RESTORATION	U	Oct 30/15
32-20-02-900-802-A NLG MAIN DRAG STRUT BOTTOM STAY ASSY - RESTORATION	U	Oct 30/15
32-20-02/400 NOSE-LANDING-GEAR MAIN BRACE STRUT - REMOVAL/INSTALLA- TION	U	Oct 30/15
32-20-02-000-801-A MAIN BRACE STRUT OF THE NOSE LANDING GEAR - REMOVAL	U	Feb 16/16
32-20-02-400-801-A MAIN BRACE STRUT OF THE NOSE LANDING GEAR - INSTALLA- TION	U	Oct 30/15
32-20-03/200 NOSE LANDING GEAR AUXILIARY BRACE STRUT - MAINTENANCE PRACTICES	U	Oct 30/15
32-20-03-900-801-A NLG AUXILIARY BRACE STRUT - RESTORATION	U	Oct 30/15
32-20-03-900-802-A NLG LOWER AUXILIARY DRAG STRUT ASSY - RESTORATION	U	Oct 30/15
32-20-03/400 NOSE LANDING GEAR AUXILIARY BRACE STRUT - REMOVAL/ INSTALLATION	U	Oct 30/15
32-20-03-000-801-A AUXILIARY BRACE STRUT OF THE NOSE LANDING GEAR - RE- MOVAL	U	Oct 30/15
32-20-03-400-801-A AUXILIARY BRACE STRUT OF THE NOSE LANDING GEAR - INSTAL- LATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

 Chapter 32
Page 8 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-20-04/200 NOSE LANDING GEAR SPRING CARTRIDGE - MAINTENANCE PRACTICES	U	Oct 30/15
32-20-04-900-801-A NLG SPRING ASSEMBLY - RESTORATION	U	Oct 30/15
32-20-04/400 NOSE LANDING GEAR SPRING CARTRIDGE - REMOVAL/INSTALLATION	U	Oct 30/15
32-20-04-000-801-A SPRING ASSEMBLIES OF THE NOSE LANDING GEAR - REMOVAL	U	Oct 30/15
32-20-04-400-801-A SPRING ASSEMBLIES OF THE NOSE LANDING GEAR - INSTALLATION	U	Oct 30/15
32-20-05/400 NOSE-LANDING-GEAR DOOR ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
32-20-05-000-801-A DOOR OF THE NOSE LANDING GEAR - REMOVAL	U	Oct 30/15
32-20-05-400-801-A DOOR OF THE NOSE LANDING GEAR - INSTALLATION	U	Oct 30/15
32-20-05/500 <i>EFFECTIVITY: JAA CERTIFIED AIRCRAFT</i> NOSE-LANDING-GEAR DOOR ASSEMBLY - ADJUSTMENT/TEST	U	Oct 30/15
32-20-05-700-801-A <i>EFFECTIVITY: JAA CERTIFIED AIRCRAFT</i> NOSE-LANDING-GEAR DOOR-OPEN INDICATION - OPERATIONAL CHECK	U	Oct 30/15
32-20-05/600 NOSE-LANDING-GEAR DOOR ASSEMBLY - INSPECTION/CHECK	U	Oct 30/15
32-20-05-200-801-A NLG DOORS - INSPECTION	U	Oct 30/15
32-20-06/400 NOSE-LANDING-GEAR DOOR PROTECTIVE RUBBER SHAPES - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 9 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-20-06-000-801-A NLG-DOOR PROTECTIVE RUBBER SHAPES - REMOVAL	U	Oct 30/15
32-20-06-400-801-A NLG-DOOR PROTECTIVE RUBBER SHAPES - INSTALLATION	U	Oct 30/15
32-20-07/400 NOSE LANDING-GEAR DOOR POLYURETHANE FILM - REMOVAL/ INSTALLATION	U	Oct 30/15
32-20-07-000-801-A NOSE LANDING-GEAR DOOR POLYURETHANE FILM - REMOVAL	U	Oct 30/15
32-20-07-400-801-A NOSE LANDING-GEAR DOOR POLYURETHANE FILM - INSTALLA- TION	U	Oct 30/15
32-20-07/600 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> NOSE LANDING-GEAR DOOR POLYURETHANE FILM - INSPECTION/ CHECK	U	Oct 30/15
32-20-07-200-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> NOSE LANDING-GEAR DOOR POLYURETHANE FILM - INSPECTION/ CHECK	U	Oct 30/15
32-20-07/600 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> NOSE LANDING-GEAR DOOR POLYURETHANE FILM - INSPECTION/ CHECK	U	Apr 28/17
32-20-07-200-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> NOSE LANDING-GEAR DOOR POLYURETHANE FILM - INSPECTION/ CHECK	U	Oct 30/15
32-20-08/400 NOSE-LANDING-GEAR SLIDING TUBE - REMOVAL/INSTALLATION	U	Oct 30/15
32-20-08-000-801-A SLIDING TUBE OF THE NOSE LANDING GEAR - REMOVAL	U	Oct 30/15
32-20-08-400-801-A SLIDING TUBE OF THE NOSE LANDING GEAR - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 10 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-20-08/600 NOSE-LANDING-GEAR SLIDING TUBE - INSPECTION/CHECK	U	Oct 30/15
32-20-08-200-801-A NLG WHEEL AXLE - INSPECTION	U	Apr 27/18
32-20-08/800 NOSE-LANDING-GEAR SLIDING TUBE - REPAIR	U	Oct 30/15
32-20-08-300-801-A NLG WHEEL AXLE - REPAIR	U	Apr 27/18
32-20-09/400 AUXILIARY DRAG STRUT CARDAN OF THE NOSE LANDING GEAR - REMOVAL/INSTALLATION	U	Oct 30/15
32-20-09-000-801-A AUXILIARY DRAG STRUT CARDAN OF THE NOSE LANDING GEAR - REMOVAL	U	Oct 30/15
32-20-09-400-801-A AUXILIARY DRAG STRUT CARDAN OF THE NOSE LANDING GEAR - INSTALLATION	U	Oct 30/15
32-20-10/400 NOSE-LANDING-GEAR TORQUE LINK ASSEMBLIES - REMOVAL/ INSTALLATION	U	Oct 30/15
32-20-10-000-801-A NOSE-LANDING-GEAR TORQUE LINK ASSEMBLY - REMOVAL	U	Oct 30/15
32-20-10-400-801-A NOSE-LANDING-GEAR TORQUE LINK ASSEMBLY - INSTALLATION	U	Oct 31/16
32-20-10/600 NOSE-LANDING-GEAR TORQUE LINK ASSEMBLIES - INSPECTION/ CHECK	U	Oct 30/15
32-20-10-200-801-A NOSE-LANDING-GEAR TORQUE LINK - INSPECTION	U	Oct 31/16
32-20-11/400 NOSE-LANDING-GEAR LIGHTS PROTECTION - REMOVAL/INSTALLA- TION	U	Apr 28/17

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 11 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-20-11-000-801-A NOSE-LANDING-GEAR LIGHTS PROTECTION - REMOVAL	U	Apr 28/17
32-20-11-400-801-A NOSE-LANDING-GEAR LIGHTS PROTECTION - INSTALLATION	U	Apr 28/17
32-30-00/500 EXTENSION AND RETRACTION - ADJUSTMENT/TEST	U	Oct 30/15
32-30-00-700-801-A EXTENSION AND RETRACTION SYSTEM - OPERATIONAL CHECK	U	Oct 31/16
32-32-00/500 LANDING GEAR EXTENSION AND RETRACTION (ELECTRICAL) - ADJUSTMENT/TEST	U	Oct 30/15
32-32-00-700-801-A LG EXTENSION AND RETRACTION SYSTEM THROUGH CHANNELS A AND B - OPERATIONAL CHECK (WITH JACKS)	U	Oct 31/17
32-32-00-700-802-A FUNCTIONAL CHECK OF THE LANDING GEAR CONTROL LEVER AFTER REPLACEMENT OF THE LANDING GEAR (WITHOUT JACKS)	U	Oct 30/15
32-32-01/400 LANDING GEAR ELECTRONIC UNIT (LGEU) - REMOVAL/INSTALLATION	U	Oct 30/15
32-32-01-000-801-A LGEU - REMOVAL	U	Oct 30/15
32-32-01-400-801-A LGEU - INSTALLATION	U	Oct 30/15
32-32-02/400 LANDING GEAR CONTROL LEVER - REMOVAL/INSTALLATION	U	Oct 30/15
32-32-02-000-801-A LANDING GEAR CONTROL LEVER - REMOVAL	U	Oct 30/15
32-32-02-400-801-A LANDING GEAR CONTROL LEVER - INSTALLATION	U	Oct 30/15
32-32-02-040-801-A LANDING-GEAR CONTROL LEVER - DEACTIVATION PROCEDURE	U	Oct 30/15
32-32-02-440-801-A LANDING-GEAR CONTROL LEVER - REACTIVATION PROCEDURE	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 12 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-32-02/500 LANDING GEAR CONTROL LEVER - ADJUSTMENT/TEST	U	Oct 30/15
32-32-02-700-801-A LG CONTROL LEVER SOLENOID AND DOWNLOCK RELEASE BUT- TON - OPERATIONAL CHECK	U	Oct 30/15
32-33-01/400 FREE-FALL SELECTOR VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-01-000-801-A FREE-FALL SELECTOR VALVE - REMOVAL	U	Oct 30/15
32-33-01-400-801-A FREE-FALL SELECTOR VALVE - INSTALLATION	U	Oct 30/15
32-33-02/400 NOSE LANDING GEAR DOOR SOLENOID VALVE - REMOVAL/INSTAL- LATION	U	Oct 30/15
32-33-02-000-801-A NLG-DOOR SOLENOID-VALVE - REMOVAL	U	Oct 30/15
32-33-02-400-801-A NLG-DOOR SOLENOID-VALVE - INSTALLATION	U	Oct 30/15
32-33-03/400 NOSE LANDING GEAR DOOR ACTUATOR - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-03-000-801-A NLG DOOR ACTUATOR - REMOVAL	U	Apr 29/16
32-33-03-400-801-A NLG DOOR ACTUATOR - INSTALLATION	U	Apr 29/16
32-33-04/400 LANDING GEAR SOLENOID VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-04-000-801-A LANDING-GEAR SOLENOID-VALVE - REMOVAL	U	Oct 30/15
32-33-04-400-801-A LANDING-GEAR SOLENOID-VALVE - INSTALLATION	U	Oct 30/15
32-33-05/400 NOSE LANDING GEAR ACTUATOR - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 13 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-33-05-000-801-A NOSE LANDING GEAR ACTUATOR - REMOVAL	U	Apr 27/18
32-33-05-400-801-A NOSE LANDING GEAR ACTUATOR - INSTALLATION	U	Apr 27/18
32-33-06/400 NOSE LANDING GEAR UNLOCKING ACTUATOR - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-06-000-801-A UNLOCKING ACTUATOR OF THE NOSE LANDING GEAR - REMOVAL	U	Oct 30/15
32-33-06-400-801-A UNLOCKING ACTUATOR OF THE NOSE LANDING GEAR - INSTALLATION	U	Oct 30/15
32-33-07/400 NOSE LANDING GEAR UPLOCK BOX - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-07-000-801-A NLG UPLOCK BOX - REMOVAL	U	Oct 30/15
32-33-07-400-801-A NLG UPLOCK BOX - INSTALLATION	U	Oct 30/15
32-33-08/400 MAIN LANDING GEAR ACTUATOR - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-08-000-801-A MAIN LANDING GEAR ACTUATOR - REMOVAL	U	Oct 30/15
32-33-08-400-801-A MAIN LANDING GEAR ACTUATOR - INSTALLATION	U	Oct 30/15
32-33-08/600 MAIN LANDING GEAR ACTUATOR - INSPECTION/CHECK	U	Oct 31/16
32-33-08-200-801-A MAIN LANDING-GEAR MANEUVERING ACTUATOR - INSPECTION FOR CORROSION	U	Oct 31/16
32-33-08/800 MAIN LANDING GEAR ACTUATOR - REPAIR	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 14 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-33-08-300-801-A MAIN LANDING-GEAR ACTUATOR - REPAIR	U	Oct 30/15
32-33-09/400 MAIN LANDING GEAR UNLOCKING ACTUATOR - REMOVAL/INSTAL- LATION	U	Oct 30/15
32-33-09-000-801-A UNLOCKING ACTUATOR OF THE MAIN LANDING GEAR - REMOVAL	U	Oct 30/15
32-33-09-400-801-A UNLOCKING ACTUATOR OF THE MAIN LANDING GEAR - INSTALLA- TION	U	Oct 30/15
32-33-10/400 MAIN LANDING GEAR UPLOCK BOX - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-10-000-801-A MLG UPLOCK BOX - REMOVAL	U	Oct 30/15
32-33-10-400-801-A MLG UPLOCK BOX - INSTALLATION	U	Oct 30/15
32-33-11/400 CHECK VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-11-000-801-A CHECK VALVE - REMOVAL	U	Oct 30/15
32-33-11-400-801-A CHECK VALVE - INSTALLATION	U	Oct 30/15
32-33-12/400 RESTRICTOR VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-12-000-801-A RESTRICTOR VALVE - REMOVAL	U	Oct 30/15
32-33-12-400-801-A RESTRICTOR VALVE - INSTALLATION	U	Oct 30/15
32-33-13/400 CHECK VALVE FREE-FALL SYSTEM - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-13-000-801-A FREE-FALL CHECK VALVE - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 15 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-33-13-400-801-A FREE-FALL CHECK VALVE - INSTALLATION	U	Oct 30/15
32-33-15/400 LANDING GEAR HYDRAULIC ACCUMULATOR - REMOVAL/INSTALLATION	U	Oct 30/15
32-33-15-000-801-A LANDING-GEAR ACTUATION-SYSTEM HYDRAULIC ACCUMULATOR - REMOVAL	U	Oct 30/15
32-33-15-400-801-A LANDING-GEAR ACTUATION-SYSTEM HYDRAULIC ACCUMULATOR - INSTALLATION	U	Oct 30/15
32-33-15/500 LANDING GEAR HYDRAULIC ACCUMULATOR - ADJUSTMENT/TEST	U	Oct 30/15
32-33-15-700-801-A LANDING-GEAR HYDRAULIC ACCUMULATOR - FUNCTIONAL CHECK	U	Oct 30/15
32-33-15-700-802-A LANDING-GEAR HYDRAULIC ACCUMULATOR - LEAKAGE TEST	U	Oct 30/15
32-34-00/300 LANDING GEAR - SERVICING	U	Oct 30/15
32-34-00-600-801-A MLG AND NLG - LUBRICATION	R	Oct 29/18
32-34-00/500 LANDING GEAR - ADJUSTMENT/TEST	U	Oct 30/15
32-34-00-700-801-A LG EMERGENCY EXTENSION - OPERATIONAL AND FUNCTIONAL CHECKS	U	Oct 30/15
32-34-01/400 OVERRIDE SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
32-34-01-000-801-A OVERRIDE SWITCH - REMOVAL	U	Oct 30/15
32-34-01-400-801-A OVERRIDE SWITCH - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 16 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-34-02/400 LANDING GEAR FREE-FALL ACTUATING DEVICE - REMOVAL/ INSTALLATION	U	Oct 30/15
32-34-02-000-801-A LANDING-GEAR FREE-FALL ACTUATING DEVICE - REMOVAL	U	Oct 30/15
32-34-02-400-801-A LANDING-GEAR FREE-FALL ACTUATING DEVICE - INSTALLATION	U	Oct 30/15
32-34-03/400 FREE-FALL CONTROL CABLES - REMOVAL/INSTALLATION	U	Oct 30/15
32-34-03-000-801-A LANDING-GEAR FREE-FALL CONTROL CABLES - REMOVAL	R	Oct 29/18
32-34-03-400-801-A LANDING-GEAR FREE-FALL CONTROL CABLES - INSTALLATION	R	Oct 29/18
32-34-03/500 FREE-FALL CONTROL CABLES - ADJUSTMENT/TEST	U	Oct 30/15
32-34-03-700-801-A FREE-FALL CONTROL CABLES - CHECK	U	Oct 30/15
32-34-03-700-802-A FREE-FALL CONTROL CABLES - ADJUSTMENT	U	Oct 30/15
32-40-00/200 WHEELS AND BRAKES - MAINTENANCE PRACTICES	U	Oct 30/15
32-40-00-800-801-A NORMAL BRAKE AND EMERGENCY PARKING BRAKE SYSTEMS - BLEEDING	U	Oct 30/15
32-41-00/500 MAIN BRAKE SYSTEM - ADJUSTMENT/TEST	U	Oct 30/15
32-41-00-700-801-A MAIN BRAKE SYSTEM - FUNCTIONAL CHECK	U	Apr 28/17
32-41-01/400 BRAKE PEDAL TRANSDUCER - REMOVAL/INSTALLATION	U	Oct 30/15
32-41-01-000-801-A BRAKE-PEDAL POSITION-TRANSDUCER - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 17 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-41-01-400-801-A BRAKE-PEDAL POSITION-TRANSDUCER - INSTALLATION	U	Apr 29/16
32-41-01/500 BRAKE PEDAL TRANSDUCER - ADJUSTMENT/TEST	U	Oct 30/15
32-41-01-700-801-A BRAKE-PEDAL POSITION TRANSDUCER - OPERATIONAL CHECK	U	Oct 30/15
32-41-01-700-802-A BRAKE PEDAL TRANSDUCER - FUNCTIONAL TEST	U	Oct 30/15
32-41-02/400 BRAKE CONTROL UNIT - REMOVAL/INSTALLATION	U	Oct 30/15
32-41-02-000-801-A BRAKE CONTROL UNIT - REMOVAL	U	Oct 30/15
32-41-02-400-801-A BRAKE CONTROL UNIT - INSTALLATION	U	Oct 30/15
32-41-03/400 WHEEL SPEED TRANSDUCER - REMOVAL/INSTALLATION	U	Oct 30/15
32-41-03-000-801-A WHEEL SPEED TRANSDUCER - REMOVAL	U	Oct 30/15
32-41-03-400-801-A WHEEL SPEED TRANSDUCER - INSTALLATION	U	Oct 30/15
32-41-04/400 PRESSURE SWITCH (PRESSURE SUPPLY) - REMOVAL/INSTALLATION	U	Oct 30/15
32-41-04-000-801-A PRESSURE SWITCH (PRESSURE SUPPLY) - REMOVAL	U	Oct 30/15
32-41-04-400-801-A PRESSURE SWITCH (PRESSURE SUPPLY) - INSTALLATION	U	Oct 31/17
32-41-05/400 BRAKE SHUTOFF VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-41-05-000-801-A BRAKE SHUTOFF VALVE - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 18 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-41-05-400-801-A BRAKE SHUTOFF VALVE - INSTALLATION	U	Oct 31/17
32-41-06/400 BRAKE CONTROL VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-41-06-000-801-A BRAKE CONTROL VALVE - REMOVAL	U	Oct 30/15
32-41-06-400-801-A BRAKE CONTROL VALVE - INSTALLATION	U	Oct 31/17
32-41-07/400 HYDRAULIC FUSE - REMOVAL/INSTALLATION	U	Oct 30/15
32-41-07-000-801-A HYDRAULIC FUSE - REMOVAL	U	Oct 30/15
32-41-07-400-801-A HYDRAULIC FUSE - INSTALLATION	U	Oct 30/15
32-41-07/500 HYDRAULIC FUSE - ADJUSTMENT/TEST	U	Oct 30/15
32-41-07-700-801-A MAIN BRAKE HYDRAULIC FUSES - FUNCTIONAL CHECK	U	Oct 30/15
32-41-08/400 PRESSURE TRANSDUCER - REMOVAL/INSTALLATION	U	Oct 30/15
32-41-08-000-801-A PRESSURE TRANSDUCER - REMOVAL	U	Oct 30/15
32-41-08-400-801-A PRESSURE TRANSDUCER - INSTALLATION	U	Oct 31/17
32-41-08-040-801-A PRESSURE TRANSDUCER - DEACTIVATION PROCEDURE	U	Oct 30/15
32-41-08-440-801-A PRESSURE TRANSDUCER - REACTIVATION PROCEDURE	U	Oct 30/15
32-41-09/400 CHECK VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-41-09-000-801-A CHECK VALVE - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 19 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-41-09-400-801-A CHECK VALVE - INSTALLATION	U	Oct 30/15
32-41-09/500 CHECK VALVE - ADJUSTMENT/TEST	U	Oct 30/15
32-41-09-700-801-A RETURN-LINE CHECK VALVE - OPERATIONAL CHECK	U	Oct 30/15
32-44-00/500 EMERGENCY/PARKING BRAKE SYSTEM - ADJUSTMENT/TEST	U	Oct 30/15
32-44-00-700-801-A EMERGENCY/PARKING BRAKE SYSTEM - FUNCTIONAL CHECK	U	Oct 30/15
32-44-01/400 EMERGENCY/PARKING BRAKE VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-44-01-000-801-A EMERGENCY/PARKING BRAKE VALVE - REMOVAL	U	Oct 30/15
32-44-01-400-801-A EMERGENCY/PARKING BRAKE VALVE - INSTALLATION	U	Oct 30/15
32-44-02/200 HYDRAULIC ACCUMULATOR - MAINTENANCE PRACTICES	U	Oct 30/15
32-44-02-910-801-A HYDRAULIC ACCUMULATOR EMERGENCY/PARKING BRAKE - RE- LEASE	U	Oct 30/15
32-44-02/300 HYDRAULIC ACCUMULATOR - SERVICING	U	Oct 30/15
32-44-02-600-801-A EMERGENCY/PARKING BRAKE ACCUMULATOR - CHARGE	U	Oct 30/15
32-44-02/400 HYDRAULIC ACCUMULATOR - REMOVAL/INSTALLATION	U	Oct 30/15
32-44-02-000-801-A HYDRAULIC ACCUMULATOR OF THE EMERGENCY/PARKING BRAKE SYSTEM - REMOVAL	U	Oct 30/15
32-44-02-400-801-A HYDRAULIC ACCUMULATOR OF THE EMERGENCY/PARKING BRAKE SYSTEM - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 20 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-44-02/500 HYDRAULIC ACCUMULATOR - ADJUSTMENT/TEST	U	Oct 30/15
32-44-02-700-801-A EMERGENCY/PARKING BRAKE ACCUMULATOR - CHECK	U	Oct 30/15
32-44-02-700-802-A EMERGENCY/PARKING BRAKE ACCUMULATOR - LEAKAGE TEST	U	Oct 30/15
32-44-03/400 CHARGING VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-44-03-000-801-A CHARGING VALVE OF THE HYDRAULIC ACCUMULATOR OF THE EMERGENCY/PARKING BRAKE SYSTEM - REMOVAL	U	Oct 30/15
32-44-03-400-801-A CHARGING VALVE OF THE HYDRAULIC ACCUMULATOR OF THE EMERGENCY/PARKING BRAKE SYSTEM - INSTALLATION	U	Oct 30/15
32-44-04/400 PRESSURE GAGE - REMOVAL/INSTALLATION	U	Oct 30/15
32-44-04-000-801-A PRESSURE GAGE OF THE EMERGENCY/PARKING BRAKE SYSTEM - REMOVAL	U	Oct 30/15
32-44-04-400-801-A PRESSURE GAGE OF THE EMERGENCY/PARKING BRAKE SYSTEM - INSTALLATION	U	Oct 30/15
32-44-05/400 PRESSURE SWITCH (ACCUMULATOR LOW PRESSURE) - REMOVAL/ INSTALLATION	U	Oct 30/15
32-44-05-000-801-A PRESSURE SWITCH OF THE EMERGENCY/PARKING BRAKE SYS- TEM - REMOVAL	U	Oct 30/15
32-44-05-400-801-A PRESSURE SWITCH OF THE EMERGENCY/PARKING BRAKE SYS- TEM - INSTALLATION	U	Oct 30/15
32-44-05-040-801-A PRESSURE SWITCH OF THE EMERGENCY/PARKING BRAKE SYS- TEM - DEACTIVATION PROCEDURE	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 21 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-44-05-440-801-A PRESSURE SWITCH OF THE EMERGENCY/PARKING BRAKE SYSTEM - REACTIVATION PROCEDURE	U	Oct 30/15
32-44-05/500 PRESSURE SWITCH (ACCUMULATOR LOW PRESSURE) - ADJUSTMENT/TEST	U	Oct 30/15
32-44-05-700-801-A PRESSURE SWITCH OF THE ACCUMULATOR LOW PRESSURE - FUNCTIONAL CHECK	U	Oct 30/15
32-44-06/400 THERMAL RELIEF VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-44-06-000-801-A THERMAL RELIEF VALVE OF THE EMERGENCY/PARKING BRAKE SYSTEM- REMOVAL	U	Apr 27/18
32-44-06-400-801-A THERMAL RELIEF VALVE OF THE EMERGENCY/PARKING BRAKE SYSTEM- INSTALLATION	U	Apr 27/18
32-44-06/500 THERMAL RELIEF VALVE - ADJUSTMENT/TEST	U	Oct 30/15
32-44-06-700-801-A THERMAL RELIEF VALVE - FUNCTIONAL CHECK	U	Oct 30/15
32-44-07/400 PRESSURE SWITCH (EMERGENCY/PARKING BRAKE) - REMOVAL/INSTALLATION	U	Oct 30/15
32-44-07-000-801-A PRESSURE SWITCH - REMOVAL	U	Oct 30/15
32-44-07-400-801-A PRESSURE SWITCH - INSTALLATION	U	Oct 30/15
32-44-07-040-801-A PRESSURE SWITCH - DEACTIVATION PROCEDURE	U	Oct 30/15
32-44-07-440-801-A PRESSURE SWITCH OF THE EMERGENCY/PARKING BRAKE SYSTEM - REACTIVATION PROCEDURE	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 22 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-44-07/500 PRESSURE SWITCH (EMERGENCY/PARKING BRAKE) - ADJUST- MENT/TEST	U	Oct 30/15
32-44-07-700-801-A PRESSURE SWITCH OF THE EMERGENCY/PARKING BRAKE - OP- ERATIONAL CHECK	U	Oct 30/15
32-44-08/400 CHECK VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
32-44-08-000-801-A CHECK VALVE - REMOVAL	U	Oct 30/15
32-44-08-400-801-A CHECK VALVE - INSTALLATION	U	Oct 30/15
32-44-08/500 CHECK VALVE - ADJUSTMENT/TEST	U	Oct 30/15
32-44-08-700-801-A RETURN-LINE CHECK VALVE - OPERATIONAL CHECK	U	Oct 30/15
32-44-10/300 EMERGENCY/PARKING BRAKE HANDLE AND VALVE - SERVICING	U	Oct 30/15
32-44-10-600-801-A LUBRICATE EMERGENCY/PARKING BRAKE CONTROL	U	Oct 30/15
32-44-11/400 EMERGENCY/PARKING BRAKE - REMOVAL/INSTALLATION	U	Oct 30/15
32-44-11-000-801-A EMERGENCY/PARKING BRAKE - REMOVAL	U	Oct 30/15
32-44-11-400-801-A EMERGENCY PARKING BRAKE - INSTALLATION	U	Oct 30/15
32-44-11/500 EMERGENCY/PARKING BRAKE - ADJUSTMENT/TEST	U	Oct 30/15
32-44-11-700-801-A EMERGENCY/PARKING BRAKE - ADJUSTMENT	U	Oct 30/15
32-47-01/400 TEMPERATURE SENSORS - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 23 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-47-01-000-801-A TEMPERATURE SENSORS - REMOVAL	U	Oct 31/17
32-47-01-400-801-A TEMPERATURE SENSORS - INSTALLATION	U	Oct 31/17
32-47-02/400 TEMPERATURE SIGNAL CONDITIONERS - REMOVAL/INSTALLATION	U	Oct 30/15
32-47-02-000-801-A TEMPERATURE SIGNAL CONDITIONERS - REMOVAL	U	Oct 30/15
32-47-02-400-801-A TEMPERATURE SIGNAL CONDITIONERS - INSTALLATION	U	Oct 30/15
32-49-01/300 MAIN WHEEL TIRE - SERVICING	U	Oct 30/15
32-49-01-600-801-A MLG WHEEL TIRE - CHECK AND CHARGE	U	Oct 30/15
32-49-01/600 MAIN WHEEL TIRE - INSPECTION/CHECK	U	Feb 16/16
32-49-01-200-801-A MLG WHEEL TIRE - INSPECTION	U	Apr 29/16
32-49-02/400 MAIN WHEEL ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
32-49-02-000-801-A WHEEL ASSEMBLY OF THE MAIN LANDING GEAR - REMOVAL	U	Apr 28/17
32-49-02-400-801-A WHEEL ASSEMBLY OF THE MAIN LANDING GEAR - INSTALLATION	R	Oct 29/18
32-49-02/600 MAIN WHEEL ASSEMBLY - INSPECTION/CHECK	U	Oct 30/15
32-49-02-200-801-A MLG WHEEL ASSEMBLY - INSPECTION	U	Oct 30/15
32-49-03/400 BRAKE ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
32-49-03-000-801-A BRAKE ASSEMBLY OF THE MAIN LANDING GEAR - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 24 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-49-03-400-801-A BRAKE ASSEMBLY OF THE MAIN LANDING GEAR - INSTALLATION	U	Oct 30/15
32-49-03-000-802-A BRAKE ASSEMBLY SHUTTLE VALVE - REMOVAL	U	Oct 30/15
32-49-03-400-802-A BRAKE ASSEMBLY SHUTTLE VALVE - INSTALLATION	U	Oct 30/15
32-49-03/600 BRAKE ASSEMBLY - INSPECTION/CHECK	U	Oct 30/15
32-49-03-200-801-A BRAKE ASSEMBLY - INSPECTION	U	Oct 31/17
32-49-03-200-803-A BRAKE ASSEMBLY - DETAILED INSPECTION	U	Oct 31/17
32-49-04/300 NOSE WHEEL TIRE - SERVICING	U	Oct 30/15
32-49-04-600-801-A NLG WHEEL TIRE - CHECK AND CHARGING	U	Oct 30/15
32-49-04/600 NOSE WHEEL TIRE - INSPECTION/CHECK	U	Oct 30/15
32-49-04-200-801-A NLG WHEEL TIRE - INSPECTION	U	Oct 30/15
32-49-05/200 NOSE WHEEL ASSEMBLY - MAINTENANCE PRACTICES	U	Apr 27/18
32-49-05-860-801-A NOSE-LANDING-GEAR WHEEL ASSEMBLY - CHECK/BALANCING	U	Apr 27/18
32-49-05/400 NOSE WHEEL ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
32-49-05-000-801-A WHEEL ASSEMBLY OF THE NOSE LANDING GEAR - REMOVAL	U	Apr 29/16
32-49-05-400-801-A WHEEL ASSEMBLY OF THE NOSE LANDING GEAR - INSTALLATION	U	Apr 28/17
32-49-05/600 NOSE WHEEL ASSEMBLY - INSPECTION/CHECK	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 25 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-49-05-200-801-A NLG WHEEL ASSEMBLY - INSPECTION	U	Oct 30/15
32-49-06/400 NOSE WHEEL SPIN BRAKE - REMOVAL/INSTALLATION	U	Oct 30/15
32-49-06-000-801-A NOSE-WHEEL SPIN-BRAKE - REMOVAL	U	Oct 30/15
32-49-06-400-801-A NOSE-WHEEL SPIN-BRAKE - INSTALLATION	U	Oct 30/15
32-49-07/500 BRAKE SHUTTLE VALVE - ADJUSTMENT/TEST	U	Oct 30/15
32-49-07-700-801-A BRAKE SHUTTLE VALVE - OPERATIONAL CHECK	U	Oct 30/15
32-50-00/500 NOSE WHEEL STEERING SYSTEM - ADJUSTMENT/TEST	U	Oct 30/15
32-50-00-700-801-A NOSE WHEEL STEERING SYSTEM DISENGAGEMENT - OPERATIONAL CHECK	U	Oct 30/15
32-50-00-700-802-A NOSE WHEEL STEERING SYSTEM - QUICK ADJUSTMENT	U	Oct 30/15
32-50-00-700-803-A NOSE WHEEL STEERING SYSTEM ACTUATION - OPERATIONAL CHECK	U	Oct 30/15
32-50-00-700-804-A NOSE WHEEL STEERING SYSTEM - COMPLETE ADJUSTMENT	U	Oct 30/15
32-50-00/600 NOSE WHEEL STEERING SYSTEM - INSPECTION/CHECK	U	Oct 30/15
32-50-00-600-801-A NOSE WHEEL POSITION INDICATION MARK PLACARD - INSPECTION	U	Oct 30/15
32-50-01/400 STEERING HANDLE WHEEL - REMOVAL/INSTALLATION	U	Oct 30/15
32-50-01-000-801-A STEERING HANDLE WHEEL - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 26 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-50-01-400-801-A STEERING HANDLE WHEEL - INSTALLATION	U	Oct 30/15
32-50-01/500 STEERING HANDLE WHEEL - ADJUSTMENT/TEST	U	Oct 30/15
32-50-01-700-801-A STEERING HANDLE WHEEL POTENTIOMETER - ADJUSTMENT	U	Oct 30/15
32-50-02/400 RUDDER PEDAL POTENTIOMETER - REMOVAL/INSTALLATION	U	Oct 30/15
32-50-02-000-801-A RUDDER PEDAL POTENTIOMETER - REMOVAL	U	Oct 30/15
32-50-02-400-801-A RUDDER PEDAL POTENTIOMETER - INSTALLATION	U	Oct 30/15
32-50-02-000-802-A RUDDER PEDAL POTENTIOMETER ASSY - REMOVAL	U	Oct 30/15
32-50-02-400-802-A RUDDER PEDAL POTENTIOMETER ASSY - INSTALLATION	U	Oct 30/15
32-50-02/500 RUDDER PEDAL POTENTIOMETER - ADJUSTMENT/TEST	U	Oct 30/15
32-50-02-700-801-A RUDDER PEDAL POTENTIOMETER - ADJUSTMENT/TEST	U	Oct 30/15
32-50-03/400 STEERING ELECTRONIC CONTROL MODULE (SECM) - REMOVAL/ INSTALLATION	U	Oct 30/15
32-50-03-000-801-A NOSE WHEEL STEERING ELECTRONIC CONTROL MODULE - RE- MOVAL	U	Oct 30/15
32-50-03-400-801-A NOSE WHEEL STEERING ELECTRONIC CONTROL MODULE - IN- STALLATION	U	Oct 30/15
32-50-04/400 STEERING MANIFOLD - REMOVAL/INSTALLATION	U	Oct 30/15
32-50-04-000-801-A STEERING MANIFOLD - REMOVAL	U	Feb 16/16

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 27 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-50-04-400-801-A STEERING MANIFOLD - INSTALLATION	U	Oct 30/15
32-50-04/500 STEERING MANIFOLD - ADJUSTMENT/TEST	U	Oct 30/15
32-50-04-700-801-A STEERING MANIFOLD - FUNCTIONAL TEST	U	Oct 30/15
32-50-05/400 LOAD POTENTIOMETER - REMOVAL/INSTALLATION	U	Oct 30/15
32-50-05-000-801-A LOAD POTENTIOMETER - REMOVAL	U	Oct 30/15
32-50-05-400-801-A LOAD POTENTIOMETER - INSTALLATION	U	Oct 30/15
32-50-05/500 LOAD POTENTIOMETER - ADJUSTMENT/TEST	U	Oct 30/15
32-50-05-700-801-A LOAD POTENTIOMETER - ADJUSTMENT	U	Oct 30/15
32-50-06/400 7-DEGREE PROXIMITY SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
32-50-06-000-801-A 7-DEGREE PROXIMITY SWITCH - REMOVAL	U	Oct 30/15
32-50-06-400-801-A 7-DEGREE PROXIMITY SWITCH - INSTALLATION	U	Oct 30/15
32-50-06/500 7-DEGREE PROXIMITY SWITCH - ADJUSTMENT/TEST	U	Oct 30/15
32-50-06-700-801-A 7-DEGREE PROXIMITY SWITCH - FUNCTIONAL CHECK	U	Oct 30/15
32-50-06-700-802-A 7-DEGREE PROXIMITY SWITCH - ADJUSTMENT	U	Oct 30/15
32-50-07/200 FEEDBACK UNIT (POTENTIOMETER) - MAINTENANCE PRACTICES	U	Oct 30/15
32-50-07-900-801-A FEEDBACK POTENTIOMETER - RESTORATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 28 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-50-07/400 FEEDBACK UNIT (POTENTIOMETER) - REMOVAL/INSTALLATION	U	Oct 30/15
32-50-07-000-801-A FEEDBACK UNIT (POTENTIOMETER) - REMOVAL	U	Oct 30/15
32-50-07-400-801-A FEEDBACK UNIT (POTENTIOMETER) - INSTALLATION	U	Oct 30/15
32-50-07/500 FEEDBACK UNIT (POTENTIOMETER) - ADJUSTMENT/TEST	U	Oct 30/15
32-50-07-700-801-A FEEDBACK UNIT (POTENTIOMETER) - FUNCTIONAL CHECK/ ADJUSTMENT	U	Oct 30/15
32-50-08/400 DISENGAGE SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
32-50-08-000-801-A DISENGAGE SWITCH - REMOVAL	U	Oct 30/15
32-50-08-400-801-A DISENGAGE SWITCH - INSTALLATION	U	Oct 30/15
32-50-09/400 <i>EFFECTIVITY: AIRCRAFT WITH EXTERNAL STEERING DISENGAGE- MENT SWITCH</i> EXTERNAL STEERING DISENGAGEMENT SWITCH - REMOVAL/ INSTALLATION	U	Oct 30/15
32-50-09-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH EXTERNAL STEERING DISENGAGE- MENT SWITCH</i> EXTERNAL STEERING DISENGAGEMENT SWITCH - REMOVAL	U	Oct 30/15
32-50-09-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH EXTERNAL STEERING DISENGAGE- MENT SWITCH</i> EXTERNAL STEERING DISENGAGEMENT SWITCH - INSTALLATION	U	Oct 30/15
32-50-10/400 NOSE WHEEL STEERING INDICATION PLATES - REMOVAL/INSTAL- LATION	U	Oct 30/15
32-50-10-000-801-A STEERING INDICATION PLATES - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 29 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-50-10-400-801-A STEERING INDICATION PLATES - INSTALLATION	U	Oct 30/15
32-60-00/200 LANDING GEAR PROXIMITY AND PRESSURE SWITCH PROTECTION / RESTORATION - MAINTENANCE PRACTICES	U	Oct 31/16
32-60-00-910-801-A LANDING GEAR PROXIMITY SWITCH AND HARNESS ELECTRICAL CONNECTORS - RESTORATION AND PROTECTION	U	Oct 31/16
32-60-00-910-802-A CONNECTOR OF THE PRESSURE SWITCH - PROTECTION	U	Oct 30/15
32-61-01/400 LANDING GEAR UPLOCK PROXIMITY SWITCH - REMOVAL/INSTALLA- TION	U	Oct 30/15
32-61-01-000-801-A UPLOCK PROXIMITY SWITCH - REMOVAL	U	Oct 30/15
32-61-01-400-801-A UPLOCK PROXIMITY SWITCH - INSTALLATION	U	Oct 30/15
32-61-01-040-801-A UPLOCK PROXIMITY SWITCH - DEACTIVATION PROCEDURE	U	Oct 30/15
32-61-01-440-801-A UPLOCK PROXIMITY SWITCH - REACTIVATION PROCEDURE	U	Oct 30/15
32-61-02/400 LANDING GEAR DOWNLOCK PROXIMITY SWITCH - REMOVAL/ INSTALLATION	U	Oct 30/15
32-61-02-000-801-A DOWNLOCK PROXIMITY SWITCH - REMOVAL	U	Oct 30/15
32-61-02-400-801-A DOWNLOCK PROXIMITY SWITCH - INSTALLATION	U	Oct 30/15
32-61-02-040-801-A DOWNLOCK PROXIMITY SWITCH - DEACTIVATION PROCEDURE	U	Oct 30/15
32-61-02-440-801-A DOWNLOCK PROXIMITY SWITCH - REACTIVATION PROCEDURE	U	Oct 30/15
32-62-00/500 LANDING GEAR WARNING SYSTEM - ADJUSTMENT/TEST	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 30 of 32
Rev 55 - Oct 29/18

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
32-62-00-700-801-A LANDING-GEAR WARNING SYSTEM - OPERATIONAL CHECK	U	Oct 30/15
32-63-00/200 AIR/GROUND (WOW) SYSTEM SIMULATION - MAINTENANCE PRACTICES	U	Oct 30/15
32-63-00-860-801-A "FLIGHT"/"GROUND" CONDITION SIMULATION IN AIR/GROUND SYSTEM	U	Apr 27/18
32-63-00/500 AIR/GROUND (WOW) SYSTEM SIMULATION - ADJUSTMENT/TEST	U	Oct 30/15
32-63-00-700-801-A AIR/GROUND SYSTEM - OPERATIONAL CHECK	U	Oct 31/16
32-63-01/400 MAIN-LANDING-GEAR AIR/GROUND (WOW) PROXIMITY SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
32-63-01-000-801-A AIR/GROUND (WOW) PROXIMITY SWITCH OF MLG - REMOVAL	U	Oct 30/15
32-63-01-400-801-A AIR/GROUND (WOW) PROXIMITY SWITCH OF MLG - INSTALLATION	U	Oct 30/15
32-63-02/400 NOSE-LANDING-GEAR AIR/GROUND (WOW) PROXIMITY SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
32-63-02-000-801-A AIR/GROUND (WOW) PROXIMITY SWITCH OF NLG - REMOVAL	U	Oct 30/15
32-63-02-400-801-A AIR/GROUND (WOW) PROXIMITY SWITCH OF NLG - INSTALLATION	U	Oct 30/15
32-63-03/400 NOSE-LANDING-GEAR DOOR-SEQUENCE PROXIMITY SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
32-63-03-000-801-A DOOR-SEQUENCE PROXIMITY SWITCH OF THE NLG - REMOVAL	U	Oct 30/15
32-63-03-400-801-A DOOR-SEQUENCE PROXIMITY SWITCH OF THE NLG - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 32
Page 31 of 32
Rev 55 - Oct 29/18

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
32-63-04/400 <i>EFFECTIVITY: JAA CERTIFIED AIRCRAFT</i> NOSE-LANDING-GEAR DOOR OPEN PROXIMITY SWITCH - REMOV- AL/INSTALLATION	U	Oct 30/15
32-63-04-000-801-A <i>EFFECTIVITY: JAA CERTIFIED AIRCRAFT</i> NLG DOOR-OPEN PROXIMITY SWITCH - REMOVAL	U	Oct 30/15
32-63-04-400-801-A <i>EFFECTIVITY: JAA CERTIFIED AIRCRAFT</i> NLG DOOR-OPEN PROXIMITY SWITCH - INSTALLATION	U	Oct 30/15
32-63-05/500 LANDING-GEAR PROXIMITY SWITCH - ADJUSTMENT/TEST	U	Oct 30/15
32-63-05-700-801-A PROXIMITY SWITCH (SENSOR) - FUNCTIONAL CHECK	U	Oct 30/15
32-63-05-700-802-A PROXIMITY SWITCH (SENSOR) - FUNCTIONAL CHECK - ALTERNA- TIVE PROCEDURE	U	Oct 30/15
32-63-05-700-803-A PROXIMITY SWITCH (SENSOR) - CLEARANCE (GAP) ADJUSTMENT	U	Oct 30/15
32-63-05-700-804-A PROXIMITY SWITCH (SENSOR) - CLEARANCE (GAP) ADJUSTMENT - ALTERNATIVE PROCEDURE	U	Oct 30/15
32-63-05/800 LANDING-GEAR PROXIMITY SWITCH - REPAIR	U	Oct 30/15
32-63-05-300-801-A PROXIMITY SWITCH - REPAIR	U	Oct 30/15