

THRUST REVERSER MODULE - EXTERNAL - INSPECTION/CHECK

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to do the visual inspection of the thrust reverser module for general condition.
- B. Related Zones: 416/426.
- C. Zone Boundaries: STA XN = 3085.0 thru STA XN = 4543.81.
- D. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
05-20-74-200-801-A ♦	THRUST REVERSER MODULE - EXTER- NAL GENERAL VISUAL INSPECTION	ALL

TASK 05-20-74-200-801-A

EFFECTIVITY: ALL

## 2. THRUST REVERSER MODULE - EXTERNAL GENERAL VISUAL INSPECTION

### A. General

- (1) This task gives instructions to do SMRD Zonal Task 78-Z416-213-001-A00.
- (2) You must do the external general visual inspection (GVI) of thrust reverser module, at zones 416/426, within a touching distance of the items examined.
- (3) The function of the external visual inspection (GVI) is to find damage, failure, or irregular conditions that can be easily seen.

### B. References

REFERENCE	DESIGNATION
<a href="#">AMM MPP 78-30-00/200</a>	- MAINTENANCE PRACTICES

### C. Zones and Accesses

Not Applicable

### D. Tools and Equipment

ITEM	DESCRIPTION	PURPOSE	QTY
Standard	Ladder	To get access to the inspection area	

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Thrust reverser

### I. Preparation

SUBTASK 841-002-A

**WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN [AMM MPP 78-30-00/200](#) TO PREVENT INJURY TO PERSONS AND DAMAGE TO MATERIAL.**

- (1) Put the ladder in position.

J. External General Visual Inspection ([Figure 601](#))

*SUBTASK 212-002-A*

**WARNING: DO NOT TOUCH THE THRUST REVERSER AND ENGINE COMPONENTS UNTIL THEY ARE COOL. THE TEMPERATURE CAN STAY HOT FOR A LONG TIME AFTER THE ENGINE STOPS.**

- (1) Examine the thrust reverser external zone for loose rivets, nicks, cracks, dents, erosion, corrosion, deformation, and deteriorated protective treatment ([Figure 601](#)).

K. Follow-on



*SUBTASK 842-002-A*

- (1) Remove the ladder.

EFFECTIVITY: ALL

Thrust Reverser Module - External General Visual Inspection

Figure 601



DET. A

145AMM050057.MCE A