

PORTABLE FIRE EXTINGUISHERS - ADJUSTMENT/TEST

EFFECTIVITY: NOT APPLICABLE TO DISPOSABLE FIRE EXTINGUISHERS

1. General

- A. This section gives the procedures to do a hydrostatic check of the portable fire extinguishers.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
26-24-01-700-801-A ◆	PORTABLE FIRE EXTINGUISHERS - HYDROSTATIC CHECK	NOT APPLICABLE TO DISPOSABLE FIRE EXTINGUISHERS

TASK 26-24-01-700-801-A

EFFECTIVITY: NOT APPLICABLE TO DISPOSABLE FIRE EXTINGUISHERS

2. PORTABLE FIRE EXTINGUISHERS - HYDROSTATIC CHECK

A. General

- (1) To do this check, it is necessary to remove the fire extinguisher from the aircraft.
- (2) To do the task, refer to the manufacturer's instructions.

B. References

REFERENCE	DESIGNATION
AMM TASK 26-24-01-000-801-A/400	-
AMM TASK 26-24-01-400-801-A/400	-

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin

I. Preparation

SUBTASK 841-002-A

- (1) Get access to the applicable portable fire extinguisher.
- (2) Remove the portable fire extinguisher (AMM TASK 26-24-01-000-801-A/400).

J. Hydrostatic Check of the Portable Fire Extinguisher

SUBTASK 720-002-A

- (1) Do a hydrostatic test of the portable fire extinguisher. Refer to the applicable fire extinguisher component maintenance manual or to the instructions on the fire extinguisher bottle.

K. Follow-on

SUBTASK 842-002-A

- (1) Install the applicable portable fire extinguisher (AMM TASK 26-24-01-400-801-A/400).
- (2) Put the aircraft back to its usual configuration.

