

## PYLON FIRE DETECTOR - REMOVAL/INSTALLATION

*EFFECTIVITY: ALL*

1. General

- A. This section gives the procedures to remove/install the pylon fire detector.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
26-11-02-000-801-A	PYLON FIRE DETECTOR - REMOVAL	ALL
26-11-02-400-801-A	PYLON FIRE DETECTOR - INSTALLATION	ALL

TASK 26-11-02-000-801-A

EFFECTIVITY: ALL

## 2. PYLON FIRE DETECTOR - REMOVAL

### A. General

(1) This task is applicable to the LH and RH pylons.

### B. References

REFERENCE	DESIGNATION
<a href="#">AMM MPP 71-00-00/200</a>	- MAINTENANCE PRACTICES
<a href="#">AMM TASK 71-11-01-000-801-A/400</a>	ENGINE UPPER COWLING - REMOVAL

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
412	Upper cowling	LH engine
422	Upper cowling	RH engine
413	Lower cowling	LH engine
423	Lower cowling	RH engine

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the pylon	1

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Pylon

### I. Preparation

SUBTASK 841-002-A

**WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN [AMM MPP 71-00-00/200](#) TO PREVENT INJURY TO PERSONS AND DAMAGE TO MATERIAL.**

- (1) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them.
  - START 1/2.
  - POWERPLANT FIRE DET 1/2.
- (2) Put the workstand in the work area.
- (3) Remove the upper cowling ([AMM TASK 71-11-01-000-801-A/400](#)) to get access to the pylon fire detector.

J. Removal ([Figure 401](#))

*SUBTASK 020-002-A*


**CAUTION:** DURING THE REMOVAL PROCEDURE, IF THE DETECTOR IS IN CONDITION TO BE USED AGAIN, BE CAREFUL NOT TO CAUSE DAMAGE OR SHARP BENDS TO IT.

- (1) Disconnect the electrical connector (1) from the detector (2).
- (2) Release the Dzus fastener from the sensing element (5).
- (3) Cut the lockwire and remove the clamp (3) which attaches the detector (2) to the support in the pylon.
- (4) Remove the detector (2) and sensing element (5) from the pylon.
- (5) Install protection caps to the disconnected points.

EFFECTIVITY: ALL

Pylon Fire Detector - Removal/Installation

Figure 401



145AMM260004.MCE B

TASK 26-11-02-400-801-A  
EFFECTIVITY: ALL

### 3. PYLON FIRE DETECTOR - INSTALLATION

#### A. General

(1) This task is applicable to the LH and RH pylons.

#### B. References

REFERENCE	DESIGNATION
<a href="#">AMM MPP 71-00-00/200</a>	- MAINTENANCE PRACTICES
AMM TASK 26-10-00-700-801-A/500	-
AMM TASK 26-10-00-700-802-A/500	-
<a href="#">AMM TASK 71-11-01-400-801-A/400</a>	ENGINE UPPER COWLING - INSTALLATION

#### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
412	Upper cowling	LH engine
422	Upper cowling	RH engine
413	Lower cowling	LH engine
423	Lower cowling	RH engine

#### D. Tools and Equipment

Not Applicable

#### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the pylon	1

#### F. Consumable Materials

SPECIFICATION (BRAND)	DESCRIPTION	QTY
MS20995C20	Lockwire	AR

#### G. Expandable Parts

Not Applicable

#### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Pylon

I. Installation (Figure 401)

*SUBTASK 420-002-A*

**WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN [AMM MPP 71-00-00/200](#) TO PREVENT INJURY TO PERSONS AND DAMAGE TO MATERIAL.**

**CAUTION: THE SENSING ELEMENT MUST NOT DIRECTLY TOUCH A PYLON PART, OR HAVE SHARP BENDS OR MASHES.**

- (1) Remove the protection caps from the disconnected points, if applicable.
- (2) Put the detector (2) and sensing element (5) in the pylon.
- (3) Attach the detector (2) to the pylon support with the clamp (3) and safety it.
- (4) Attach the sensing element (5) to the clamps (4) with the Dzus fastener.
- (5) Connect the electrical connector (1) to the detector (2).

J. Follow-on

*SUBTASK 842-002-A*

- (1) Install the upper cowling ([AMM TASK 71-11-01-400-801-A/400](#)).
- (2) Remove the workstand.
- (3) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them:
  - START 1/2.
  - POWERPLANT FIRE DET 1/2.
- (4) Do an operational test of the fire detection system (AMM TASK 26-10-00-700-801-A/500) or (AMM TASK 26-10-00-700-802-A/500) as applicable.