

## PACK DUCT OVERTEMPERATURE SWITCH - ADJUSTMENT/TEST

*EFFECTIVITY: ALL*

### 1. General

- A. This section gives the procedures to do the functional check of the cooling-pack duct overtemperature switch.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
21-51-09-700-801-A ♦	COOLING-PACK DUCT OVERTEMPERATURE SWITCH - FUNCTIONAL CHECK	ALL

TASK 21-51-09-700-801-A

EFFECTIVITY: ALL

## 2. COOLING-PACK DUCT OVERTEMPERATURE SWITCH - FUNCTIONAL CHECK

### A. General

- (1) To do the functional check of the cooling-pack duct overtemperature switch, refer to Hamilton Sundstrand CMM 21-61-69.

### B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
<a href="#">AMM TASK 21-51-09-000-801-A/400</a>	PACK DUCT OVERTEMPERATURE SWITCH - REMOVAL
<a href="#">AMM TASK 21-51-09-400-801-A/400</a>	PACK DUCT OVERTEMPERATURE SWITCH - INSTALLATION
Hamilton Sundstrand CMM 21-61-69	-

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
191	191EL	Left side of the wing-to-fuselage fairing
191	191FR	Right side of the wing-to-fuselage fairing

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

Not Applicable

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	LH or RH cooling pack

### I. Preparation

**SUBTASK 841-002-A**

- (1) Remove the access panel(s) AMM MPP 06-41-01/100 as applicable:
- 191EL (duct overtemperature switch of the LH cooling pack).
  - 191FR (duct overtemperature switch of the RH cooling pack).

- (2) Remove the cooling-pack duct overtemperature switch from the aircraft (Refer to [AMM TASK 21-51-09-000-801-A/400](#)).

J. Switch Functional Check

*SUBTASK 720-002-A*

- (1) Do the functional check of the switch. Refer to Hamilton Sundstrand CMM 21-61-69.

K. Follow-on

*SUBTASK 842-002-A*

- (1) Install the cooling-pack duct overtemperature switch in the aircraft (Refer to [AMM TASK 21-51-09-400-801-A/400](#)).
- (2) Install the access panel(s) (AMM MPP 06-41-01/100), as applicable:
  - 191EL (duct overtemperature switch of the LH cooling pack).
  - 191FR (duct overtemperature switch of the RH cooling pack).

